

1/SSP

320REQ0007

496568

DATA REQUIREMENT (DR) - 10

EXPERIMENT/FACILITY REQUIREMENTS DOCUMENT FOR THE
SPACE STATION FURNACE FACILITY

SECTION 1: INTEGRATED CONFIGURATION-1

(NASA-CR-192533)
EXPERIMENT/FACILITY REQUIREMENTS
DOCUMENT FOR THE SPACE STATION
FURNACE FACILITY. SECTION 1:
INTEGRATED CONFIGURATION Final
Report (Teledyne Brown
Engineering) 350 p

N93-27147

Uncclas

G3
■/18 0165062

NASA-32077
DRAFT
MAY 1992

372

• 8 5 0 7 5 0 8

• 8 5 0 7 5 0 8

FOREWORD

The Space Station Furnace Facility (SSFF) is designed to accommodate and support a variety of furnace modules throughout the operational lifetime of the facility. Since the SSFF will be operational for 30 years, and various furnace modules will be accommodated, the Experiment/Facility Requirements Document (E/FRD) is divided into two separate sections. Section 1 describes the integrated SSFF-to-SSF interface, which includes the SSFF Core subsystem requirements and the furnace module requirements based on the information obtained from the Furnace Developer's Section 2, and Section 2 describes the furnace module-to-SSFF interface. Multiple Section 2s may be required for each E/FRD, depending on how many furnace modules the SSFF will accommodate per mission, since a separate Section 2 will be written for each furnace module. Both sections will be replaced for each mission with the appropriate mission-peculiar furnace module interface requirements since the Core configuration is a function of the furnace module(s).

This E/FRD reflects the Initial Configuration-1 (IC1), which is the initial integration of the SSFF Core and Furnace Module-1 into the SSF U. S. Laboratory Module-A. IC1 is planned for 1997, based on the assumption that Utilization Flight 3 (UF-3) is the carrier. Furnace Module-1 is scheduled to be an upgrade of the present Crystal Growth Furnace (CGF), and Section 2 reflects the requirements of that module.



TABLE OF CONTENTS

<u>SECTION</u>	<u>TITLE</u>	<u>PAGE</u>
1.1	FUNCTIONAL OBJECTIVES AND EQUIPMENT IDENTIFICATION.....	1.1-1
1.1.1	System Description.....	1.1-1
1.1.2	Functional Objectives	1.1-1
1.1.3	Equipment Identification.....	1.1-3
1.1.4	Operational Functional Flows.....	1.1-3
1.2	STRUCTURAL/MECHANICAL	1.2-1
1.2.1	Equipment List and Mass Properties	1.2-1
1.2.2	Interface Detail	1.2-1
1.2.2.1	SSF-to-SSFF MSS Interface	1.2-1
1.2.2.2	SSF-to-SSFF Core Rack Interface.....	1.2-12
1.2.2.2.1	SSFF EPS-to-SSFF Core Rack.....	1.2-12
1.2.2.2.2	SSFF DMS-to-SSFF Core Rack.....	1.2-12
1.2.2.2.3	SSF TCS-to-SSFF Core Rack.....	1.2-12
1.2.2.2.4	SSF VES-to-SSFF Core Rack.....	1.2-12
1.2.2.2.5	SSF-to-SSFF Experiment Rack-1 Interface.....	1.2-12
1.2.2.3	SSF-to-SSFF Experiment Rack-1 Interface.....	1.2-12
1.2.2.4	Crew Interface	1.2-15
1.3	POINTING/STABILIZATION AND ALIGNMENT	1.3-1
1.4	ORBITAL REQUIREMENTS AND CONSTRAINTS	1.4-1
1.5	ELECTRICAL REQUIREMENTS	1.5-1
1.6	THERMAL FLUID REQUIREMENTS	1.6-1
1.6.1	Heat Transfer Characteristics.....	1.6-1
1.6.2	Fluid/Vent Requirements	1.6-1
1.7	DATA SYSTEM REQUIREMENTS	1.7-1
1.7.1	Signal Interface Definition.....	1.7-1
1.7.2	Signal Interface Definition Expansion.....	1.7-1
1.7.3	Event/Exception Monitoring Requirements.....	1.7-1
1.7.4	Payload Operations Integration Center Display Requirements	1.7-1
1.7.5	POIC Limit Sensing/Exception Monitoring Requirements	1.7-61
1.8	FLIGHT SOFTWARE REQUIREMENTS	1.8-1
1.8.1	Command Support	1.8-1
1.8.2	Health and Status Data	1.8-1
1.8.3	Onboard Storage.....	1.8-1
1.8.4	Display.....	1.8-1
1.8.5	Program Loads and Modifications Downloading.....	1.8-1
1.8.6	Ancillary Data	1.8-1

TABLE OF CONTENTS (Cont.)

<u>SECTION</u>	<u>TITLE</u>	<u>PAGE</u>
1.9 PHYSICAL INTEGRATION		1.9-1
1.9.1 Rack Integration and Checkout		1.9-1
1.9.1.1 Core Rack Checkout		1.9-1
1.9.1.2 Experiment Rack-1 Checkout.....		1.9-1
1.9.1.3 Furnace Module-1 Checkout.....		1.9-1
1.9.1.4 Integrated Furnace Rack Checkout.....		1.9-1
1.9.1.5 SSFF Facility Checkout.....		1.9-5
1.9.2 KSC Verification		1.9-5
1.9.3 Postlanding.....		1.9-5
1.10 OPERATIONS SUPPORT		1.10-1
1.11 TRAINING OBJECTIVES		1.11-1
1.12 ENVIRONMENTAL CONTAMINATION DATA REQUIREMENTS		1.12-1

LIST OF FIGURES

<u>FIGURE</u>	<u>TITLE</u>	<u>PAGE</u>
1.1-1	SSFF IC1 Configuration	1.1-2
1.1-2	DMS Component Tree	1.1-40
1.1-3	PCDS Component Tree	1.1-41
1.1-4	TCS Component Tree	1.1-42
1.1-5	GDS Component Tree	1.1-43
1.1-6	Furnace Module-1 Equipment Pictorial Representation	1.1-44
1.1-7	SSFF Block Diagram	1.1-45
1.2-1	SSFF-to-SSF Resource Interfaces.....	1.2-2
1.2-2	SSF-to-SSFF Core Rack Physical Interface.....	1.2-9
1.2-3	SSF-to-SSFF Experiment Rack-1 Physical Interface	1.2-10
1.2-4	SSFF Interconnect Tray Assembly	1.2-11
1.2-5	Core Rack Panel Layout	1.2-13
1.2-6	Experiment Rack-1 Panel Layout.....	1.2-14
1.5-1	PCDS Interface Block Diagram.....	1.5-2
1.5-2	Power Profiles by Functional Objectives	1.5-3
1.6-1	TCS Interface Block Diagram.....	1.6-2
1.6-2	GDS Interface Block Diagram.....	1.6-5
1.7-1	DMS Interface Block Diagram	1.7-2
1.8-1	SSFF Software External Interface Diagram	1.8-2
1.8-2	Software Component Tree.....	1.8-3
1.9-1	Physical Integration Flow.....	1.9-2
1.9-2	Physical Deintegration Flow	1.9-7

LIST OF TABLES

<u>TABLE</u>	<u>TITLE</u>	<u>PAGE</u>
1.1-1	SSFF Functional Objectives.....	1.1-4
1.1-2	Functional Objective Requirements Sheets	1.1-21
1.1-3	SSFF Operational Functional Flow.....	1.1-46
1.2-1	List of Equipment Properties	1.2-3
1.2-2	Stowage List	1.2-8
1.6-1	On-Orbit Thermal Requirements	1.6-3
1.6-2	Fluid Requirements.....	1.6-6
1.7-1	Signal Interface Definition	1.7-3
1.7-2	Signal Interface Definition Expansion.....	1.7-4
1.7-3	Event/Exception Monitor Requirements.....	1.7-42
1.7-4	POIC Display Requirements.....	1.7-43
1.7-5	POIC Limit Sensing/Exception Monitor Requirements	1.7-63
1.9-1	SSFF Integration Ground Processing Requirements.....	1.9-3
1.9-2	SSFF Integration Requirements.....	1.9-4
1.9-3	SSFF Postlanding Ground Processing Requirements.....	1.9-6
1.10-1	SSFF Mission Operations Support.....	1.10-2
1.11-1	Training Participation	1.11-2
1.11-2	Training Objectives	1.11-3
1.12-1	Flight Environment Limits.....	1.12-2
1.12-2	External Contamination Sources	1.12-3

ACRONYM LIST

AA	Avionics Air
CCF	Centralized Core Function
CCOS	Centralized Core Operating System
CCU	Core Control Unit
CdTe	Cadmium Telluride
CGF	Crystal Growth Furnace
cm	Centimeter
CMCU	Core Monitor and Control Unit
CP	Coldplate
CPC	Core Power Conditioners
CPCS	Core Power Conditioners Stimulus
CRW	Crew
CSF	Core-Specific Function Data Management Subsystem (SSFF)
DC	Direct Current
DCF	Distributed Core Function
DCMU	Distributed Core Monitoring Unit
DCOS	Distributed Core Operating System
dia	Diameter
DMS	Data Management System (SSF)
DR	Data Requirement
E/FRD	Experiment/Facility Requirements Document
EAC	Experiment Apparatus Container
EPS	Electrical Power System
ESF	Experiment-Specific Function
Ess	Essential
FAU	Furnace Actuator Unit
FCU	Furnace Control Unit
FDACS	Furnace Data Acquisition and Control System
FDDI	Fiber Distributed Data Interface
FDIR	Fault Detection, Isolation, and Recovery
FDS	Fire Detection and Suppression
FM-1	Furnace Module-1
FO	Functional Objective
ft	Foot

ACRONYM LIST (Cont.)

ft ²	Square foot
FTM	Furnace Translation Mechanism
g	Gravity
GaAs	Gallium Arsenide
GDS	Gas Distribution Subsystem
GHE	Gaseous Helium
GN ₂	Gaseous Nitrogen
GND	Ground
GSE	Ground Support Equipment
H/W	Hardware
H ₂ O	Water
HDR	High-Density Recorder
HgZnTe	Mercury Zinc Telluride
HRDL	High-Rate Data Link
h	Hour
HX	Heat Exchanger
Hz	Hertz
IC1	Integrated Configuration-1
IROP	Integrated Requirements on Payloads
IFEA	Integrated Furnace Enclosure Apparatus
ISPR	International Standard Payload Rack
ISS	Internal Support Structure
JSC	Johnson Space Center
kg	Kilogram
KSC	Kennedy Space Center
kW	Kilowatt
kWh	Kilowatthour
LAN	Local Area Network
lbm	Pound Mass
LNS	Liquid Nitrogen System
MBPS	Megabytes per Second
MDM	Multiplexer/Demultiplexer
mm	Millimeter
MPAC	Multipurpose Application Console

ACRONYM LIST (Cont.)

MPLM	Mini-Pressurized Logistics Module
MSFC	Marshall Space Flight Center
MSS	Mechanical Structures Subsystem
NASA	National Aeronautics and Space Administration
NTSC	National Television Standard Committee
OMIS	Operations Management Information System
ORU	Orbital Replacement Unit
PAM	Payload Accommodations Manager
PCDS	Power Conditioning and Distribution Subsystem
PED	Payload Element Developer
PES	Payload Executive Software
PI	Payload Investigator
PIC	Payload Integration Center
PIM	Payload Increment Manager
PLM	Pressurized Logistics Module
POIC	Payload Operations Integration Center
ppm	Parts per Million
psia	Pounds per Square Inch Absolute
PTRD	Payload Training Requirements Document
QD	Quick Disconnect
RFM	Reconfigurable Furnace Module
RPC	Remote Power Controller
RPCM	Remote Power Controller Module
RPDA	Remote Power Distribution Assembly
S/W	Software
SACA	Sample Ampoule/Cartridge Assembly
sec	Second
SEM	Sample Exchange Mechanism
SIP	Sample Insertion Port
SS	Subsystem
SSF	Space Station Freedom
SSFF	Space Station Furnace Facility
STS	Space Transportation System
SW	Software

ACRONYM LIST (Conc.)

TAT	Training Assessment Team
TBD	To Be Determined
TCS	Thermal Control System (SSF) Thermal Control Subsystem (SSFF)
UF-3	Utilization Flight 3
UPTP	User Payload Training Plan
USL	United States Laboratory
V	Volt
Vdc	Volts Direct Current
VES	Vacuum Exhaust System
W	Watt
μm	Micrometer
$\text{M}\Omega$	Megohm

1.1. FUNCTIONAL OBJECTIVES AND EQUIPMENT IDENTIFICATION

1.1.1 SYSTEM DESCRIPTION

The function of the Space Station Furnace Facility (SSFF) is to support materials research into the crystal growth and solidification processes of electronic and photonic materials, metals and alloys, and glasses and ceramics. To support this broad base of research requirements, the SSFF will employ a variety of furnace modules operated, regulated, and supported by a core of common subsystems. Furnace modules may be reconfigured or specifically developed to provide unique solidification conditions for each set of experiments. The SSFF modular approach permits the addition of new or scaled-up furnace modules to support the evolution of the facility as new science requirements are identified. The SSFF Core is of modular design to permit augmentation for enhanced capabilities.

The fully integrated configuration of the SSFF will consist of three racks with the capability of supporting up to two furnace modules per rack. The initial configuration of the SSFF will consist of two of the three racks and one furnace module. This Experiment/Facility Requirements Document (E/FRD) describes the integrated facility requirements for the Space Station Freedom (SSF) Integrated Configuration-1 (IC1) mission. The IC1 SSFF will consist of two racks: the Core Rack, with the centralized subsystem equipment, and the Experiment Rack-1, with Furnace Module-1 and the distributed subsystem equipment to support the furnace.

The IC1 SSFF configuration is shown in Figure 1.1-1. It consists of two double rack replacement structures, the centralized and distributed components to support furnace operations, and Furnace Module-1. The SSFF support functions are provided by the following Core subsystems:

- Power Conditioning and Distribution Subsystem (SSFF PCDS)
- Data Management Subsystem (SSFF DMS)
- Thermal Control Subsystem (SSFF TCS)
- Gas Distribution Subsystem (SSFF GDS)
- Mechanical Structures Subsystem (SSFF MSS)

1.1.2 FUNCTIONAL OBJECTIVES

There are 13 functional objectives (FOs) for the SSFF which are structured as one FO for payload checkout; one FO for Core activation; one FO for the distributed equipment activation; eight FOs for experiment sample operations, calibration/bakeout, and vent and purge cycles; one FO for furnace sample loading or shutdown; and one FO for SSFF shutdown. The actual FO numbering is as follows:




FIGURE 1.1-1. SSFF IC1 CONFIGURATION

- FO-0 Payload Checkout
- FO-1 Core Activation
- FO-2 Distributed Equipment Activation
- FO-3 Furnace Module-1 Sample Exchange
- FO-4 Furnace Module-1 Vent/Purge
- FO-5 Furnace Module-1 Process Sample HgCdTe
- FO-6 Furnace Module-1 Process Sample HgZnTe
- FO-6A Furnace Module-1 Process Sample Extended HgZnTe
- FO-7 Furnace Module-1 Process Sample CdTe
- FO-8 Furnace Module-1 Process Sample GaAs
- FO-9 Configure Furnace Module-1 for Sample Loading or Shutdown
- FO-10 SSFF Shutdown
- FO-11 Furnace Module-1 Process Calibration/Bakeout

Table 1.1-1 shows a listing of the SSFF FOs along with the equipment associated with each step of each FO. Step duration, crew time requirements, and average power requirements for each step of each FO are defined in Table 1.1-2, Functional Objective Requirements Sheets.

1.1.3 EQUIPMENT IDENTIFICATION

The SSFF will occupy two double rack locations in the U. S. Laboratory (USL) for IC1. The Core Rack, modified [relative to the International Standard Payload Rack (ISPR)] to permit interconnections to the adjacent experiment rack, will provide mechanical/structural interface for the centralized SSFF subsystem components. Experiment Rack-1 will provide mechanical/structural interface for distributed SSFF subsystem equipment required to support the furnace operation, and Furnace Module-1. Figures 1.1-2 through 1.1-5 show the SSFF centralized and distributed equipment to the Orbital Replacement Unit (ORU) level per subsystem. Figure 1.1-6 shows the Furnace Module-1 equipment. A block diagram of the SSFF is shown in Figure 1.1-7, which identifies and shows the interrelationship of each item of SSFF equipment and the interfaces with SSF and the furnace module.

1.1.4 OPERATIONAL FUNCTIONAL FLOWS

Preliminary functional flows are shown in Table 1.1-3 for each FO. Functional flows define the function performed, the performing element, and decisions involved in accomplishing each FO.

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 1 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-1 Step 1	CCU and CMCU Activation	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors
FO-1 Step 2	SSFF to Ground Link	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors
FO-1 Step 3	Test CMCU	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors
FO-1 Step 4	Configure and Test TCS in Core Rack	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 2 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-1 Step 5	Test CPC	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Core Power Conditioners
FO-1 Step 6	GDS Test	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Latching Solonoid Valves Contamination Monitor
FO-1 Step 7	Activate Camera and Videolink	NOT USED IN IC1
FO-1 Step 8	Core Readiness Check	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 3 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-1 Step 8 (Cont.)	Core Readiness Check	Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers
FO-2 Step 1	CCU Powers RPCM/DCMU	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit
FO-2 Step 2	CCU Powers FCU	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit
FO-2 Step 3	FCU Checkout	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 4 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-2 Step 3 (Cont.)	FCU Checkout	Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit
FO-2 Step 4	FAU Powered	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-2 Step 5	FAU Checkout	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 5 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-2 Step 6	Configure and Test TCS in Furnace Rack	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducer Video Processor Unit Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-2 Step 7	GDS Test	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 6 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-2 Step 8	Furnace-Specific Tests	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-3 Step 1	Command Manual Sample Exchange	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 7 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-3 Step 2	Vent/Fill Furnace Module-1	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-3 Step 3	Equalize Furnace Module-1 Pressure	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit Manual Valve
FO-3 Step 4	Prep Equipment	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 8 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-3 Step 4 (Cont.)	Prep Equipment	Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-3 Step 5	Open SIP	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-3 Step 6	Insert Samples	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 9 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-3 Step 7	Close SIP	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-3 Step 8	Open Valves	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit Manual Valves
FO-3 Step 9	Command Manual Sample Exchange Off	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 10 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-3 Step 9 (Cont.)	Command Manual Sample Exchange Off	Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-3 Step 10	Perform Seal Check	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-4 Step 1	GN ₂ Purge Furnace	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 11 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-4 Step 2	Argon Backfill	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package. Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-4 Step 3	Command Sample Process	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-4 Step 4	TCS Configured	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 12 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-4 Step 3 (Cont.)	TCS Configured	Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit
FO-5	Vapor Crystal Growth of HgCdTe	All equipment listed below
FO-6	Meltback and Regrowth of HgZnTe	All equipment listed below
FO-6a	Meltback and Regrowth of HgZnTe	All equipment listed below
FO-7	Growth of CdTe by Dir. Solidification	All equipment listed below
FO-8	Growth of GaAs by Dir. Solidification	All equipment listed below Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit Furnace Module-1

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 13 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-9 Step 1	Verify Furnace in HOME Position	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit Furnace Module-1
FO-9 Step 2	Furnace-Specific Tests	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Video Processor Unit Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit Furnace Module-1
FO-9 Step 3	Furnace-Specific Tests	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 14 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-9 Step 3 (Cont.)	Furnace-Specific Tests	RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit Furnace Module-1
FO-10 Step 1	Distributed Equipment Shutdown	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers
FO-10 Step 2	Verify Experiment Shutdown	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 15 of 17)

FUNCTIONAL OBJECTIVE NUMBER	TITLE	EQUIPMENT REQUIRED ITEM
FO-10 Step 3	Shut Down GDS Subsystems	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers
FO-10 Step 4	DMS Nonessentials Shutdown	Core Control Unit Core Monitor Control Unit RPCM Essentials Power Supply Voltage and Current Sensors Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers
FO-10 Step 5	TCS Shutdown	Core Control Unit Core Monitor Control Unit Essentials Power Supply Voltage and Current Sensors
FO-10 Step 6	CCU Shutdown	

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 16 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-11 Step 1	Activate Calibration/Bakeout	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit Furnace Module-1
FO-11 Step 2	Initiate Calibration Process	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit Furnace Module-1
FO-11 Step 3	Bakeout Process	Core Control Unit Removable Hard Drive CDROM/WORM Drive High-Density Recorder Core Monitor Control Unit Crew Interface CPCS RPCM

TABLE 1.1-1. SSFF FUNCTIONAL OBJECTIVES (Sheet 17 of 17)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-11 Step 3 (Cont.)	Bakeout Process	Essentials Power Supply Voltage and Current Sensors Shutoff Valves Pump Package Flow Meters Flow Control Valves Temperature Sensors Pressure Transducers Distributed Core Monitoring Unit Furnace Control Unit Furnace Actuator Unit Furnace Module-1

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 1 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>0</u>						
FO NAME: <u>Payload Activation</u>	PREREQUISITE: _____						
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____						
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____						
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	5:00	5:00	1:00			
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		0.00	0.00	0.00			
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Open TCS manual valves						
2	Open GDS manual valves						
3	Verify Station services activated at rack						

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 2 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>1</u>						
FO NAME: <u>Core Activation</u>	PREREQUISITE: <u>FO-0</u>						
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____						
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____						
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	5:00	2:00	1:00	4:00	3:00	7:00
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		1.008	1.008	1.008	1.1479	1.4637	1.2926
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Activate CCU and CMCU						
2	SSF to ground initial link						
3	Test CMCU						
4	Configure and test TCS in Core						
5	Test CPC						
6	GDS tests in Core						

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 3 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>			FO NUMBER: <u>1</u>		
FO NAME: <u>Core Activation</u>			PREREQUISITE: <u>FO-0</u>		
NO. OF PERFORMANCES: <u>MIN.</u> _____ <u>DES.</u> _____			SEQUENCE: _____		
REQUIRED TIMEFRAME (MET): <u>MIN.</u> _____ <u>MAX.</u> _____			JOINT OPS WITH: _____		
STEP NUMBER		7	8		
STEP DURATION (MINS:SECS)	MINIMUM				
	MAXIMUM				
	PREFERRED	3:00	5:00		
STEP DELAY (HRS:MINS)	MINIMUM				
	MAXIMUM				
	PREFERRED				
CREW	NUMBER				
	PREFERRED				
MICROGRAVITY (g's)					
VACUUM VENT					
CONSUMABLES					
AVERAGE POWER REQUIRED (kW)		1.1479	1.1479		
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS				
	EXPERIMENT APPLICATIONS				
DATA	DLINK DIGITAL (MBPS)				
	REAL-TIME (RT) OR DUMP (D)				
	COMMANDING				
	PES (P), ISE (I), MPAC (M), POIC (PC)				
	VIDEO				
	STANDARD/NONSTANDARD NTSC				
REAL-TIME/DUMP/STORE					
SPECIAL EQUIPMENT OR CONSTRAINTS					
STEP NO.		STEP DESCRIPTION			
7		Activate camera and test videolink and high rate link (not used during MTC)			
8		Core readiness check			

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 4 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>2</u>						
FO NAME: <u>Distributed Equipment</u>	PREREQUISITE: <u>FO-1</u>						
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____						
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____						
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	1:00	2:00	2:00	2:00	2:00	5:00
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		1.3220	1.7620	1.7620	2.0988	2.0988	2.1136
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	CCU activates RPCM						
2	CCU activates FCU						
3	FCU checkout						
4	FAU activation						
5	FAU checkout						
6	CCU configuration of TCS						

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 5 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>		FO NUMBER: <u>2</u>					
FO NAME: <u>Distributed Equipment</u>		PREREQUISITE: <u>FO-1</u>					
NO. OF PERFORMANCES: MIN. _____ DES. _____		SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____		JOINT OPS WITH: _____					
STEP NUMBER		7	8				
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	:17	12:00				
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		2.1835	2.1336				
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
<u>STEP NO.</u>		<u>STEP DESCRIPTION</u>					
7		Checkout GDS components					
8		Furnace specific tests					

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 6 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>3</u>					
FO NAME: <u>Manual Sample Exchange</u>	PREREQUISITE: <u>FO-2</u>					
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____					
STEP NUMBER	1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM					
	MAXIMUM					
	PREFERRED	1:00	32:00	10:00	10:00	7:00
STEP DELAY (HRS:MINS)	MINIMUM					
	MAXIMUM					
	PREFERRED					
CREW	NUMBER					
	PREFERRED	1		1	1	1
MICROGRAVITY (g's)						
VACUUM VENT						
CONSUMABLES						
AVERAGE POWER REQUIRED (kW)	2.1336	2.1487	2.1336	2.1336	2.1336	2.1336
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS					
	EXPERIMENT APPLICATIONS					
DATA	DLINK DIGITAL (MBPS)					
	REAL-TIME (RT) OR DUMP (D)					
	COMMANDING					
	PES (P), ISE (I), MPAC (M), POIC (PC)					
	VIDEO STANDARD/NONSTANDARD NTSC					
	REAL-TIME/DUMP/STORE					
SPECIAL EQUIPMENT OR CONSTRAINTS						
STEP NO.	STEP DESCRIPTION					
1	Command "Manual Sample Exchange" on					
2	Vent/fill furnace module					
3	Equalize furnace module pressure					
4	Prep equipment					
5	Open SIP					
6	Insert samples					

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 7 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>			FO NUMBER: <u>3</u>			
FO NAME: <u>Manual Sample Exchange</u>			PREREQUISITE: <u>FO-2</u>			
NO. OF PERFORMANCES: MIN. _____ DES. _____			SEQUENCE: _____			
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____			JOINT OPS WITH: _____			
STEP NUMBER		7	8	9	10	11
STEP DURATION (MINS:SECS)	MINIMUM					
	MAXIMUM					
	PREFERRED	3:00	3:00	1:00	65:00	4:00
STEP DELAY (HRS:mins)	MINIMUM					
	MAXIMUM					
	PREFERRED					
CREW	NUMBER					
	PREFERRED	1	1	1	1	1
MICROGRAVITY (g's)						
VACUUM VENT						
CONSUMABLES						
AVERAGE POWER REQUIRED (kW)		2.1336	2.1336	2.1336	2.1338	2.1336
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS					
	EXPERIMENT APPLICATIONS					
DATA	DOWLINK DIGITAL (MBPS)					
	REAL-TIME (RT) OR DUMP (D)					
	COMMANDING					
	PES (P), ISE (I), MPAC (M), POIC (PC)					
	VIDEO STANDARD/NONSTANDARD NTSC					
	REAL-TIME/DUMP/STORE					
SPECIAL EQUIPMENT OR CONSTRAINTS						
STEP NO.		STEP DESCRIPTION				
7	Close SIP					
8	Open valves					
9	Command "Manual Sample Exchange" off					
10	Perform seal check					
11	Load list process					

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 8 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>4</u>						
FO NAME: <u>Purge Furnace Module</u>	PREREQUISITE: <u>FO-3</u>						
NO. OF PERFORMANCES: MIN. <u> </u> D&S. <u> </u>	SEQUENCE: <u> </u>						
REQUIRED TIMEFRAME (MET): MIN. <u> </u> MAX. <u> </u>	JOINT OPS WITH: <u> </u>						
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	32:00	10:00	2:00	2:00		
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		2.1487	2.1487	2.1336	2.1639		
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	GN2 purge furnace						
2	Argon backfill						
3	Command sample process						
4	TCS configured						

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 9 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>5</u>					
FO NAME: <u>Vapor Crystal Growth of HgCdTe</u>	PREREQUISITE: <u>FO-3</u>					
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____					
STEP NUMBER	1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM			.		
	MAXIMUM			.		
	PREFERRED	3:00	188:00	60:00	480:00	240:00
STEP DELAY (HRS:MINS)	MINIMUM			.		
	MAXIMUM			.		
	PREFERRED					
CREW	NUMBER			.		
	PREFERRED			.		
MICROGRAVITY (g's)						
VACUUM VENT						
CONSUMABLES						
AVERAGE POWER REQUIRED (kW)	2.2536	3.2496	2.5996	2.5996	2.2536	2.536
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS					
	EXPERIMENT APPLICATIONS					
DATA	DOWLINK DIGITAL (MBPS)					
	REAL-TIME (RT) OR DUMP (D)					
	COMMANDING					
	PES (P), ISE (I), MPAC (M), POIC (PC)					
	VIDEO STANDARD/NONSTANDARD NTSC					
	REAL-TIME/DUMP/STORE					
SPECIAL EQUIPMENT OR CONSTRAINTS						
STEP NO.	STEP DESCRIPTION					
1	Activate furnace for processing					
2	Activate and process heat cycle					
3	Anneal sample					
4	Initiate vapor crystal growth processing					
5	Cool sample and extract					
6	Cool and stow					

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 10 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>6</u>						
FO NAME: <u>Meltback and Regrowth of HgZnTe</u>	PREREQUISITE: <u>FO-3</u>						
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____						
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____						
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	3:00	340:00	120:00	125:00	600:00	7390:00
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		2.2536	2.7316	2.6496	2.6496	2.6496	2.6496
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DOWNLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Activate furnace for processing						
2	Process heat cycle						
3	Initial soak						
4	Translation to growth position						
5	Final soak						
6	Directional solidification						

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 11 of 19)

EXPERIMENT NAME: Space Station Furnace Facility		FO NUMBER: 6					
FO NAME: Meltback & Regrowth of HgZnTe		PREREQUISITE: FO-3					
NO. OF PERFORMANCES: MIN. _____ DES. _____		SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____		JOINT OPS WITH: _____					
STEP NUMBER		7	8				
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	372:00	115:00				
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		2.3246	2.1946				
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO						
	STANDARD/NONSTANDARD NTSC						
REAL-TIME/DUMP/STORE							
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.		STEP DESCRIPTION					
7 Cool sample							
8 Stow sample							

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 12 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>6A</u>						
FO NAME: <u>Meltback and Regrowth of HgZnTe (Extended)</u>	PREREQUISITE: <u>FO-3</u>						
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____						
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____						
STEP NUMBER	1	2	3	4	5	6	
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	3:00	340:00	120:00	125:00	600:00	59957:00
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)	2.2536	2.7316	2.6496	2.6496	2.6496	2.6496	
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Activate furnace for processing						
2	Process heat cycle						
3	Initial soak						
4	Translation to growth position						
5	Final soak						
6	Directional solidification						

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 13 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>		FO NUMBER: <u>6A</u>					
FO NAME: <u>Meltback and Regrowth of HgZnTe (Extended)</u>		PREREQUISITE: <u>FO-3</u>					
NO. OF PERFORMANCES: MIN. _____ DES. _____		SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. ____ MAX. _____		JOINT OPS WITH: _____					
STEP NUMBER		7	8				
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	372:00	115:00				
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		2.3246	2.1946				
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
<u>STEP NO.</u>		<u>STEP DESCRIPTION</u>					
7	Cool sample						
8	Internally stow sample						

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 14 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>7</u>						
FO NAME: <u>Growth of CdTe by Directional Solidification</u>	PREREQUISITE: <u>FO-3</u>						
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____						
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____						
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	3:00	538:00	120:00	4278:00	438:00	208:00
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		2.2536	3.4786	3.3746	3.2996	2.7244	2.3746
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Activate furnace module for processing						
2	Process heat cycle						
3	Soak						
4	Process sample, directional solidification						
5	Cool sample to 400 °C						
6	Cool sample to 200 °C and internally stow sample						

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 15 of 19)

EXPERIMENT NAME: Space Station Furnace Facility			FO NUMBER: 8					
FO NAME: Growth of GaAs by Directional Solidification			PREREQUISITE: FO-3					
NO. OF PERFORMANCES: MIN. _____ DES. _____			SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____			JOINT OPS WITH: _____					
STEP NUMBER			1	2	3	4	5	6
STEP DURATION (MINS:SECS)		MINIMUM						
		MAXIMUM						
		PREFERRED	3:00	45:00	227:00	68:00	720:00	210:00
STEP DELAY (HRS:MINS)		MINIMUM						
		MAXIMUM						
		PREFERRED						
CREW		NUMBER						
		PREFERRED						
MICROGRAVITY (g's)								
VACUUM VENT								
CONSUMABLES								
AVERAGE POWER REQUIRED (kW)			2.2536	2.9916	4.4866	3.4776	3.3926	2.8016
ONBOARD COMPUTER SUPPORT		CORE APPLICATIONS						
		EXPERIMENT APPLICATIONS						
DATA		DOWNLINK DIGITAL (MBPS)						
		REAL-TIME (RT) OR DUMP (D)						
		COMMANDING						
		PES (P), ISE (I), MPAC (M), POIC (PC)						
		VIDEO						
		STANDARD/NONSTANDARD NTSC						
REAL-TIME/DUMP/STORE								
SPECIAL EQUIPMENT OR CONSTRAINTS								
STEP NO.			STEP DESCRIPTION					
1	Activate furnace module processing							
2	Preheat cycle							
3	Process heat cycle							
4	Soak							
5	Translate furnace/process sample							
6	Cool down to 800 °C							

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 16 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>8</u>						
FO NAME: <u>Growth of GaAs by Directional Solidification</u>	PREREQUISITE: <u>FO-3</u>						
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____						
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____						
STEP NUMBER		7					
STEP DURATION (MINS:SECS)		MINIMUM					
		MAXIMUM					
		PREFERRED	466:00				
STEP DELAY (HRS:MINS)		MINIMUM					
		MAXIMUM					
		PREFERRED					
CREW		NUMBER					
		PREFERRED					
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		2.2536					
ONBOARD COMPUTER SUPPORT		CORE APPLICATIONS					
		EXPERIMENT APPLICATIONS					
DATA	DLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
REAL-TIME/DUMP/STORE							
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.		STEP DESCRIPTION					
7		Cool down to 200 °C and internally stow					

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 17 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>9</u>					
FO NAME: <u>Configure Furnace for Shutdown/Sample Loading</u>	PREREQUISITE: _____					
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____					
STEP NUMBER	1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM					
	MAXIMUM					
	PREFERRED	3:00	5:00	1:00		
STEP DELAY (HRS:MINS)	MINIMUM					
	MAXIMUM					
	PREFERRED					
CREW	NUMBER					
	PREFERRED					
MICROGRAVITY (g's)						
VACUUM VENT						
CONSUMABLES						
AVERAGE POWER REQUIRED (kW)	2.1336	2.1336	2.1336			
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS					
	EXPERIMENT APPLICATIONS					
DATA	DOWNLINK DIGITAL (MBPS)					
	REAL-TIME (RT) OR DUMP (D)					
	COMMANDING					
	PES (P), ISE (I), MPAC (M), POIC (PC)					
	VIDEO STANDARD/NONSTANDARD NTSC					
	REAL-TIME/DUMP/STORE					
SPECIAL EQUIPMENT OR CONSTRAINTS						
STEP NO.	STEP DESCRIPTION					
1	Verify furnace is in home position					
2	Furnace specific tests					
3	CCU secures power from furnace module					

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 18 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>		FO NUMBER: <u>10</u>					
FO NAME: <u>SSFF Shutdown</u>		PREREQUISITE: <u>FO-9</u>					
NO. OF PERFORMANCES: MIN. _____ DES. _____		SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____		JOINT OPS WITH: _____					
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	3:00	3:00	5:00	1:00	1:00	1:00
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		1.1479	1.1479	1.1479	0.5612	0.3102	0.00
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DOWNLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Distributed Core Eq. shutdown						
2	Verify experiment/furnace shutdown						
3	GDS shutdown						
4	DMS nonessential shutdown						
5	TCS shutdown						
6	CCU shutdown						

TABLE 1.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 19 of 19)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>			FO NUMBER: <u>11</u>				
FO NAME: <u>Furnace Calibration/Bakeout</u>			PREREQUISITE: <u>FO-3</u>				
NO. OF PERFORMANCES: MIN. _____ DES. _____			SEQUENCE: _____				
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____			JOINT OPS WITH: _____				
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	1:00	TBD	480:00			
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		2.1336	TBD	TBD			
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DLINK DIGITAL (MBPS)						
	REAL-TIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POIC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Activate calibration/bakeout						
2	Initiate calibration						
3	Bakeout/calibration process						




FIGURE 1.1-2. DMS COMPONENT TREE




FIGURE 1.1-3. PCDS COMPONENT TREE




FIGURE 1.1-4. TCS COMPONENT TREE




FIGURE 1.1-5. GDS COMPONENT TREE




FIGURE 1.1-6. FURNACE MODULE-1 EQUIPMENT PICTORIAL REPRESENTATION

TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 1 of 19)

FO: <u>0</u>	FO TITLE: <u>PAYOUT ACTIVATION AND CHECKOUT</u>	CENTRALIZED SS FUNCTIONS	DISTRIBUTED SS FUNCTIONS	FURNACE MODULE
GND/PES/CRW FUNCTION				
<pre> graph TD S1[STEP 1 OPEN TCS MANUAL VALVE CRW] --> S2[STEP 2 OPEN GDS MANUAL VALVE CRW] S2 --> S3[STEP 3 VERIFY SSF SERVICES AT RACK CRW] S3 --> E[END OF FO-0 PROCEED TO FO-1] </pre>				




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 2 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 3 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 4 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 5 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 6 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 7 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 8 of 19)

FO: <u>3</u>	FO TITLE: <u>FURNACE SAMPLE EXCHANGE AND VERIFICATION</u>	CENTRALIZED SS FUNCTIONS	DISTRIBUTED SS FUNCTIONS	FURNACE MODULE
GND/PES/CRW FUNCTION				
<pre> graph TD C((C)) --> S8[STEP 8 OPEN MANUAL VALVES CRW] S8 --> S9[STEP 9 COMMAND MANUAL EXCHANGE OFF CRW] S9 --> S10[STEP 10 PERFORM SEAL CHECK CRW] S10 --> S11[STEP 11 LOAD LIST PROCESS PES] S11 --> E[END OF FO-3 PROCEED TO FO-4] </pre>				

TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 9 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 10 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 11 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 12 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 13 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 14 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 15 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 16 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 17 of 19)




TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 18 of 19)





TABLE 1.1-3. SSFF OPERATIONAL FUNCTIONAL FLOW (Sheet 19 of 19)



1.2. STRUCTURAL/MECHANICAL

The Integrated Configuration-1 (IC1) Space Station Furnace Facility (SSFF) will be mounted in the U. S. Laboratory (USL) Module-A. The SSFF Core Rack will be mounted in a double rack location, and Experiment Rack-1 will be mounted in an adjacent double rack location. Figure 1.2-1 shows the SSFF system interface with Space Station Freedom (SSF). The physical and functional interfaces defined herein between SSFF and the USL are as follows:

- SSF-to-SSFF Mechanical Structures Subsystem (MSS) Physical Interfaces:
 - SSFF Core Rack to USL Module-A
 - SSFF Experiment Rack-1 to USL Module-A
 - SSFF Interconnect Tray Assembly to USL Module-A
- SSF-to-SSFF Core Rack Services Functional Interfaces:
 - SSF Electrical Power System (EPS) to SSFF Core Rack
 - SSF Data Management Subsystem (DMS) to SSFF Core Rack
 - SSF Thermal Control Subsystem (TCS) to SSFF Core Rack
 - SSF Vacuum Exhaust System (VES) to SSFF Core Rack
 - SSF Liquid Nitrogen System (LNS) to SSFF Core Rack
 - SSF avionics air to SSFF Core Rack
 - SSF fire detection and suppression to SSFF Core Rack
- SSF-to-SSFF Experiment Rack-1 Services Functional Interfaces:
 - SSF avionics air to SSFF Experiment Rack-1
 - SSF fire detection and suppression to SSFF Experiment Rack-1
- Crew Interface

1.2.1 EQUIPMENT LIST AND MASS PROPERTIES

Mass properties of the SSFF are shown in Table 1.2-1. Stowage items and their properties are shown in Table 1.2-2.

1.2.2 INTERFACE DETAIL

1.2.2.1 SSF-to-SSFF MSS Interface

The SSFF MSS will interface with SSF by physical connections of the Core Rack, Experiment Rack-1, and the MSS Interconnect Tray Assembly. The Core Rack and Experiment Rack-1 are rack replacement structures modified from an International Standard Payload Rack (ISPR), and they attach to the USL at the ISPR pivot points and attach fitting locations. Figure 1.2-2 shows the Core Rack interface with SSF, and Figure 1.2-3 shows the Experiment Rack-1 interface with SSF. Figure 1.2-4 shows the Interconnect Tray Assembly, which provides support for the cabling and plumbing between the Core Rack and Experiment Rack-1. The Interconnect Tray Assembly attaches to the USL in the standoff.




FIGURE 1.2-1. SSFF TO SSF RESOURCE INTERFACES

TABLE 1.2-1. LIST OF EQUIPMENT PROPERTIES (Sheet 1 of 5)

Equipment Nomenclature	Mass (kg)	Mass Maturity (%)	Mounting Preferred	Center of Gravity Station (cm)			Moment of Inertia (kg-m ²)			Product of Inertial (kg-m ²)		
				X	Y	Z	I _x	I _y	I _z	I _{xy}	I _{xz}	I _{yz}
GAS DISTRIBUTION SUBSYSTEM:												
Centralized Equipment:												
Argon+bottle (1)	17.5	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Latching Sol. Valves (4)	4.0	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Manual Valves, 1/4" (4)	0.9	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Manual Valve, 1" (1)	2.4	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Regulators (2)	1.8	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Filter, 1/4" (2)	0.3	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Pressure Sensors (3)	0.5	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Pressure Gauge (1)	0.5	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Contamin. Monitor (1)	18.0	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Check Valve, 1/4" (4)	0.6	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
QD (with cap), 1/4" (4)	0.4	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
QD (with cap), 1" (2)	3.2	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Plumbing/hose/fittings	6.0	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Distributed Equipment:												
Latch. Sol Valve (6)	6.0	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Press. Relief Valves (2)	0.9	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Filter, 1" (1)	3.6	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Compressor (1)	15.0	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Storage Tank (1)	17.5	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Accumulator (1)	8.0	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Check Valves (2)	0.4	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
CM Sensor (2)	6.0	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Pressure Sensors (3)	0.5	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
QD (with cap), 1/4" (1)	0.1	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
QD (with cap), 1" (1)	1.6	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Check Valve, 1/4" (1)	0.1	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Plumbing/hose/fittings	1.0	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD

TABLE 1.2-1. LIST OF EQUIPMENT PROPERTIES (Sheet 2 of 5)

Equipment Nomenclature	Mass (kg)	Mass Maturity (%)	Mounting Preferred	Center of Gravity Station (cm)			Moment of Inertia (kg-m ²)			Product of Inertia (kg-m ²)		
				X	Y	Z	I _x	I _y	I _z	I _{xz}	I _{yz}	I _{xz}
DATA MANAGEMENT SUBSYSTEM												
Centralized Equipment:												
Core Control Unit (1)	29.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Hard Drive (1)	22.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
CDROM/WORM (1)	7.7	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
High-Density Recorder (1)	57.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Core Monitor & Control Unit (1)	20.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Crew Interface (1)	23.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
CPICS (2)	36.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Cabling (AR)	20.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Distributed Equipment:												
Furnace Control Unit (1)	43.5	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Furnace Actuator Unit (1)	29.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
DCMU (1)	20.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Cabling (AR)	6.5	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
POWER CONDITIONING AND DISTRIBUTION SUBSYSTEM												
Centralized Equipment:												
Core Power Distrib. (1)	42.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Core Pwr Conditioner (1)	47.2	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Core Junction Box-A (1)	4.5	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Core Junction Box-B (1)	4.5	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD

TABLE 1.2-1. LIST OF EQUIPMENT PROPERTIES (Sheet 3 of 5)

Equipment Nomenclature	Mass (kg)	Mass Maturity (%)	Mounting Preferred	Center of Gravity Station (cm)	Moment of Inertia (kg-m ²)	Product of Inertia (kg-m ²)					
	est.	cal.	act.	X	Y	Z	I _x	I _y	I _z	I _{xz}	I _{yz}
POWER CONDITIONING AND DISTRIBUTING SUBSYSTEM (Cont.)											
Centralized Equip. (cont.)											
Essentials Pwr Supp. (1)	3.2	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Volt./Current Sensors (4)	2.0	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Line and Connectors	11.3	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Distributed Equipment:											
Current Pulsing Equipment (1)	13.6	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Furnace Pwr. Dist. (1)	7.3	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Furnace Junction Box (1)	9.5	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Essentials Pwr Supp. (1)	4.8	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Volt./Current Sens. (66)	33.0	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Line and Connectors	3.4	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
THERMAL CONTROL SUBSYSTEM											
Centralized Equipment:											
Heat Exchanger (1)	13.6	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Pump Package (1)	15.9	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Flow Meters (2)	1.5	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Flow Control Valves (2)	3.7	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Temperature Sensors (5)	0.5	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Pressure Transducers (3)	1.5	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Custom Coldplates (4)	24.0	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
-5 Coldplates (2)	3.3	100	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD

TABLE 2-1. List of Equipment Properties (Sheet 4 of 5)

Equipment Nomenclature	Mass (kg)	Mass Maturity (%)	Mounting Preferred	Center of Gravity Station (cm)			Moment of Inertia (kg-m ²)			Product of Inertia (kg-m ²)		
	est.	cal.	act.	X	Y	Z	I _x	I _y	I _z	I _{xy}	I _{xz}	I _{yz}
THERMAL SUBSYSTEM												
Centralized Equip. (Cont.):												
Pwr Mod CP-Upper (2)	12.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Pwr Mod CP-Lower (2)	9.8	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Plumbing (25 m)	13.6	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Quick Disconnects (37)	3.7	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Check Valves (2)	0.1	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Manual Valves (2)	0.3	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Shutoff Valves (2)	3.7	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Water	10.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Distributed Equipment:												
Modified -7 CPs (3)	11.7	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Temperature Sensors (3)	0.2	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Pressure Transducer (1)	0.5	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Flow Meter (1)	0.8	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Flow Control Valve (1)	1.9	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Check Valve(1)	0.1	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Manual Valve (1)	0.2	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Shutoff Valve (1)	1.9	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Plumbing (12 m)	6.8	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Quick Disconnects (16)	1.6	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Water	7.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD

TABLE 1.2-1. LIST OF EQUIPMENT PROPERTIES (Sheet 5 of 5)

Equipment Nomenclature	Mass (kg)	Mass Maturity (%)	Mounting Preferred	Center of Gravity Station (cm)			Moment of Inertia (kg-m ²)			Product of Inertia (kg-m ²)		
				X	Y	Z	I _x	I _y	I _z	I _{xy}	I _{xz}	I _{yz}
MECHANICAL STRUCTURES SUBSYSTEM:												
Interconnect Tray	72.7	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Centralized Equipment:												
TCS	22.9	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
PCDS	31.8	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
GDS	21.7	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
DMS	56.2	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Distributed Equipment:												
Exp. Rack-1 MSS	28.4	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Rack Replacement Structures:												
Core Rack Experiment Rack-1	92.3 128.7	100 100	0 0	0 0	TBD TBD	TBD TBD	TBD TBD	TBD TBD	TBD TBD	TBD TBD	TBD TBD	TBD TBD
Furnaces:												
Furnace Module-1	327.0	100	0	0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD

TABLE 1.2-2. STOWAGE LIST

Item	Number Required	Mass Each (kg)	Dimensions (cm) LxWxH or LxDia	Stowage Responsibility		Stowage Phase			Special Requirements		
				Ex	PL	L	O	R			
TBD											




FIGURE 1.2-2. SSF TO SSFF CORE RACK PHYSICAL INTERFACE




FIGURE 1.2-3. SSF TO SSFF EXPERIMENT RACK-1 PHYSICAL INTERFACE




FIGURE 1.2-4. SSFF INTERCONNECT TRAY ASSEMBLY

1.2.2.2 SSF-to-SSFF Core Rack Interface

The SSFF will interface with SSF services in the standoff through an ISPR passthrough rack panel in the Core Rack. Figure 1.2-5 shows this Core Rack panel layout. SSFF subsystems receive the SSF services at the Core Rack, and then those services are routed out to Experiment Rack-1. All SSF services are provided at the Core Rack except avionics air and fire detection and suppression, which are provided at each rack location. Subsystem interfaces with SSF are described below.

1.2.2.2.1 SSF EPS-to-SSFF Core Rack - The SSFF Power Conditioning and Distribution Subsystem (PCDS) will interface with the SSF EPS by connecting to two 6-kW, 120-Vdc power buses in the Core Rack.

1.2.2.2.2 SSF DMS-to-SSFF Core Rack - The SSFF DMS will interface with the SSF DMS by connecting to the MIL-STD-1553 bus or the payload fiber distributed data interface (FDDI) at the Core Rack panel. The SSFF DMS will also require a high-rate data link (HRDL) interface at the Core Rack panel to accommodate transfer of high-rate data.

1.2.2.2.3 SSF TCS-to-SSFF Core Rack - The SSFF TCS will interface with the SSF TCS by connecting to the moderate temperature cooling loop with hoses from a payload rack heat exchanger behind the Core Rack panel.

1.2.2.2.4 SSF VES-to-SSFF Core Rack - The SSFF Gas Distribution Subsystem (GDS) will interface with the SSF VES by connecting a vacuum line at the Core Rack panel.

1.2.2.2.5 SSF LNS-to-SSFF Core Rack - The SSFF GDS will interface with the SSF LNS by connecting a nitrogen line at the Core Rack panel.

1.2.2.3 SSF-to-SSFF Experiment Rack-1 Interface

The only services provided directly from SSF to Experiment Rack-1 are avionics air and fire detection and suppression. The SSF will interface with SSFF Experiment Rack-1 at the furnace interface panel as shown in Figure 1.2-6. An SSFF-provided hose assembly will connect between this panel and the standoff interface service connection. All other Experiment Rack-1 services will be provided by the SSFF Core Rack.




FIGURE 1.2-5. CORE RACK PANEL LAYOUT




FIGURE 1.2-6. EXPERIMENT RACK-1 PANEL LAYOUTS

1.2.2.4 Crew Interface

A keyboard and display interface will be provided for crew interaction at the Core Rack. This system will have a standard QWERTY-type keyboard which can accept crew input commands for operation or configuration of the SSFF subsystems as required. Experiment sample exchanges will also require crew interface at Furnace Module-1, and opening and closing of manual valves will require crew interface at both rack locations.



1.3. POINTING/STABILIZATION AND ALIGNMENT

The Space Station Furnace Facility (SSFF) is required to provide for the alignment of the axis of selected solidification modules to within 5° of the residual g-vector. An acceleration of approximately $1.8 \times 10^{-6} g_0$ is required to prevent a 100- μm particle from moving 1 diameter in 1000 sec.

The allowable acceleration level requirements are as follows for a 1-cm diameter sample:

- | | |
|---|--|
| 1. $g \leq 1.0 \times 10^{-6} g_0$ | for $0 \leq f \leq 0.020$ for periods up to 90 days |
| 2. $g \leq 1.0 \times 10^{-6} g_0 \times \frac{f}{0.020 \text{ Hz}}$ | for $f \geq 0.020$ along residual g-vector |
| 3. $g' \leq 1.6 \times 10^{-7} g_0 \times \frac{f}{0.020 \text{ Hz}}$ | for $f \geq 0.012$ along any axis perpendicular to the residual g-vector |

where,


g = Acceleration level within the experimental sample fluid (melt, solution, or vapor) and at the solidification/fluid interface.

g_0 = Acceleration at sea level on Earth.

g' = Acceleration level perpendicular to direction of solidification front or desired fluid motion.

f = Frequency of periodic accelerations in hertz.

Furnace Module-1 requires that there shall be 1-mm maximum lateral displacement between sample and furnace centerlines at any point along centerlines at any time during processing. This does not include any contribution from the sample's being not straight or out of round. It does include heater assembly and translation system contributions.



1.4. ORBITAL REQUIREMENTS AND CONSTRAINTS

TBD



1.5. ELECTRICAL REQUIREMENTS

The Space Station Furnace Facility (SSFF) Power Conditioning and Distribution Subsystem (PCDS) is composed of the equipment necessary to condition and distribute power provided by the Space Station Freedom (SSF) Electrical Power System (EPS) to SSFF subsystems. Figure 1.5-1 shows the PCDS block diagram. The SSFF PCDS will interface with the SSF by connecting to two 6-kW, 120-Vdc power buses. Since 3- and 6-kW SSF payload racks use one bus as a primary feed and the other as an essential feed, 12-kW racks are required to maintain $1\text{ M}\Omega$ of electrical isolation between the two buses at all times (SSF Electric Power Specifications and Standards, SSP 30482). No true essentials bus exists at this time, only the two main buses. This means that a 12-kW rack must tie the two buses together whenever backup essentials power will be required. The two SSFF power buses (Bus A and Bus B) will feed the PCDS via SSF-provided Remote Power Distribution Assemblies (RPDAs) or through an SSFF-designed assembly (similar in function).

The bulk of the power to be distributed by the PCDS will be consumed by the Furnace Module-1 heaters with the remainder serving as housekeeping power to the SSFF subsystems. The Integrated Configuration-1 (IC1) configuration of the SSFF will require maximum peak power from the SSF of 4.6 kW. The operational power profile defining the use of the SSF-provided power by the SSFF during each functional objective (FO) is shown in Figure 1.5-2. The power profile data given here represent power requirement estimates to cover any of the the SSFF-accommodated Furnace Module-1 needs. The power levels defined in Figure 1.5-2 are considered maximums. Time duration for peak power requirements is 72 h. The average power required is 2.7 kW. The total energy requirement is 3800 kWh.





FIGURE 1.5-1. PCDS INTERFACE BLOCK DIAGRAM

FO-1 CORE ACTIVATION



FO-2 DIST. EQP. ACT.





FIGURE 1.5-2. POWER PROFILES BY FUNCTIONAL OBJECTIVES (Sheet 1 of 6)

320REQ0007

FO-3 MSE



FO-4 VENT/PURGE





FIGURE 1.5-2. POWER PROFILES BY FUNCTIONAL OBJECTIVES (Sheet 2 of 6)

FO-5 HgCdTe



FO-6 HgZnTe





FIGURE 1.5-2. POWER PROFILES BY FUNCTIONAL OBJECTIVES (Sheet 3 of 6)

320REQ0007

F0-6A HgZnTe



F0-7 CdTe





FIGURE 1.5-2. POWER PROFILES BY FUNCTIONAL OBJECTIVES (Sheet 4 of 6)

320REQ0007

FO-8 GaAs



FO-9 SHUTDN/SAMP UNL




FIGURE 1.5-2. POWER PROFILES BY FUNCTIONAL OBJECTIVES (Sheet 5 of 6)

FO-10 SSFF SHUTDOWN




FIGURE 1.5-2. POWER PROFILES BY FUNCTIONAL OBJECTIVES (Sheet 6 of 6)

1.6. THERMAL/FLUID REQUIREMENTS

1.6.1 HEAT TRANSFER CHARACTERISTICS

The Space Station Furnace Facility (SSFF) Thermal Control System (TCS) water cooling loop will collect heat from Furnace Module-1 and the Core Rack electronics. The collected heat will then be transferred to the Space Station Freedom (SSF) TCS moderate temperature loop via the Core Rack heat exchanger. Figure 1.6-1 shows the TCS block diagram. On-orbit thermal requirements of the SSFF are shown in Table 1.6-1.

The SSFF TCS water cooling loop collects heat from the furnace modules and subsystem electronics. The collected heat is then transferred to the SSF TCS via the Core Rack heat exchanger. Total maximum heat dissipation of the Integrated Configuration-1 (IC1) configuration of SSFF to the SSF TCS is 4518 W.

Avionics air will be required to cool some SSFF subsystem equipment in both racks. Total maximum heat dissipation to avionics air is 371 W in the Core Rack and 366 W in Experiment Rack-1.

1.6.2 FLUID/VENT REQUIREMENTS

The Gas Distribution Subsystem (GDS) provides the distribution of SSF-provided gases and vacuum to Furnace Module-1. It also provides contamination monitoring of waste gases and gaseous argon to Furnace Module-1. The GDS block diagram is shown in Figure 1.6-2.

The IC1 configuration of the SSFF GDS will require 10.4 kg of SSF-provided dry nitrogen at the Core Rack per 90-day mission, supplied at 618 to 756 kPa (90 to 110 psia). This will be regulated down internally in the core to approximately 137 to 240 kPa (20 to 35 psia) for safe pressurization of the furnace enclosures. The GDS will also require the SSF-provided vacuum at the Core Rack, which furnishes the furnace modules access to the 1×10^{-3} torr vacuum line.

Gas and vacuum requirements for the IC1 configuration of SSFF are shown in Table 1.6-2.




FIGURE 1.6-1. TCS INTERFACE BLOCK DIAGRAM

TABLE 1.6-1. ON-ORBIT THERMAL REQUIREMENTS (Sheet 1 of 2)

Equipment Item and Eq No.	Cabin	Heat-Sink Type		Exp CP (SSFF)	Exp. HX	Cooling Load (W)		Standby	Peak*	Operate	Non-Operate	Min/Max Temp (°C)	Thermal Capacitance (W·h·°C)	Special Considerations (as applicable)
		Av. Air (nonducted)	Av. Air (ducted)			Operate	Peak*							
FO-1	X	X	X			134	200					TBD	TBD	
FO-2	X	X	X			1053	1327					TBD	TBD	
FO-2	X	X	X			310	391		17/43			TBD	TBD	
FO-3	X	X	X			1653	1817		18/50			TBD	TBD	
FO-3	X	X	X			323	332		17/43			TBD	TBD	
FO-4	X	X	X			1817	1817					TBD	TBD	
FO-4	X	X	X			332	347		17/43			TBD	TBD	
FO-5	X	X	X			1817	1817					TBD	TBD	
FO-5	X	X	X			232	270					TBD	TBD	
FO-5	X	X	X			317	317		17/43			TBD	TBD	
FO-6	X	X	X			1817	1817		18/50			TBD	TBD	
FO-6	X	X	X			283	285		18/50			TBD	TBD	
FO-6	X	X	X			317	317		17/43			TBD	TBD	
FO-6A	X	X	X			1817	1817		18/50			TBD	TBD	
FO-6A	X	X	X			283	285		18/50			TBD	TBD	
FO-6A	X	X	X			317	317		17/43			TBD	TBD	
FO-7	X	X	X			1817	1817		18/50			TBD	TBD	
FO-7	X	X	X			525	580		17/43			TBD	TBD	
FO-7	X	X	X			317	317		17/43			TBD	TBD	
FO-8	X	X	X			1817	1817		18/50			TBD	TBD	
FO-8	X	X	X			524	697		18/50			TBD	TBD	
FO-8	X	X	X											

TABLE 1.6-1. ON-ORBIT THERMAL REQUIREMENTS (Sheet 2 of 2)

Equipment Item and FO No.	Heat-Sink Type				Cooling Load (W)		Min/Max Temp (°C)		Thermal Capacitance (W·h·°C)		Special Considerations (as applicable)
	Av. Air Cabin (nonducted)	Av. Air (ducted)	Exp. CP (SSFF)	Exp. HX	Standby	Peak*	Operate or other	Standby	Operate	Non-Operate	
FO-9	X			X	317 1817	317 1817	17/43 18/50		TBD TBD		
FO-9											
FO-10	X			X		44 465	121 1026		TBD TBD		
FO-10											
FO-11	X			X	317 2000	317 2016	17/43 18/50		TBD TBD		
FO-11											

* Each FO contains multiple steps; therefore, peak water-cooled load and peak avionics air load may not occur on the same step.




FIGURE 1.6-2. GDS INTERFACE BLOCK DIAGRAM

TABLE 1.6-2. FLUID REQUIREMENTS

Equipment Item and FO No.	Functional Requirement (Pressure, Purge, Vent Vacuum)	Gas or Liquid Parameters					Vent	When Required and Duration	Vacuum Vent Rate: torr-/l/sec	Special Considerations (as applicable)
		Type	Quantity Stored (kg)	Pressure Limits (N/m ²)	Flow-rate (kg/h)	Pressure Drop (N/m ²)				
FO-1	N/A									
FO-2	N/A									
FO-3	Purge/vent	GN ₂	1.4 (supp. by SSF)	TBD	TBD	TBD	0.133	TBD	1.2 x 10 ⁻³	
FO-4	N ₂ purge/vent	GN ₂	1.4	TBD	TBD	TBD	0.133	TBD	1.2 x 10 ⁻³	
FO-4	Ar purge/vent	Ar	1.9	TBD	TBD	TBD	0.133	TBD	1.2 x 10 ⁻³	
FO-5	N/A									
FO-6	N/A									
FO-6A	N/A									
FO-7	N/A									
FO-8	N/A									
FO-9	Vent						0.133	TBD	1.2 x 10 ⁻³	
FO-10	N/A									
FO-11	N/A									

1.7. DATA SYSTEM REQUIREMENTS

This section describes the Space Station Furnace Facility (SSFF) Data Management System (DMS) and the data system requirements of the SSFF to Space Station Freedom (SSF). The SSFF DMS contains the electronics for control and monitoring of subsystems associated with SSFF Core and Furnace Module-1 operations, including the Thermal Control Subsystem (TCS), the Power Conditioning and Distribution Subsystem (PCDS), and the Gas Distribution Subsystem (GDS). In addition to these subsystem tasks, the DMS also monitors and controls the unique functions of Furnace Module-1 including closed loop control of heater temperatures via thermocouple inputs (and other sensors), sensing and control of furnace translation (i.e., movement of the relative sample position to the hot/cold zones), and sensing and control of the Furnace Module-1 actuators and effectors. The DMS provides a communications media for the facility, stores digitized experiment data, and provides an interface to the SSF DMS. The SSFF DMS, as shown in Figure 1.7-1, consists of the Core and distributed components. Subsections 1.7.1 through 1.7.5 and Tables 1.7-1 through 1.7-5 define the DMS interface data and resource requirements of the SSFF.

1.7.1 SIGNAL INTERFACE DEFINITION

Table 1.7-1 defines the following data signals and control:

- Onboard and uplink commands to the SSFF and SSFF Furnace Module-1
- Routing of SSFF Core housekeeping data
- Routing of Furnace Module-1 housekeeping data
- Routing of Furnace Module-1 science data

1.7.2 SIGNAL INTERFACE DEFINITION EXPANSION

Table 1.7-2 is an expansion of the data from Table 1.7-1.

1.7.3 EVENT/EXCEPTION MONITORING REQUIREMENTS

Onboard event and exception monitoring requirements for SSFF and Furnace Module-1 are defined in Table 1.7-3.

1.7.4 PAYOUT OPERATIONS INTEGRATION CENTER DISPLAY REQUIREMENTS

The Payload Operations Integration Center (POIC) controls all payload operations and is equipped with consoles for data management, operations control, and mission planning. The data to provide this capability are shown in Table 1.7-4.

1.7.5 POIC LIMIT SENSING/EXCEPTION MONITORING REQUIREMENTS

Limit sensing and exception monitoring is provided to the POIC via downlink and is defined in Table 1.7-5.




FIGURE 1.7-1. DMS INTERFACE BLOCK DIAGRAM

TABLE 1.7-1. SIGNAL INTERFACE DEFINITION

RESERVED///////////////										
C S D I N SER.DAT E E C S R ///////////////										
M I E N O --- V X A A A										
D G F T . NM NW S T E C L M T										
N . R OS OO O Y N P . P E										
ENT DESCRIPTION	I U A F . R P T M C L									
NO.	L L A OS OD F E 1 0 0 E									
K	C F FS X N F									
106 FURNACE MODULE HOUSEKEEPING DATA	SI 1 3 32 N 1									
107 SSFF HOUSEKEEPING DATA	SI 1 3 32 N 1									
850 FURNACE SCIENCE DATA	SI 1 3 32 N 1									
851 FURNACE SCIENCE DATA	SI 1 3 32 N 1									
900 SSF CMDS & S/W PATCHES TO SSFF	Y SO 1 N 1									

1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 1 of 38)

TABLE 17-2 SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 2 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 3 of 38)

			C U	MN NM SI T	DATA DESCRIPTION	MON C	//////////
			I MIS	SO OS O Y		REQ A	
			I DA	G / G P START	END DATA VALUE	C R C SID E T	
		DESCRIPTION	I G	W F E	- - - - - T	E E .	
	R .		I U E	D I I	WD BT WD BT Y	V X C	D IO NO. X A
	R		I L	S X	# P	T D	P B
	.		I K	/ D	- E	N C O	? E
					T P F	-	I L
						D E	
1	ENT C N						
0	O						
1	R .						
1	R						
1	.						
1							
1261 106 Argon Fill Valve Closed Status	DI	01	I B 25 08 25 08				
1262 106 Argon Fill Valve Open Status	DI	01	I B 25 09 25 09				
1263 106 Hot Main Red Mod A RCCB Off Stat	DI	01	I B 25 10 25 10				
1264 106 Hot Main Red Mod A RCCB On Stat	DI	01	I B 25 11 25 11				
1265 106 Water Outlet Valve Normal Stat	DI	01	I B 25 12 25 12				
1266 106 Water Outlet Valve Bypass Stat	DI	01	I B 25 13 25 13				
1267 106 Water Inlet Valve Normal Status	DI	01	I B 25 14 25 14				
1268 106 Water Inlet Valve Bypass Status	DI	01	I B 25 15 25 15				
1269 106 Fail Safe Brake RCCB Off Status	DI	01	I B 26 00 26 00				
1270 106 Fail Safe Brake RCCB On Status	DI	01	I B 26 01 26 01				
1271 106 Core Hold Down Not Retracted	DI	01	I B 26 02 26 02				
1272 106 Core Hold Down Retracted	DI	01	I B 26 03 26 03				
1273 106 Core Hold Down Not Extended	DI	01	I B 26 04 26 04				
1274 106 Core Hold Down Extended	DI	01	I B 26 05 26 05				
1275 106 Core HD Motor RCCB Off Status	DI	01	I B 26 06 26 06				
1276 106 Core HD Motor RCCB On Status	DI	01	I B 26 07 26 07				
1277 106 Step Motor Clutch RCCB Off Stat	DI	01	I B 26 08 26 08				
1278 106 Step Motor Clutch RCCB On Status	DI	01	I B 26 09 26 09				
1279 106 Step Motor Drive RCCB Off Stat	DI	01	I B 26 10 26 10				
1280 106 Step Motor Drive RCCB On Stat	DI	01	I B 26 11 26 11				
1281 106 Rapid Xlation Clutch RCCB Off St	DI	01	I B 26 12 26 12				
1282 106 Rapid Xlation Clutch RCCB On St	DI	01	I B 26 13 26 13				
1283 106 Rapid Xlation Mtr RCCB Off Stat	DI	01	I B 26 14 26 14				
1284 106 Rapid Xlation Mtr RCCB On Stat	DI	01	I B 26 15 26 15				
1285 106 Furnace Position Not Home	DI	01	I B 27 00 27 00				
1286 106 Furnace Position Home	DI	01	I B 27 01 27 01				
1287 106 Furn Extreme Trvl Not Exceeded	DI	01	I B 27 02 27 02				
1288 106 Furn Extreme Trvl Exceeded	DI	01	I B 27 03 27 03				
1289 106 Ampoule Alignment Not Retracted	DI	01	I B 27 04 27 04				
1290 106 Ampoule Alignment Retracted	DI	01	I B 27 05 27 05				
1	1	1	1	1	1	1	1
0	0	3 4	4 4	4 4	5 5	5 5	1
3	6 7	9 0	3 5	7 8	1 3	5 7	5 6 7
							1 2
							5 8
							0

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 4 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 5 of 38)

320REQ0007

TABLE I-7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 6 of 38)

ENT	C N	M N	M N S I T	D A T A	D E S C R I P T I O N	M O N I C	/ / / / /
NO.	O O	M S	S O I O Y	-	-	REQ A	-
I R .	I R .	G .	P S T A R T	E N D	D A T A V A L U E	--L	C I R C S I D E T
I R .	I R .	G .	W F E	-	-	E E	D I O N O . X A
I .	I .	U E	D I	W D B T W D B T Y	V X C	T D	P B
I K	I K	L	S X *	*	P	N C O	I L
I K	I K	I / D	I	E	T P F	D E	I
029	1850 SEM	Indexing	Jog CW	Status	-	-	41 2
030	1850 Ampoule	Not Processing	-	-	02	-	41 2
031	1850 Ampoule	Processing	-	-	02	-	41 2
032	1850 Indexing Cam	Not Stowed	-	-	02	-	41 2
033	1850 Indexing Cam	Stowed	-	-	02	-	41 2
034	1850 Peltier	Connector Not Retracted	-	-	02	-	41 2
035	1850 Peltier	Connector Retracted	-	-	02	-	41 2
036	1850 Peltier	Connector Not Extended	-	-	02	-	41 2
037	1850 Peltier	Connector Extended	-	-	02	-	41 2
038	1850 Ampoule	Failure 2 Status	-	-	02	-	41 2
039	1850 Ampoule	Failure 1 Status	-	-	02	-	41 2
040	1850 Ampoule	Failure 2 Status	-	-	02	-	41 2
041	1850 Ampoule	Failure 1 Status	-	-	02	-	41 2
042	1850 Ampoule	Failure 2 Status	-	-	02	-	41 2
043	1850 Ampoule	Failure 1 Status	-	-	02	-	41 2
044	1850 Ampoule	Failure 2 Status	-	-	02	-	41 2
045	1850 Ampoule	Failure 1 Status	-	-	02	-	41 2
046	1850 PDS	Airflow 1 Status	-	-	02	-	41 2
047	1850 PCS	Airflow 1 Status	-	-	02	-	41 2
048	1850 IFEA	ABS Press 2	RCCB Off	Status	02	-	41 2
049	1850 IFEA	ABS Press 2	RCCB On	Status	02	-	41 2
050	1850 Spare	RCCB Off Stat	-	-	02	-	41 2
051	1850 Spare	RCCB On Stat	-	-	02	-	41 2
052	1850 IFEA	Coolant Flow #1	Status	-	02	-	41 2
053	1850 SCS	Airflow 1 Status	-	-	02	-	41 2
054	1850 Cartridge	Failure 2 Status	-	-	02	-	41 2
055	1850 Cartridge	Failure 1 Status	-	-	02	-	41 2
056	1850 Cartridge	Failure 2 Status	-	-	02	-	41 2
057	1850 Cartridge	Failure 1 Status	-	-	02	-	41 2
058	1850 Ampoule	Failure 2 Status	-	-	02	-	41 2
1	1	1	1	1	1	1	1
0	0	3	4	4	4	5	6
3	6	9	0	3	5	7	8
7	7	7	1	3	5	7	0

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 7 of 38)

		ICU	MNI	MIS	ST	DATA DESCRIPTION	MONIC	REQA	CRCSID	EIT
ENT C N	NO.	MIS	SO OS OY	D A	G. G	P START END DATA VALUE	---	L E E .	D IO NO.	
R .	R .	R .	R .	U E	W F E	WD BT Y	T	V X C	T D	
-	-	-	-	L	S X *	*	P	N C O ?	E	
-	-	-	-	K	/ D	*	E	T P F	D E	
059	850	Ampoule	6 Failure	1 Status		02				4 2
060	850	Ampoule	5 Failure	2 Status		02				4 2
061	850	Ampoule	5 Failure	1 Status		02				4 2
062	850	Water	Outlet	V1v RCCB Off	Status	02				4 2
063	850	Water	Outlet	V1v RCCB On	Status	02				4 2
064	850	Vacuum	Vent	V1v RCCB Off	Status	02				4 2
065	850	Vacuum	Vent	V1v RCCB On	Status	02				4 2
066	850	SEM	Index	Motor	RCCB Off	Status	02			4 2
067	850	SEM	Index	Motor	RCCB On	Status	02			4 2
068	850	Core	HD	Motor	RCCB Off	Status	02			4 2
069	850	Core	HD	Motor	RCCB On	Status	02			4 2
070	850	Hot	Boost	Mod A	RCCB Off	Status	02			4 2
071	850	Hot	Boost	Mod A	RCCB On	Status	02			4 2
072	850	Hot	Boost	Mod B	RCCB Off	Status	02			4 2
073	850	Hot	Boost	Mod B	RCCB On	Status	02			4 2
074	850	Cold	Main	Prim	Mod RCCB Off	Stat	02			4 2
075	850	Cold	Main	Prim	Mod RCCB On	Stat	02			4 2
076	850	Hot	Main	Prim	Mod A	RCCB Off	Stat			4 2
077	850	Hot	Main	Prim	Mod A	RCCB On	Stat			4 2
078	850	Carousel	Trk	Extr	Right	Lim-Not	02			4 2
079	850	Carousel	Trk	Extr	Right	Lim	02			4 2
080	850	Ampoule	Support	Not	Secure	02				4 2
081	850	Ampoule	Support	Secure		02				4 2
082	850	Carousel	Trk	Extr	Left	Lim-Not	02			4 2
083	850	Carousel	Trk	Extr	Left	Limit	02			4 2
084	850	Carousel	Spacer	Plt	Gap	Lim-Not	02			4 2
085	850	Carousel	Spacer	Plt	Gap	Limit	02			4 2
086	850	Ampoule	Spt	Plt	Mtr	RCCB Off	St			4 2
087	850	Ampoule	Spt	Plt	Mtr	RCCB On	Stac			4 2
088	850	Ampoule	Align	Mtr	RCCB Off	Stat	02			4 2
1										
0	0									
3	6									

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 8 of 38)

		C	U	MN	NM	S/T	DATA DESCRIPTION	MON	C
ENTC	NI	M	S	SO	OS	O/Y	-	REQ	A
NO.	O/O	D	G	/G	P	START	END	DATA	VALUE
R.	R.	I	G	W	F	E	-	T	E E
R.	R.	I	E	D	I	WD BT	WD BT	Y	V X C
.	.	I	L	S	X	*	*	P	N C O
		K	I	V	D	I	I	E	T P F
									D E
									41 2
089	850 Ampoule Align Mtr	RCCB	On	Stat	I	02			41 2
090	850 Water Inlet Valve	RCCB	Off	Stat	I	02			41 2
091	850 Water Inlet Valve	RCCB	On	Status	I	02			41 2
092	850 Argon Fill Valve	RCCB	Off	Status	I	02			41 2
093	850 Argon Fill Valve	RCCB	On	Status	I	02			41 2
094	850 System Bus Relay Off	Status			I	02			41 2
095	850 System Bus Relay On	Status			I	02			41 2
096	850 IFFEA Coolant Flow #2 Status				I	02			41 2
097	850 PCS Airflow 2 Status				I	02			41 2
098	850 Cartridge 6 Failure 2	Status			I	02			41 2
099	850 Cartridge 6 Failure 1	Status			I	02			41 2
100	850 Cartridge 5 Failure 2	Status			I	02			41 2
101	850 Cartridge 5 Failure 1	Status			I	02			41 2
102	850 Cartridge 4 Failure 2	Status			I	02			41 2
103	850 Cartridge 4 Failure 1	Status			I	02			41 2
104	850 Cartridge 3 Failure 2	Status			I	02			41 2
105	850 Cartridge 3 Failure 1	Status			I	02			41 2
106	850 PCS Utility RCCB Off Status				I	02			41 2
107	850 PCS Utility RCCB On Status				I	02			41 2
108	£50 Step Motor Drive	RCCB	Off	Status	I	02			41 2
109	850 Step Motor Drive	RCCB	On	Status	I	02			41 2
110	850 IFFEA ABS Press 1	RCCB	Off	Status	I	02			41 2
111	850 IFFEA ABS Press 1	RCCB	On	Status	I	02			41 2
112	850 Peltier Conn Motor	RCCB	Off	Status	I	02			41 2
113	850 Peltier Conn Motor	RCCB	On	Status	I	02			41 2
114	850 Step Motor Clutch	RCCB	Off	Status	I	02			41 2
115	850 Step Motor Clutch	RCCB	On	Status	I	02			41 2
116	850 Rapid Xlation Clutch	RCCB	Off	Status	I	02			41 2
117	850 Rapid Xlation Clutch	RCCB	On	Status	I	02			41 2
118	850 Rapid Xlation Mtr	RCCB	Off	Status	I	02			41 2

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 9 of 38)

320REQ0007

TABLE I-7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 10 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 11 of 38)

		ICU	MN	NMISIT	DATA DESCRIPTION	MONIC	//////////
ENT(C N)	NO. IO O	MIS	ISO	IO(Y)	REQA	REQA	-
R .	R .	DIA	G.	P START	END DATA VALUE	-- L	CRC SID E T
.	.	G	W F E	----- ----- T	E E .	D IO NO.	X A
R	R	UE	D I	WD BT WD BT Y	V X C	T D	P B
L	L	S X *	*	P	N C O	? E	I L
K	K	/ D	E	T P F		D	D E
1179 850 Last Command Received Word #25		02					
1180 850 Last Command Received Word #26		02					
1181 850 Last Command Received Word #27		02					
1182 850 Last Command Received Word #28		02					
1183 850 Last Command Received Word #29		02					
1184 850 Last Command Received Word #30		02					
1185 850 Last Command Received Word #31		02					
1186 850 Invalid Command Flag		02					
1187 850 User Requested Data		02					
1188 850 ECS Next Timeline Record		02					
1189 850 FTS Next Timeline Record		02					
1190 850 FHS Cold Guard Next Timeline Rec		02					
1191 850 FHS Cold Zone Next Timeline Rec		02					
1192 850 FHS Booster Next Timeline Rec		02					
1193 850 FHS Hot Zone Next Timeline Rec		02					
1194 850 FHS Hot Guard Next Timeline Rec		02					
1195 850 SIDS Next Timeline Record		02					
1196 850 ECS Current Segment Start Time		02					
1197 850 ECS Current Segment Stop Time		02					
1198 850 FTS Current Segment Start Time		02					
1199 850 FTS Current Segment Stop Time		02					
1200 850 FHS Cold Guard Cur Seg Start Tim		02					
1201 850 FHS Cold Guard Cur Seg Stop Time		02					
1202 850 FHS Cold Zone Cur Seg Start Tim		02					
1203 850 FHS Cold Zone Cur Seg Stop Time		02					
1204 850 FHS Booster Cur Seg Start Time		02					
1205 850 FHS Booster Cur Seg Stop Time		02					
1206 850 FHS Hot Zone Cur Seg Start Time		02					
1207 850 FHS Hot Zone Cur Seg Stop Time		02					
1208 850 FHS Hot Guard Cur Seg 'Start Time'		02					
		1	1	1	1	1	1
		0	0	3 4	4 4	5 5	6 6
		3	6	9 0	3 5	7 8	7 7

TABLE 17-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 12 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 13 of 38)

		C U	MN NM S T	DATA DESCRIPTION	MON C	//////////
ENT C N		M S	SO OS O Y		REQ A	
NO. O O		D A	G. /G	P START END DATA VALUE	--- L	C R C SID E T
R .	DESCRIPTION	G	W F E	--- T	E E .	D IO NO. X A
R		U E	D I	WD BT WD BT Y	V X C	T D P B
.		L	S X	# P	N C O	? E I L
		K	/ D	E	T P F	P D E
1239 850 Sample 3 Temp 3			02			
1240 850 Sample 3 Temp 4			02			
1241 350 Sample 3 Temp 5			02			
1242 850 Sample 3 Temp 6			02			
1243 850 Sample 4 Temp 1			02			
1244 850 Sample 4 Temp 2			02			
1245 850 Sample 4 Temp 3			02			
1246 850 Sample 4 Temp 4			02			
1247 850 Sample 4 Temp 5			02			
1248 850 Sample 4 Temp 6			02			
1249 850 Sample 5 Temp 1			02			
1250 850 Sample 5 Temp 2			02			
1251 850 Sample 5 Temp 3			02			
1252 850 Sample 5 Temp 4			02			
1253 850 Sample 5 Temp 5			02			
1254 850 Sample 5 Temp 6			02			
1255 850 Sample 6 Temp 1			02			
1256 850 Sample 6 Temp 2			02			
1257 850 Sample 6 Temp 3			02			
1258 850 Sample 6 Temp 4			02			
1259 850 Sample 6 Temp 5			02			
1260 850 Sample 6 Temp 6			02			
1261 850 Stepping Motor Phase A Current			02			
1262 850 Stepping Motor Phase A Voltage			02			
1263 850 Stepping Motor Phase B Current			02			
1264 850 Stepping Motor Phase B Voltage			02			
1265 850 Furnace Linear Position			02			
1266 850 FTS Stepping Motor Temp			02			
1267 850 Rapid Translation Motor RPM			02			
1268 850 Cold Guard Heater Current			02			
1	1	1	1	1	1	1
0	0	3 4	4 4	4 4	5 5	5 5
3	6 7	9 0	3 5	7 8	1 3	5 7
					5 6 7	1 2
						5 8
						0

TABLE 17-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 14 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 15 of 38)

ENT	C	N	MN	NM	S	T	DATA	DESCRIPTION	MON	C	
NO.	O		SO	OS	OY				REQ	A	
R	.	R	G	P	START	END	DATA	VALUE	--L	C R S D E T	
.		I	W	F E	--	--	T	E .	D O N O		
		D	I	WD BT WD BT			V X C	T D	P B		
		L	S	X *	*	*	P	N C O ?	I L		
		K	I	D			E	T P F	D E		
1299	850	Booster Heater Control Temp	2		02						
300	850	Cold Guard Heater Control Temp	1		02						
301	850	Cold Guard Heater Control Temp	2		02						
302	850	Cold Main Prim Htr Cntrl Temp	1		02						
303	850	Cold Main Prim Htr Cntrl Temp	2		02						
304	850	Cold Main Red Htr Control Temp	1		02						
305	850	Cold Main Red Htr Control Temp	2		02						
306	850	Hot Guard Heater Control Temp	1		02						
307	850	Hot Guard Heater Control Temp	2		02						
308	850	Hot Main Prim Htr Control Temp	1		02						
309	850	Hot Main Prim Htr Control Temp	2		02						
310	850	Hot Main Red Htr Control Temp	1		02						
311	850	Hot Main Red Htr Control Temp	2		02						
312	850	Indexing CAM Rotary Position			02						
313	850	Ampoule Alignment Arm Temp			02						
314	850	SEM Track Temp			02						
315	850	RTD Mux 1 Calibration - High			02						
316	850	RTD Mux 1 Calibration - Low			02						
317	850	RTD Mux 2 Calibration - High			02						
318	850	RTD Mux 2 Calibration - Low			02						
319	850	RTD Mux 3 Calibration - High			02						
320	850	RTD Mux 3 Calibration - Low			02						
321	850	RTD Mux 4 Calibration - High			02						
322	850	RTD Mux 4 Calibration - Low			02						
323	850	RTD Mux 5 Calibration - High			02						
324	850	RTD Mux 5 Calibration - Low			02						
325	850	RTD Mux 6 Calibration - High			02						
326	850	RTD Mux 6 Calibration - Low			02						
327	850	RTD Mux 7 Calibration - High			02						
328	850	RTD Mux 7 Calibration - Low			02						

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 16 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 17 of 38)

		ICU	IMN	NM	SIT	DATA DESCRIPTION	IMONC	//////////
ENT	C N	IM S	SO	OS	O Y		REQ A	-----
NO.	O O	ID A	G.	/G	P	START	END	DATA VALUE
R	-	I G	W	F	E	-	-	E E .
R	-	I U E	D	I	WD	BT	WT	V X C
.	-	I L	S	X	#	*	P	T D ?
-	-	K	I	/	D	-	E	N C O I L P F
-	-	-	-	-	-	-	-	D E
1359	850	Unused						
1360	850	Cold Guard Zone Setpoint Temp	02					
1361	850	Cold Main Zone Setpoint Temp	02					
1362	850	Booster Zone Setpoint Temp	02					
1363	850	Hot Main Zone Setpoint Temp	02					
1364	850	Hot Guard Zone Setpoint Temp	02					
1365	850	Cold Guard Htr Calc Temp 1	02					
1366	850	Cold Guard Htr Calc Temp 2	02					
1367	850	Unused	02					
1368	850	Unused	02					
1369	850	Cold Main Prim Htr Calc Temp 1	02					
1370	850	Cold Main Prim Htr Calc Temp 2	02					
1371	850	Cold Main Red Htr Calc Temp 1	02					
1372	850	Cold Main Red Htr Calc Temp 2	02					
1373	850	Booster Htr Calc Temp 1	02					
1374	850	Booster Htr Calc Temp 2	02					
1375	850	Unused	02					
1376	850	Unused	02					
1377	850	Hot Main Prim Htr Calc Temp 1	02					
1378	850	Hot Main Prim Htr Calc Temp 2	02					
1379	850	Hot Main Red Htr Calc Temp 1	02					
1380	850	Hot Main Red Htr Calc Temp 2	02					
1381	850	Hot Guard Htr Calc Temp 1	02					
1382	850	Hot Guard Htr Calc Temp 2	02					
1383	850	Unused	02					
1384	850	Unused	02					
1385	850	Cold Guard Zone Act Temp	02					
1386	850	Cold Main Zone Act Temp	02					
1387	850	Booster Zone Act Temp	02					
1388	850	Hot Main Zone Act Temp	02					
			1	1	1	1	1	1
			3	4	4	4	5	5
0	0		9	3	5	7	8	6
3	6		0	0	0	0	0	0

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 18 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 19 of 38)

ENT	C	N	I	C	I	U	MN	NM	S	T	DATA DESCRIPTION	(MONIC)		
NO.	O	O	I	M	S	SO	OS	O	Y	-	-REQ'A	-		
R	.	R	R	D	A	G	/G	P	START	END	DATA VALUE	-- L	C R S D E T	
.	.	.	.	U	E	D	I	W	F E	-- T	E E .	D IO NO.	X A	
.	.	.	.	L	X	S	X	I	WD BT WD BT Y	V X C	T D	P B	I L	
.	.	.	.	K	D	/	D	E	P	N C O	? E	I L	D IE	
.	.	.	.						T P F					
419	850	Booster Htr Calc Voltage							02				41 2	
420	850	Unused							02				41 2	
421	850	Hot Main Prim Htr Calc Voltage							02				41 2	
422	850	Hot Main Red Htr Calc Voltage							02				41 2	
423	850	Hot Guard Htr Calc Voltage							02				41 2	
424	850	Unused							02				41 2	
425	850	Cold Guard Htr Act Current							02				41 2	
426	850	Unused							02				41 2	
427	850	Cold Main Prim Htr Act Current							02				41 2	
428	850	Cold Main Red Htr Act Current							02				41 2	
429	850	Booster Htr Act Current							02				41 2	
430	850	Unused							02				41 2	
431	850	Hot Main Prim Htr Act Current							02				41 2	
432	850	Hot Main Red Htr Act Current							02				41 2	
433	850	Guard Htr Act Current							02				41 2	
434	850	Unused							02				41 2	
435	850	Cold Guard Htr Calc Resistance							02				41 2	
436	850	Unused							02				41 2	
437	850	ColdMain Prim Htr Calc Resistance							02				41 2	
438	850	ColdMain Red Htr Calc Resistance							02				41 2	
439	850	Booster Htr Resistance							02				41 2	
440	850	Unused							02				41 2	
441	850	HOTMain Prim Htr Calc Resistance							02				41 2	
442	850	Hot Main Red Htr Calc Resistance							02				41 2	
443	850	Guard Htr Calc Resistance							02				41 2	
444	850	Unused							02				41 2	
445	850	Cold Guard Htr Limited Power							02				41 2	
446	850	Unused							02				41 2	
447	850	Cold Main Prim Htr Limited Power							02				41 2	
448	850	Cold Main Red Htr Limited Power							02				41 2	

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 20 of 38)

ENT	C	N	I	CIU	MN	NM	SIT	DATA	DESCRIPTION	MON	C		
NO.	O	O	R	MIS	SO	OS	OY			REQ	A		
			R	DIA	G	I	/G	P	START	END	DATA	VALUE	
			R	I	G	W	I	E			E	E	T
			.	UIE	I	D	I	WD	BT	BT	Y		CIRCUITID
			L	I	S	X	#	#	P		V	X	DIODENO.
			K	I	I	D	I	E		E	N	C	O
											T	T	D
											?	E	I
											P	B	L
											ID	E	F
449	850	Booster Htr Limited Power				02							
450	850	Unused				02							41 2
451	850	Hot Main Prim Htr Limited Power				02							41 2
452	850	Hot Main Red Htr Limited Power				02							41 2
453	850	Hot Guard Htr Limited Power				02							41 2
454	850	Unused				02							41 2
455	850	Cold Guard Htr Des Current				02							41 2
456	850	Unused				02							41 2
457	850	Cold Main Prim Htr Des Current				02							41 2
458	850	Cold Main Red Htr Des Current				02							41 2
459	850	Booster Htr Des Current				02							41 2
460	850	Unused				02							41 2
461	850	Hot Main Prim Htr Des Current				02							41 2
462	850	Hot Main Red Htr Des Current				02							41 2
463	850	Hot Guard Htr Des Current				02							41 2
464	850	Unused				02							41 2
465	850	Cold Guard Zone Saturation Flag				02							41 2
466	850	Cold Main Zone Saturation Flag				02							41 2
467	850	Booster Zone Saturation Flag				02							41 2
468	850	Hot Main Zone Saturation Flag				02							41 2
469	850	Hot Guard Zone Saturation Flag				02							41 2
470	850	Integral Power Fault Time				02							41 2
471	850	Fault Sum Delta Power				02							41 2
472	850	Integral Gain				02							41 2
473	850	Fault Proportional Gain				02							41 2
474	850	Fault Intermediate Calc. Value 1				02							41 2
475	850	Fault Intermediate Calc. Value 2				02							41 2
476	850	Delta Power - Previous				02							41 2
477	850	Delta Power - 2nd Previous				02							41 2
478	850	Faulted Zone				02							41 2

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 21 of 38)

		CIU	MN MS SI	DATA DESCRIPTION	MONIC	
ENT C N		M S	SO OS OY	REQ A	---	---
NO. O O	DESCRIPTION	D A	G /G P START END DATA VALUE	C RCSID E T	D IO NO.	X A
IR .		I G	W F E --- --- --- T	E E .	T D	P B
IR .		I U E	D I WD BT WD BT Y	V X C	? E	I L
I .		I L	S X I *	P	N C O	D E
I .		I K	/ D	E	T P F	
479 850 Integral Gain Array 1			02			
480 850 Integral Gain Array 2			02			
481 850 Integral Gain Array 3			02			
482 850 Integral Gain Array 4			02			
483 850 Integral Gain Array 5			02			
484 850 Proportional Gain Array 1			02			
485 850 Proportional Gain Array 2			02			
486 850 Proportional Gain Array 3			02			
487 850 Proportional Gain Array 4			02			
488 850 Proportional Gain Array 5			02			
489 850 FF Ampoule Align Not Extended			02			
490 850 FF Ampoule Align Extended			02			
491 850 FF Ampoule Align Mtr RCCB Off			02			
492 850 FF Ampoule Align Mtr RCCB On			02			
493 850 FF Car Trk Extr Right Lim-Not			02			
494 850 FF Car Trk Extr Right Lim			02			
495 850 FF Car Trk Extr Left Limit-Not			02			
496 850 FF Car Trk Extr Left Limit			02			
497 850 FF Car Spacer Plt Gap Lim-Not			02			
498 850 FF Car Spacer Plt Gap Lim			02			
499 850 FF Indexing Cam Not Stowed			02			
500 850 FF Indexing Cam Stowed			02			
501 850 FF Ampoule Not Processing			02			
502 850 FF Ampoule Processing			02			
503 850 FF SEM Index Motor RCCB On Stat			02			
504 850 FF SEM Index Motor RCCB Off Stat			02			
505 850 FF Fail Safe Brake RCCB Off			02			
506 850 FF Fail Safe Brake RCCB On			02			
507 850 FF Core Hold Down Not Retracted			02			
508 850 FF Core Hold Down Retracted			02			
1	1		1	1	1	1
0	0	3 4	4 4	4 4	5 5	5 5
3	6	9 0	3 5	7 8	1 3	5 7
					5 6	7 2
					5 8	0 0

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 22 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 23 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 24 of 38)

		CIU	MN	NM	S/T	DATA DESCRIPTION	MONIC	//////////
ENT	C N	M/S	SO/OS	O/Y			REQ/A	
NO.	O O	D/A	G. /G	IP	START	END	DATA VALUE	L
R	.	I/G	W	F/E			E E .	C RC STD E T
R	.	U/E	D	I	WD BT	WD BT	T	D IO NO. X A
.	.	L	S	X	*	*	P V X C T D ?	P B I L E
.	.	K	I	/	D		N C O P	I L D E
.	.						T P F	41 2
1569	850 FF	Mech Pulsing Mod	RCCB	Off			02	
1570	850 FF	Mech Pulsing Mod	RCCB	On			02	
1571	850 FF	Cartridge 6	Failure	2	Status		02	
1572	850 FF	Cartridge 6	Failure	1	Status		02	
1573	850 FF	Cartridge 5	Failure	2	Status		02	
1574	850 FF	Cartridge 5	Failure	1	Status		02	
1575	850 FF	Cartridge 4	Failure	2	Status		02	
1576	850 FF	Cartridge 4	Failure	1	Status		02	
1577	850 FF	Cartridge 3	Failure	2	Status		02	
1578	850 FF	Cartridge 3	Failure	1	Status		02	
1579	850 FF	Cartridge 2	Failure	2	Status		02	
1580	850 FF	Cartridge 2	Failure	1	Status		02	
1581	850 FF	Cartridge 1	Failure	2	Status		02	
1582	850 FF	Cartridge 1	Failure	1	Status		02	
1583	850 FF	Ampoule 6	Failure	2	Status		02	
1584	850 FF	Ampoule 6	Failure	1	Status		02	
1585	850 FF	Hot Boost Mod A	RCCB	Off			02	
1586	850 FF	Hot Boost Mod A	RCCB	On			02	
1587	850 FF	Cold Main Red	Mod RCCB	Off			02	
1588	850 FF	Cold Main Red	Mod RCCB	On			02	
1589	850 FF	Cold Main Prim	Mod RCCB	Off			02	
1590	850 FF	Cold Main Prim	Mod RCCB	On			02	
1591	850 FF	Cold Guard	Mod RCCB	Off			02	
1592	850 FF	Cold Guard	Mod RCCB	On			02	
1593	850 FF	Peltier Conn	Retracted	Not			02	
1594	850 FF	Peltier Conn	Retracted				02	
1595	850 FF	Peltier Conn	Extended	Not			02	
1596	850 FF	Peltier Conn	Extended				02	
1597	850 FF	Peltier Conn	Motor RCCB	Off			02	
1598	850 FF	Peltier Conn	Motor RCCB	On			02	
1	1	1	1	1	1	1	1	1
0	0	3 4	4	4	4	5	5	6
3	6 7	9 0	3 5	7 8	1 3	5	7	7 7 8

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 25 of 38)

		C U	M N M S T	DATA DESCRIPTION	MON C	
ENT C N		M S	S O S O Y	---	REQ A	-----
NO. O O	DESCRIPTION	D A	G . /G	P START	DATA VALUE	--- L
R .		I G	W F E	---	T	E E -
R .		I U E	D I	WD BT	WD BT Y	D IO NO.
I .		L	S X *	P	V X C	X A
I .		K	D	E	N C O	P B
					? E	I L
					T P F	D E
599 850 FF Peltier Pulsing Drv RCCB Off		1 02	1 02	1 02	1 02	1 02
600 850 FF Peltier Pulsing Drv RCCB On		1 02	1 02	1 02	1 02	1 02
601 850 FF SCS Airflow 1 Status		1 02	1 02	1 02	1 02	1 02
602 850 FF PDS Airflow 1 Status		1 02	1 02	1 02	1 02	1 02
603 850 FF PCS Airflow 2 Status		1 02	1 02	1 02	1 02	1 02
604 850 FF PCS Airflow 1 Status		1 02	1 02	1 02	1 02	1 02
605 850 FF Hot Main Red Mod B RCCB Off		1 02	1 02	1 02	1 02	1 02
606 850 FF Hot Main Red Mod B RCCB On		1 02	1 02	1 02	1 02	1 02
607 850 FF Hot Main Red Mod A RCCB Off		1 02	1 02	1 02	1 02	1 02
608 850 FF Hot Main Red Mod A RCCB On		1 02	1 02	1 02	1 02	1 02
609 850 FF Hot Main Prim Mod B RCCB Off		1 02	1 02	1 02	1 02	1 02
610 850 FF Hot Main Prim Mod B RCCB On		1 02	1 02	1 02	1 02	1 02
611 850 FF HotMain Prim Mod A RCCB Off		1 02	1 02	1 02	1 02	1 02
612 850 FF HotMain Prim Mod A RCCB On		1 02	1 02	1 02	1 02	1 02
613 850 FF Hot Guard Modul e RCCB Off		1 02	1 02	1 02	1 02	1 02
614 850 FF Hot Guard Modul e RCCB On		1 02	1 02	1 02	1 02	1 02
615 850 FF Hot Boost Mod B RCCB Off		1 02	1 02	1 02	1 02	1 02
616 850 FF Hot Boost Mod B RCCB On		1 02	1 02	1 02	1 02	1 02
617 850 FF Hot Main Prim Htr Ctl Temp 1		1 02	1 02	1 02	1 02	1 02
618 850 FF Cold Main Red Htr Ctl Temp 1		1 02	1 02	1 02	1 02	1 02
619 850 FF TC Group A Calibration Type B		1 02	1 02	1 02	1 02	1 02
620 850 FF TC Group A Calibration Type S		1 02	1 02	1 02	1 02	1 02
621 850 FF TC Group A Calibration Type K		1 02	1 02	1 02	1 02	1 02
622 850 FF Cold Guard Heater Ctl Temp 2		1 02	1 02	1 02	1 02	1 02
623 850 FF Cold Main Prim Htr Ctl Temp 2		1 02	1 02	1 02	1 02	1 02
624 850 FF Booster Heater Ctl Temp 2		1 02	1 02	1 02	1 02	1 02
625 850 FF Hot Main Red Htr Ctl Temp 2		1 02	1 02	1 02	1 02	1 02
626 850 FF Hot Main Prim Htr Ctl Temp 2		1 02	1 02	1 02	1 02	1 02
627 850 FF Hot Guard Heater Ctl Temp 2		1 02	1 02	1 02	1 02	1 02
628 850 FF TC Group B Calibration Type B		1 02	1 02	1 02	1 02	1 02
		1 1	1 1	1 1	1 1	1 1
0		3 4	4 4	4 4	5 5	5 5
3		9 0	3 5	7 8	1 3	5 7
					5 6	6 6
					7 7	7 7
					8 0	8 0

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 26 of 38)

			ICU	MN NM S T	DATA DESCRIPTION	MONIC	REQ/A
ENT/C N			MIS	SO OS OY			
NO. O O			D/A	G /G P START	DATA VALUE	C R/C SID E T	
R .	DESCRIPTION		I/G	W F E .	-- L	D IO NO. X A	
R .			U E	D I WD BT WD BT Y	E E .	T D P B	
. .			L	S X * * P	V X C	? E I L	
K .			K	/ D E	N C O	T P F D E	
629 850 FF TC Group B Calibration Type S			1 02				41 2
630 850 FF TC Group B Calibration Type K			1 02				41 2
631 850 FF IFEA Coolant Flow #2 Status			1 02				41 2
632 850 FF IFEA Coolant Flow #1 Status			1 02				41 2
633 850 FF Sample 4 Temp 1			1 02				41 2
634 850 FF Sample 3 Temp 1			1 02				41 2
635 850 FF Sample 2 Temp 1			1 02				41 2
636 850 FF Sample 1 Temp 1			1 02				41 2
637 850 FF Cold Main Red Htr Ctl Temp 2			1 02				41 2
638 850 FF TC Group D Calibration Type B			1 02				41 2
639 850 FF TC Group D Calibration Type S			1 02				41 2
640 850 FF TC Group D Calibration Type K			1 02				41 2
641 850 FF Cold Guard Heater Ctl Temp 1			1 02				41 2
642 850 FF Cold Main Prim Htr Ctl Temp 1			1 02				41 2
643 850 FF Booster Heater Ctl Temp 1			1 02				41 2
644 850 FF Hot Guard Heater Ctl Temp 1			1 02				41 2
645 850 FF TC Group C Calibration Type B			1 02				41 2
646 850 FF TC Group C Calibration Type S			1 02				41 2
647 850 FF TC Group C Calibration Type K			1 02				41 2
648 850 FF Hot Main Red Htr Ctl Temp 1			1 02				41 2
649 850 FF Sample 2 Temp 4			1 02				41 2
650 850 FF Sample 1 Temp 4			1 02				41 2
651 850 FF Sample 6 Temp 3			1 02				41 2
652 850 FF Sample 5 Temp 3			1 02				41 2
653 850 FF Sample 4 Temp 3			1 02				41 2
654 850 FF Sample 3 Temp 3			1 02				41 2
655 850 FF Sample 2 Temp 3			1 02				41 2
656 850 FF Sample 1 Temp 3			1 02				41 2
657 850 FF Sample 6 Temp 2			1 02				41 2
658 850 FF Sample 5 Temp 2			1 02				41 2
1 1 1			1 1 1 1 1 1 1				
0 0 0 0			3 4 4 4 4 5 5 5				
3 6 7			9 0 3 5 7 8 1 3 5 7				
			5 6 7 1 2 5 8 0				

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 27 of 38)

			ICU	MNI	MISI	DATA DESCRIPTION	MNCI	
ENTIC	NO.	O	MIS	SO	OSIOY	---	REQA	---
N	I	R	DIA	G	PSTART	END	DATA VALUE	L
I	R	.	W	F	E	---	E	---
R	.	.	U	E	---	T	IO	T
.	.	.	D	I	WDIBT	WDIBT	X	A
.	.	.	S	X	*	P	P	B
.	.	.	L	*	*	I	?	D
.	.	.	K	/	D	E	NCO	L
.	.	.				E	TPF	D
.	.	.					E	E
659	850	FF	Sample	4	Temp	2	02	41 2
660	850	FF	Sample	3	Temp	2	02	41 2
661	850	FF	Sample	2	Temp	2	02	41 2
662	850	FF	Sample	1	Temp	2	02	41 2
663	850	FF	Sample	6	Temp	1	02	41 2
664	850	FF	Sample	5	Temp	1	02	41 2
665	850	FF	Sample	6	Temp	6	02	41 2
666	850	FF	Sample	5	Temp	6	02	41 2
667	850	FF	Sample	4	Temp	6	02	41 2
668	850	FF	Sample	3	Temp	6	02	41 2
669	850	FF	Sample	2	Temp	6	02	41 2
670	850	FF	Sample	1	Temp	6	02	41 2
671	850	FF	Sample	6	Temp	5	02	41 2
672	850	FF	Sample	5	Temp	5	02	41 2
673	850	FF	Sample	4	Temp	5	02	41 2
674	850	FF	Sample	3	Temp	5	02	41 2
675	850	FF	Sample	2	Temp	5	02	41 2
676	850	FF	Sample	1	Temp	5	02	41 2
677	850	FF	Sample	6	Temp	4	02	41 2
678	850	FF	Sample	5	Temp	4	02	41 2
679	850	FF	Sample	4	Temp	4	02	41 2
680	850	FF	Sample	3	Temp	4	02	41 2
681	850	FF	Sample	4	CJ Block	Temp 1	02	41 2
682	850	FF	Sample	3	CJ Block	Temp 2	02	41 2
683	850	FF	Sample	3	CJ Block	Temp 1	02	41 2
684	850	FF	Sample	2	CJ Block	Temp 2	02	41 2
685	850	FF	Sample	2	CJ Block	Temp 1	02	41 2
686	850	FF	Sample	1	CJ Block	Temp 2	02	41 2
687	850	FF	Sample	1	CJ Block	Temp 1	02	41 2
688	850	FF	RFM Water Outlet	Temp			02	41 2
	1						1	1
	0	0		3	4	4	4	1
	3	6		9	0	3	5	7

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 28 of 38)

	C	I	N	M	N	S	T	DATA DESCRIPTION	M	N	C	
ENT	C	N	M	S	O	O	I	REQ	A	REQ	A	
NO.	O	O	DIA	G.	/G	P	START	END	DATA VALUE	L	C R C SID	E T
R	.	.	I	G	W	F	E	T	E E .	D IO NO.	X A	
R	.	.	U E	D I	WD BT	WD BT	Y	V X C	T D	P B		
.	.	.	L	S X	#	*	P	N C O	? E	I L		
.	.	.	K	/ D	/ E	T P F			D E			
689	850	FF	Cold Zone	CJ	Block Temp	2	02	02	02	02	02	41 2
690	850	FF	Cold Zone	CJ	Block Temp	1	02	02	02	02	02	41 2
691	850	FF	Hot Zone	CJ	Block Temp	1	02	02	02	02	02	41 2
692	850	FF	Hot Zone	CJ	Block Temp	2	02	02	02	02	02	41 2
693	850	FF	RFM	Hot End	Shell Temp	02	02	02	02	02	02	41 2
694	850	FF	RFM	Cold End	Shell Temp	02	02	02	02	02	02	41 2
695	850	FF	IFEA	Water Inlet	Temp	02	02	02	02	02	02	41 2
696	850	FF	IFEA	Water Outlet	Temp	02	02	02	02	02	02	41 2
697	850	FF	RTD	Mux 3	Calibration	- Low	02	02	02	02	02	41 2
698	850	FF	RTD	Mux 3	Calibration	- High	02	02	02	02	02	41 2
699	850	FF	RTD	Mux 2	Calibration	- Low	02	02	02	02	02	41 2
700	850	FF	RTD	Mux 2	Calibration	- High	02	02	02	02	02	41 2
701	850	FF	RTD	Mux 1	Calibration	- Low	02	02	02	02	02	41 2
702	850	FF	RTD	Mux 1	Calibration	- High	02	02	02	02	02	41 2
703	850	FF	IFEA	Upper Atmosphere	Temp	02	02	02	02	02	02	41 2
704	850	FF	IFEA	Lower Atmosphere	Temp	02	02	02	02	02	02	41 2
705	850	FF	FTS	Stepping	Motor Temp	02	02	02	02	02	02	41 2
706	850	FF	SEM	Track	Temp	02	02	02	02	02	02	41 2
707	850	FF	Ampoule	Alignment	Arm Temp	02	02	02	02	02	02	41 2
708	850	FF	Sample 6	CJ	Block Temp	2	02	02	02	02	02	41 2
709	850	FF	Sample 6	CJ	Block Temp	1	02	02	02	02	02	41 2
710	850	FF	Sample 5	CJ	Block Temp	2	02	02	02	02	02	41 2
711	850	FF	Sample 5	CJ	Block Temp	1	02	02	02	02	02	41 2
712	850	FF	Sample 4	CJ	Block Temp	2	02	02	02	02	02	41 2
713	850	FF	Cold Main Red	Heater	Current	02	02	02	02	02	02	41 2
714	850	FF	Cold Main Red	Heater	Voltage	02	02	02	02	02	02	41 2
715	850	FF	Cold Main Primary	Heater	Cur	02	02	02	02	02	02	41 2
716	850	FF	Cold Main Primary	Heater	Volt	02	02	02	02	02	02	41 2
717	850	FF	Guard Heater	Current	02	02	02	02	02	02	41 2	
718	850	FF	Guard Heater	Voltage	02	02	02	02	02	02	41 2	
						1	1	1	1	1	1	1
						3	4	4	4	5	5	5
						9	0	3	5	7	8	8
						3	6	7	1	2	5	5

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 29 of 38)

		ICU	IMN	NM	SIT	DATA DESCRIPTION	IMONIC		REQA	
ENT	C N	IM S	SO	OS	O Y					
NO.	O O	ID A	G.	/G	P START	END	DATA VALUE	--L	CIRC SID	E T
R .	DESCRIPTION	G	W	F	E	--T	E E .	D IO NO.	X A	
R		U E	D I	WD BT	WD BT Y		V X C	T D	P B	
.		L	S X	#	P		N C O	? E	I L	
		K	/ D	E	T P F		T P F	I D	E	
1719	850 FF RTD Mux 8	Calibration - Low		02						141 2
1720	850 FF RTD Mux 8	Calibration - High		02						141 2
1721	850 FF RTD Mux 7	Calibration - Low		02						141 2
1722	850 FF RTD Mux 7	Calibration - High		02						141 2
1723	850 FF RTD Mux 6	Calibration - Low		02						141 2
1724	850 FF RTD Mux 6	Calibration - High		02						141 2
1725	850 FF RTD Mux 5	Calibration - Low		02						141 2
1726	850 FF RTD Mux 5	Calibration - High		02						141 2
1727	850 FF RTD Mux 4	Calibration - Low		02						141 2
1728	850 FF RTD Mux 4	Calibration - High		02						141 2
1729	850 FF IFEA Lower Humidity			02						141 2
1730	850 FF Rapid Translation Motor RPM			02						141 2
1731	850 FF Indexing CAM Rotary Position			02						141 2
1732	850 FF Furnace Linear Position			02						141 2
1733	850 FF Stepping Motor Phase B Cur			02						141 2
1734	850 FF Stepping Motor Phase B Volt			02						141 2
1735	850 FF Stepping Motor Phase A Cur			02						141 2
1736	850 FF Stepping Motor Phase A Volt			02						141 2
1737	850 FF Hot Main Red Heater Current			02						141 2
1738	850 FF Hot Main Red Heater Voltage			02						141 2
1739	850 FF Hot Main Primary Heater Cur			02						141 2
1740	850 FF Hot Main Primary Heater Volt			02						141 2
1741	850 FF Hot Guard Heater Current			02						141 2
1742	850 FF Hot Guard Heater Voltage			02						141 2
1743	850 FF Hot Boost Heater Current			02						141 2
1744	850 FF Hot Boost Heater Voltage			02						141 2
1745	850 FF SMS Board Velocity Reading			02						141 2
1746	850 FF Experiment Main Bus Voltage			02						141 2
1747	850 FF Experiment Main Bus Current			02						141 2
1748	850 FF IFEA Absolute Pressure 2			02						141 2

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 38 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 31 of 38)

ENT	C N	I CU	IMN	NM SIT	DATA DESCRIPTION	MON	C	//////	
NO.	O O	M S	SO	OS O Y		REQ	A	-----	
R .	D A	G . / G	P	START	END	DATA VALUE	-- L	CIRC S ID	E T
R .	I G	W F E				T	E E	DI O NO.	X A
R .	I U E	D I	W D B T	W D B T Y		J V X C	T D	P B	
.	L	S X *	*	P		N C O	? E	I L	
.	K	/ D		E		T P F		D E	
1029	851	RC Core Hold Down Not Retracted		102					
1030	851	RC Core Hold Down Retracted		102					
1031	851	RC Fail Safe Brake RCCB Off		102					
1032	851	RC Fail Safe Brake RCCB On		102					
1033	851	RC Rapid Xlation Clutch RCCB Off		102					
1034	851	RC Rapid Xlation Clutch RCCB On		102					
1035	851	RC Rapid Xlation Mtr RCCB Off		102					
1036	851	RC Rapid Xlation Mtr RCCB On		102					
1037	851	RC Step Motor Clutch RCCB Off		102					
1038	851	RC Step Motor Clutch RCCB On		102					
1039	851	RC Step Motor Drive RCCB Off		102					
1040	851	RC Step Motor Drive RCCB On		102					
1041	851	RC Furn Extreme Trvl Not Exceeded		102					
1042	851	RC Furn Extreme Trvl Exceeded		102					
1043	851	RC Furnace Position Not Home		102					
1044	851	RC Furnace Position Home		102					
1045	851	RC System Bus Relay Off		102					
1046	851	RC System Bus Relay On		102					
1047	851	RC PCS Utility RCCB Off		102					
1048	851	RC PCS Utility RCCB On		102					
1049	851	RC SEM Indexing Jog CW Status		102					
1050	851	RC SEM Indexing Jog CCW Status		102					
1051	851	RC Argon Fill Valve RCCB Off		102					
1052	851	RC Argon Fill Valve RCCB On		102					
1053	851	RC Argon Fill Valve Closed		102					
1054	851	RC Argon Fill Valve Open		102					
1055	851	RC IFEA ABS Press 1 RCCB Off		102					
1056	851	RC IFEA ABS Press 1 RCCB On		102					
1057	851	RC IFEA ABS Press 2 RCCB Off		102					
1058	851	RC IFEA ABS Press 2 RCCB On		102					
1	1			1	1	1	1	1	1
0	0			3 4	4 4 4	5 5 5	6 6 6	7 7 7	8
3	6 7			9 0	3 5 7 8	1 3 5 7	5 6 7	1 2 5 8	0

TABLE I-7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 32 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 33 of 38)

ENT IC N	ICU	MN NM S T	DATA DESCRIPTION	IMON IC	//////////
NO. O O	M S	SO OS O Y	DATA VALUE	REQ A	-----
IR .	D A	G. /G	P START	C RCSID E T	
IR .	G	W /F	END	D IO NO. X A	
IR .	UE	D /I	WD BT	T /E .	
IR .	L	S /X	WD BT Y	V X C	
IR .	K	/ D	#	P /T D	
IR .			P	N C O	
IR .			E	? E	
IR .			I	I L	
IR .			T P F	D E	
1089 851 RC Cartridge 4 Failure 2 Status	02	-	-	-	41 2
1090 851 RC Cartridge 4 Failure 1 Status	02	-	-	-	41 2
1091 851 RC Cartridge 5 Failure 2 Status	02	-	-	-	41 2
1092 851 RC Cartridge 5 Failure 1 Status	02	-	-	-	41 2
1093 851 RC Cartridge 6 Failure 2 Status	02	-	-	-	41 2
1094 851 RC Cartridge 6 Failure 1 Status	02	-	-	-	41 2
1095 851 RC Mech Pulsing Mod RCCB On	02	-	-	-	41 2
1096 851 RC Mech Pulsing Mod RCCB Off	02	-	-	-	41 2
1097 851 RC Peltier Pulsing Drv RCCB Off	02	-	-	-	41 2
1098 851 RC Peltier Pulsing Drv RCCB On	02	-	-	-	41 2
1099 851 RC Peltier Conn Motor RCCB Off	02	-	-	-	41 2
1000 851 RC Peltier Conn Motor RCCB On	02	-	-	-	41 2
101 851 RC Peltier Conn Extended-Not	02	-	-	-	41 2
102 851 RC Peltier Conn Extended	02	-	-	-	41 2
103 851 RC Peltier Conn Retracted-Not	02	-	-	-	41 2
104 851 RC Peltier Conn Retracted	02	-	-	-	41 2
105 851 RC Cold Guard Mod RCCB Off	02	-	-	-	41 2
106 851 RC Cold Guard Mod RCCB On	02	-	-	-	41 2
107 851 RC Cold Main Prim Mod RCCB Off	02	-	-	-	41 2
108 851 RC Cold Main Prim Mod RCCB On	02	-	-	-	41 2
109 851 RC Cold Main Red Mod RCCB Off	02	-	-	-	41 2
110 851 RC Cold Main Red Mod RCCB On	02	-	-	-	41 2
111 851 RC Hot Boost Mod A RCCB Off	02	-	-	-	41 2
112 851 RC Hot Boost Mod A RCCB On	02	-	-	-	41 2
113 851 RC Hot Boost Mod B RCCB Off	02	-	-	-	41 2
114 851 RC Hot Boost Mod B RCCB On	02	-	-	-	41 2
115 851 RC Hot Guard Module RCCB Off	02	-	-	-	41 2
116 851 RC Hot Guard Module RCCB On	02	-	-	-	41 2
117 851 RC HotMain Prim Mod A RCCB Off	02	-	-	-	41 2
118 851 RC HotMain Prim Mod A RCCB On	02	-	-	-	41 2
	1	1	1	1	1
	3 4	4 4	4 4	5 5	6 6
0 0 0	3 0	3 5	7 8	1 3	7 7
3 6 7	9 0	5 7	5 7	5 6 7	1 2 5 8 0

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 34 of 38)

			MN	NM	S/T	DATA DESCRIPTION	MON/C	
ENT	C N	O O	MIS	SO OS/O Y			REQ/A	
NO.	R .	R .	D/A	G./G/	P START	END	DATA VALUE	---
	DESCRIPTION		I/G	I/W	F/E		T	E/E .
			I/U/E	I/D	I/I	WD BT	WD BT	V/X/C
			I/L	I/S	I/X	*	*	N/C/O
			I/K	I/Y	I/D	I/I	I/E	T/P/F
1119	851	RC	Hot Main Prim Mod B	RCCB Off		02		41 2
1120	851	RC	Hot Main Prim Mod B	RCCB On		02		41 2
1121	851	RC	Hot Main Red Mod A	RCCB Off		02		41 2
1122	851	RC	Hot Main Red Mod A	RCCB On		02		41 2
1123	851	RC	Hot Main Red Mod B	RCCB Off		02		41 2
1124	851	RC	Hot Main Red Mod B	RCCB On		02		41 2
1125	851	RC	PCS Airflow 2	Status		02		41 2
1126	851	RC	PCS Airflow 1	Status		02		41 2
1127	851	RC	SCS Airflow 1	Status		02		41 2
1128	851	RC	PDS Airflow 1	Status		02		41 2
1129	851	RC	IFEA Coolant Flow #2	Status		02		41 2
1130	851	RC	IFEA Coolant Flow #1	Status		02		41 2
1131	851	RC	TC Group B	Calibration Type S		02		41 2
1132	851	RC	TC Group B	Calibration Type K		02		41 2
1133	851	RC	Hot Guard Heater Ctl	Temp 2		02		41 2
1134	851	RC	TC Group B	Calibration Type B		02		41 2
1135	851	RC	Hot Main Red Htr Ctl	Temp 2		02		41 2
1136	851	RC	Hot Main Prim Htr Ctl	Temp 2		02		41 2
1137	851	RC	Cold Main Prim Htr Ctl	Temp 2		02		41 2
1138	851	RC	Booster Heater Ctl	Temp 2		02		41 2
1139	851	RC	TC Group A	Calibration Type K		02		41 2
1140	851	RC	Cold Guard Heater Ctl	Temp 2		02		41 2
1141	851	RC	TC Group A	Calibration Type B		02		41 2
1142	851	RC	TC Group A	Calibration Type S		02		41 2
1143	851	RC	Hot Main Prim Htr Ctl	Temp 1		02		41 2
1144	851	RC	Cold Main Red Htr Ctl	Temp 1		02		41 2
1145	851	RC	TC Group C	Calibration Type K		02		41 2
1146	851	RC	Hot Main Red Htr Ctl	Temp 1		02		41 2
1147	851	RC	TC Group C	Calibration Type B		02		41 2
1148	851	RC	TC Group C	Calibration Type S		02		41 2

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 35 of 38)

ENT	C N	MN	NM SIT	DATA DESCRIPTION	MONIC	REQA
NO.	O O	M S	SO OS O Y	DATA VALUE	--L	CIRC SID E T
R .	D A	G . G	P START	--T	E E	DI O NO. X A
R .	I G	W F E	--	--	T D	P B
R .	I U E	I D I	WD BT WD BT Y	P	V X C	? E
R .	L	S X #	P	P	N C O	I L
R .	K	/ D	E	T P F	T P F	D E
149	851	RC	Booster Heater Ctl Temp 1	02		
150	851	RC	Hot Guard Heater Ctl Temp 1	02		
151	851	RC	Cold Guard Heater Ctl Temp 1	02		
152	851	RC	Cold Main Prim Htr Ctl Temp 1	02		
153	851	RC	TC Group D Calibration Type S	02		
154	851	RC	TC Group D Calibration Type K	02		
155	851	RC	Cold Main Red Htr Ctl Temp 2	02		
156	851	RC	TC Group D Calibration Type B	02		
157	851	RC	Sample 2 Temp 1	02		
158	851	RC	Sample 1 Temp 1	02		
159	851	RC	Sample 4 Temp 1	02		
160	851	RC	Sample 3 Temp 1	02		
161	851	RC	Sample 6 Temp 1	02		
162	851	RC	Sample 5 Temp 1	02		
163	851	RC	Sample 2 Temp 2	02		
164	851	RC	Sample 1 Temp 2	02		
165	851	RC	Sample 4 Temp 2	02		
166	851	RC	Sample 3 Temp 2	02		
167	851	RC	Sample 6 Temp 2	02		
168	851	RC	Sample 5 Temp 2	02		
169	851	RC	Sample 2 Temp 3	02		
170	851	RC	Sample 1 Temp 3	02		
171	851	RC	Sample 4 Temp 3	02		
172	851	RC	Sample 3 Temp 3	02		
173	851	RC	Sample 6 Temp 3	02		
174	851	RC	Sample 5 Temp 3	02		
175	851	RC	Sample 2 Temp 4	02		
176	851	RC	Sample 1 Temp 4	02		
177	851	RC	Sample 4 Temp 4	02		
178	851	RC	Sample 3 Temp 4	02		
1	1					
0	0					
3	6					
9	0					
3	6					
9	0					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					
5	6					
7	8					
1	2					

TABLE 17-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 36 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 37 of 38)

			ICU	IMN	NM	S	T	DATA DESCRIPTION	MON	C	//////////
ENT	C	N	IMIS	ISO	O	Y	-	-	REQ	A	-
NO.	O	O	\DIA	G.	/G	P	START	END	DATA VALUE	L	CRC SID E T
IR.	R.	.	G	W	F	E	-	-	E E	D IO NO.	X A
IR.	R.	.	U E	D	I	W	D BT	W D BT	Y	V X C	T D
.	.	L	S	X	#	#	P	N C O	? E	I L	P B
.	.	K	/	D	/	E	T P F	/	D	D E	I L
209	851	RC Sample	5	CJ	Block	Temp	1	02	-	-	41 2
210	851	RC Sample	4	CJ	Block	Temp	2	02	-	-	41 2
211	851	RC Sample	6	CJ	Block	Temp	1	02	-	-	41 2
212	851	RC Sample	5	CJ	Block	Temp	2	02	-	-	41 2
213	851	RC Ampoule	Alignment	Arm	Temp	-	-	-	-	-	41 2
214	851	RC Sample	6	CJ	Block	Temp	2	02	-	-	41 2
215	851	RC FTS	Stepping	Motor	Temp	-	-	-	-	-	41 2
216	851	RC SEM	Track	Temp	-	-	-	-	-	-	41 2
217	851	RC IFEA	Upper Atmosphere	Temp	-	-	-	-	-	-	41 2
218	851	RC IFEA	Lower Atmosphere	Temp	-	-	-	-	-	-	41 2
219	851	RC RTD	Mux 1	Calibration	-	Low	-	02	-	-	41 2
220	851	RC RTD	Mux 1	Calibration	-	High	-	02	-	-	41 2
221	851	RC RTD	Mux 2	Calibration	-	Low	-	02	-	-	41 2
222	851	RC RTD	Mux 2	Calibration	-	High	-	02	-	-	41 2
223	851	RC RTD	Mux 3	Calibration	-	Low	-	02	-	-	41 2
224	851	RC RTD	Mux 3	Calibration	-	High	-	02	-	-	41 2
225	851	RC RTD	Mux 4	Calibration	-	Low	-	02	-	-	41 2
226	851	RC RTD	Mux 4	Calibration	-	High	-	02	-	-	41 2
227	851	RC RTD	Mux 5	Calibration	-	Low	-	02	-	-	41 2
228	851	RC RTD	Mux 5	Calibration	-	High	-	02	-	-	41 2
229	851	RC RTD	Mux 6	Calibration	-	Low	-	02	-	-	41 2
230	851	RC RTD	Mux 6	Calibration	-	High	-	02	-	-	41 2
231	851	RC RTD	Mux 7	Calibration	-	Low	-	02	-	-	41 2
232	851	RC RTD	Mux 7	Calibration	-	High	-	02	-	-	41 2
233	851	RC RTD	Mux 8	Calibration	-	Low	-	02	-	-	41 2
234	851	RC RTD	Mux 8	Calibration	-	High	-	02	-	-	41 2
235	851	RC	Cold Guard	Heater	Current	-	-	-	-	-	41 2
236	851	RC	Cold Guard	Heater	Voltage	-	-	-	-	-	41 2
237	851	RC	Cold Main	Primary	Heater	Cur	-	02	-	-	41 2
238	851	RC	Cold Main	Primary	Heater	Volt	-	02	-	-	41 2
1	1	1	1	1	1	1	1	1	1	1	1
0	0	0	3	4	4	4	4	5	5	5	1
3	6	7	9	0	3	5	7	8	1	3	5
											0
											5
											7
											8
											0

TABLE I.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 38 of 38)

ENT	C N	NM	S T	DATA DESCRIPTION	MON	C	/ / / / / / / / /
NO.	O O	SO	OS	Y	REQ	A	
R .	D A	G .	G	P START	DATA VALUE	- - L	I C R C S I D E T
.	I G	I W	F E	T	E E .	D I O NO.	I X A
R	I U E	I D	I	W D B T	Y	T D	I P B
R	I L	I S	X	#	P	? E	I L
.	I K	I V	D I	I	E	T P F	I D E
239	851	RC	Cold Main Red Heater Current	02			41 2
240	851	RC	Cold Main Red Heater Voltage	02			41 2
241	851	RC	Hot Boost Heater Current	02			41 2
242	851	RC	Hot Boost Heater Voltage	02			41 2
243	851	RC	Hot Guard Heater Current	02			41 2
244	851	RC	Hot Guard Heater Voltage	02			41 2
245	851	RC	Main Primary Heater Cur	02			41 2
246	851	RC	Hot Main Primary Heater Volt	02			41 2
247	851	RC	Hot Main Red Heater Current	02			41 2
248	851	RC	Hot Main Red Heater Voltage	02			41 2
249	851	RC	Stepping Motor Phase A Cur	02			41 2
250	851	RC	Stepping Motor Phase A Volt	02			41 2
251	851	RC	Stepping Motor Phase B Cur	02			41 2
252	851	RC	Stepping Motor Phase B Volt	02			41 2
253	851	RC	Indexing CAM Rotary Position	02			41 2
254	851	RC	Furnace Linear Position	02			41 2
255	851	RC	IFEA Lower Humidity	02			41 2
256	851	RC	Rapid Translation Motor RPM	02			41 2
257	851	RC	IFEA Absolute Pressure 1	02			41 2
258	851	RC	IFEA Upper Humidity	02			41 2
259	851	RC	Experiment Main Bus Current	02			41 2
260	851	RC	IFEA Absolute Pressure 2	02			41 2
261	851	RC	SMS Board Velocity Reading	02			41 2
262	851	RC	Experiment Main Bus Voltage	02			41 2
263	851	PROCE	Elapsed Time - Seconds	02			41 2
264	851	GO/NGO	Error Override	02			41 2
265	851	CGF	Systm State	02			41 2
266	851	Auto	Pressure Ctl	02			41 2

TABLE 1.7-3. EVENT/EXCEPTION MONITOR REQUIREMENTS

TABLE 1.7.4. POIC DISPLAY REQUIREMENTS (Sheet 1 of 20)

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 2 of 20)

TABLE 1.7.4. POIC DISPLAY REQUIREMENTS (Sheet 3 of 20)

CALIBRATION COEFFICIENTS/LINEAR SEGMENTS											
IE	NIC	NCT	IN	UO	OAY	IE	IT	MR	LP	IE	IR
196	850	PCI	+0000000+001	+5000000-01							
197	850	PCI	+0000000+001	+5000000-01							
198	850	PCI	+0000000+001	+5000000-01							
199	850	PCI	+0000000+001	+5000000-01							
200	850	PCI	+0000000+001	+5000000-01							
201	850	PCI	+0000000+001	+5000000-01							
202	850	PCI	+0000000+001	+5000000-01							
203	850	PCI	+0000000+001	+5000000-01							
204	850	PCI	+0000000+001	+5000000-01							
205	850	PCI	+0000000+001	+5000000-01							
206	850	PCI	+0000000+001	+5000000-01							
207	850	PCI	+0000000+001	+5000000-01							
208	850	PCI	+0000000+001	+5000000-01							
209	850	PCI	+0000000+001	+5000000-01							
210	850	PCI	+0000000+001	+5000000-01							
211	850	PCI	+0000000+001	+5000000-01							
212	850	PCI	+0000000+001	+5000000-01							
213	850	PCI	+0000000+001	+9768000-02							
214	850	PCI	+0000000+001	+2442000-01							
215	850	PCI	+0000000+001	+2442000-01							
216	850	PCI	+0000000+001	+7326000-02							
217	850	PCI	+0000000+001	+7326000-02							
218	850	PCI	-2419000+031	+2325500+011	+9104500-031	+2442500-061					
219	850	PCI	-2419000+031	+2325500+011	+9104500-031	+2442500-061					
220	850	PCI	-2414600+031	+2297900+001	+1211300-041	-435650-091					
221	850	PCI	-2414600+031	+2297900+001	+1211300-041	-435650-091					
222	850	PCI	-2414600+031	+2297900+001	+1211300-041	-435650-091					
223	850	PCI	-2414600+031	+2297900+001	+1211300-041	-435650-091					
224	850	PCI	-2414600+031	+2297900+001	+1211300-041	-435650-091					
225	850	PCI	+1493200+021	+1381000+031	-8505200+001	-5706400-001	+1394700-021				
226	850	PCI	+1493200+021	+1381000+031	-8505200+001	-5706400-001	+1394700-021				
1	1	1	1	1	1	1	1	1	1	1	1
0	0	0	1	2	4	5	6	7	7	8	
3	5	7	8	9	0	1	2	3	3	9	0

TABLE I.7.4. POIC DISPLAY REQUIREMENTS (Sheet 4 of 20)

IE	NIC	NICT	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS							
IN	U	O	A	Y	A0	A1	A2	A3	A4	A5
I	E	M	R	I	1493200+02	+1381000+03	-8505200+01	+9220100+00	-5706400-01	+1394700-02
I	T	M	R	I	LP	+1491200+02	-8505200+01	+9220100+00	-5706400-01	+1394700-02
I	R	B	R	I	IE	+1493200+02	+1381000+03	-8505200+01	-5706400-01	+1394700-02
I	Y	E	I	B	I	+1493200+02	+1381000+03	-8505200+01	-5706400-01	+1394700-02
I	R	I	R	I	I	+1493200+02	+1381000+03	-8505200+01	-5706400-01	+1394700-02
I	R	I	A	A	I	+1493200+02	+1381000+03	-8505200+01	-5706400-01	+1394700-02
I	T	T	A	A	I	+1493200+02	+1381000+03	-8505200+01	-5706400-01	+1394700-02
I	O	I			I	+1493200+02	+1381000+03	-8505200+01	-5706400-01	+1394700-02
I	N	I			I	+1493200+02	+1381000+03	-8505200+01	-5706400-01	+1394700-02
I	227	1830	1PC	+1493200+02	+1381000+03	-8505200+01	+9220100+00	-5706400-01	+1394700-02	I41 6
I	228	1850	1PC	+1491200+02	+1381000+03	-8505200+01	+9220100+00	-5706400-01	+1394700-02	I41 6
I	229	1850	1PC	+1493200+02	+1381000+03	-8505200+01	-9220100+00	-5706400-01	+1394700-02	I41 6
I	230	1850	1PC	+1493200+02	+1381000+03	-8505200+01	+9220100+00	-5706400-01	+1394700-02	I41 6
I	231	1850	1PC	+1491200+02	+1381000+03	-8505200+01	+9220100+00	-5706400-01	+1394700-02	I41 6
I	232	1850	1PC	+1493200+02	+1381000+03	-8505200+01	-9220100+00	-5706400-01	+1394700-02	I41 6
I	233	1850	1PC	+1493200+02	+1381000+03	-8505200+01	+9220100+00	-5706400-01	+1394700-02	I41 6
I	234	1850	1PC	-1089200+02	+2705600+00	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	235	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	236	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	237	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	238	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	239	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	240	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	241	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	242	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	243	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	244	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	245	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	246	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	247	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	248	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	249	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	250	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	251	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	252	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	253	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	254	1850	1PC	-1089200+02	+2705600+02	-1504300+02	+1159800-02	+582500-04	-5337600-06	I41 6
I	255	1850	1PC	+1493200+02	+1381000+03	-8505200+01	+9220100+00	-506400-01	+1394700-02	I41 6
I	256	1850	1PC	+1493200+02	+1381000+03	-8505200+01	+9220100+00	-506400-01	+1394700-02	I41 6
I	257	1850	1PC	+1493200+02	+1381000+03	-8505200+01	+9220100+00	-506400-01	+1394700-02	I41 6

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 5 of 20)

IE NIC NICt		CALIBRATION COEFFICIENTS/LINEAR SEGMENTS						
IN	UDIO	OAY	IT	MIR	LP	IR	BIR	IEt
Y	E	I	R	I	A	I	T	
1258	1850	1PC	+1493200+02 +1381000+03 -8505200+01 +9220100+00 -5706400-01 +1394700-02	41 6				
1259	1850	1PC	+1493200+02 +1381000+03 -8505200+01 +9220100+00 -5706400-01 +1394700-02	41 6				
1260	1850	1PC	+1493200+02 +1381000+03 -8505200+01 +9220100+00 -5706400-01 +1394700-02	41 6				
1261	1850	1PC	+00000000+00 +1743900-02					
1262	1850	1PC	+00000000+00 +1743900-02					
1263	1850	1PC	+00000000+00 +1743900-02					
1264	1850	1PC	+00000000+00 +5086300-02					
1265	1850	1PC	-2566000+01 +1364100-00					
1266	1850	1PC	-2414600+03 +2297900+00 +1211300-04 -4356500-09					
1267	1850	1PC	+00000000+00 +16227600-01					
1268	1850	1PC	+00000000+00 +7326000-02					
1269	1850	1PC	+00000000+00 +1953600-01					
1270	1850	1PC	+00000000+00 +7326000-02					
1271	1850	1PC	+00000000+00 +1953600-01					
1272	1850	1PC	+00000000+00 +7326000-02					
1273	1850	1PC	+00000000+00 +1953600-01					
1274	1850	1PC	+00000000+00 +7326000-02					
1275	1850	1PC	+00000000+00 +1953600-01					
1276	1850	1PC	+00000000+00 +7326000-02					
1277	1850	1PC	+00000000+00 +1953600-01					
1278	1850	1PC	+00000000+00 +7326000-02					
1279	1850	1PC	+00000000+00 +1953600-01					
1280	1850	1PC	+00000000+00 +7326000-02					
1281	1850	1PC	+00000000+00 +1953600-01					
1282	1850	1PC	-2414600+03 +2297900+00 +1211300-04 -4356500-09					
1283	1850	1PC	-2414600+03 +2297900+00 +1211300-04 -4356500-09					
1284	1850	1PC	-2414600+03 +2297900+00 +1211300-04 -4356500-09					
1285	1850	1PC	-2414600+03 +2297900+00 +1211300-04 -4356500-09					
1286	1850	1PC	-2414600+03 +2297900+00 +1211300-04 -4356500-09					
1287	1850	1PC	-2414600+03 +2297900+00 +1211300-04 -4356500-09					
1288	1850	1PC	-2414600+03 +2297900+00 +1211300-04 -4356500-09					
1	1	1	1	1	1	1	1	1
0	0	0	1	2	4	5	6	1
3	5	7	8	9	0	2	3	0

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 6 of 20)

IE	NIC	NICT	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS					
IN	UIO	OAY						
T MIR	ILP							E T
R BIR	IE							X A
Y E	B							P B
R	R							L
A	A							I
T	A0		A1	A2	A3	A4	A5	B
I	I							D
O	I							
N	I							
289 850 PCI -2414600+03 +2297900+00 +1211300-04 -4356500-09								41 6
290 850 PCI -2414600-03 +2297900+00 +1211300-04 -4356500-09								41 6
291 850 PCI -2414600+03 +2297900+00 +1211300-04 -4356500-09								41 6
292 850 PCI -2414600+03 +2297900+00 +1211300-04 -4356500-09								41 6
293 850 PCI -2414600+03 +2297900+00 +1211300-04 -4356500-09								41 6
294 850 PCI -2414600+03 +2297900+00 +1211300-04 -4356500-09								41 6
295 850 PCI -2414600+03 +2297900+00 +1211300-04 -4356500-09								41 6
296 850 PCI -2414600+03 +2297900+00 +1211300-04 -4356500-09								41 6
297 850 PCI -2414600+03 +2297900+00 +1211300-04 -4356500-09								41 6
298 850 PCI +00000000+00 +1000000+01								41 6
299 850 PCI +00000000+00 +1000000+01								41 6
300 850 PCI +00000000+00 +1000000+01								41 6
301 850 PCI +00000000+00 +1000000+01								41 6
302 850 PCI +00000000+00 +1000000+01								41 6
303 850 PCI +00000000+00 +1000000+01								41 6
304 850 PCI +00000000+00 +1000000+01								41 6
305 850 PCI +00000000+00 +1000000+01								41 6
306 850 PCI +00000000+00 +1000000+01								41 6
307 850 PCI +00000000+00 +1000000+01								41 6
308 850 PCI +00000000+00 +1000000+01								41 6
309 850 PCI +00000000+00 +1000000+01								41 6
310 850 PCI +00000000+00 +1000000+01								41 6
311 850 PCI +00000000+00 +1000000+01								41 6
312 850 PCI +00000000+00 +8302800-01								41 6
313 850 PCI -2414600+03 +2297900+00 +1211300-04 -4356500-09								41 6
314 850 PCI -2414600+03 +2297900+00 +1211300-04 -4356500-09								41 6
315 850 PCI +9760000+03 +2442000+00								41 6
316 850 PCI +9760000+03 +2442000+00								41 6
317 850 PCI +9760000+03 +2442000+00								41 6
318 850 PCI +9760000+03 +2442000+00								41 6
319 850 PCI +9760000+03 +2442000+00								41 6
1	1	1	1	1	1	1	1	
0	0	0	2	4	5	6	7	
3	5	7	8	9	0	1	2	

TABLE 1.7.4. POIC DISPLAY REQUIREMENTS (Sheet 7 of 20)

		CALIBRATION COEFFICIENTS/LINEAR SEGMENTS																										
IE	NIC	NICT	IN	UIO	OAY	IT	MIR	LP	IE	R	BIR	Y	E	I	R	R	A	T	I	X	A	P	B	L	I	B	D	
1320	1850	IPC	+9760000+031	+2442000+001																						141 6		
1321	1850	IPC	+6810000-021	+2442000-011																						141 6		
1322	1850	IPC	+6810000-021	+2442000-011																						141 6		
1323	1850	IPC	+9760000+031	+2442000+001																						141 6		
1324	1850	IPC	+9760000+031	+2442000+001																						141 6		
1325	1850	IPC	+9760000+031	+2442000+001																						141 6		
1326	1850	IPC	+9760000+031	+2442000+001																						141 6		
1327	1850	IPC	+9760000+031	+2442000+001																						141 6		
1328	1850	IPC	+9760000+031	+2442000+001																						141 6		
1329	1850	IPC	+6810000+021	+2442000-011																						141 6		
1330	1850	IPC	+6810000+021	+2442000-011																						141 6		
1331	1850	IPC	+00000000+001	+10000000+011																						141 6		
1332	1850	IPC	+00000000+001	+3125000+001																						141 6		
1333	1850	IPC	+00000000+001	+2500000+001																						141 6		
1334	1850	IPC	+00000000+001	+10000000+011																						141 6		
1335	1850	IPC	+00000000+001	+3125000+001																						141 6		
1336	1850	IPC	+00000000+001	+2500000+001																						141 6		
1337	1850	IPC	+00000000+001	+10000000+011																						141 6		
1338	1850	IPC	+00000000+001	+3125000+001																						141 6		
1339	1850	IPC	+00000000+001	+2500000+001																						141 6		
1340	1850	IPC	+00000000+001	+10000000+011																						141 6		
1341	1850	IPC	+00000000+001	+3125000+001																						141 6		
1342	1850	IPC	+00000000+001	+2500000+001																						141 6		
1343	1850	IPC	+00000000+001	+7096670-041																						141 6		
1344	1850	IPC	+00000000+001	+10000000+011																						141 6		
1345	1850	IPC	+00000000+001	+10000000+011																						141 6		
1346	1850	IPC	+00000000+001	+10000000+011																						141 6		
1347	1850	IPC	+00000000+001	+10000000+011																						141 6		
1348	1850	IPC	+00000000+001	+10000000+011																						141 6		
1349	1850	IPC	+00000000+001	+10000000+011																						141 6		
1350	1850	IPC	+00000000+001	+10000000+011																						141 6		
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1				
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0				
3	5	7	8	9	9	9	9	9	9	9	9	9	9	9	9	9	9	9	9	9	9	9	9	9				

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 8 of 20)

IE	NIC	NICT	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS					
I	N	U/I O/I A/Y	I/P	I/T	M/R	B/R	I/E	I/B
R	A	T	A0	A1	A2	A3	A4	A5
I	O	I						
I	IN	I						
1352	1850	PC +0000000+00 +1000000+01						
1353	1850	PC +0000000+00 +1000000+01						
1354	1850	PC +0000000+00 +1000000+01						
1356	1850	PC +0000000+00 +1000000+01						
1357	1850	PC +0000000+00 +1000000+01						
1358	1850	PC +0000000+00 +1000000+01						
1360	1850	PC +0000000+00 +1000000+01						
1361	1850	PC +0000000+00 +1000000+01						
1362	1850	PC +0000000+00 +1000000+01						
1363	1850	PC +0000000+00 +1000000+01						
1364	1850	PC +0000000+00 +1000000+01						
1365	1850	PC +0000000+00 +1000000+01						
1366	1850	PC +0000000+00 +1000000+01						
1369	1850	PC +0000000+00 +1000000+01						
1370	1850	PC +0000000+00 +1000000+01						
1371	1850	PC +0000000+00 +1000000+01						
1372	1850	PC +0000000+00 +1000000+01						
1373	1850	PC +0000000+00 +1000000+01						
1374	1850	PC +0000000+00 +1000000+01						
1377	1850	PC +0000000+00 +1000000+01						
1378	1850	PC +0000000+00 +1000000+01						
1379	1850	PC +0000000+00 +1000000+01						
1380	1850	PC +0000000+00 +1000000+01						
1381	1850	PC +0000000+00 +1000000+01						
1382	1850	PC +0000000+00 +1000000+01						
1385	1850	PC +0000000+00 +1000000+01						
1386	1850	PC +0000000+00 +1000000+01						
1387	1850	PC +0000000+00 +1000000+01						
1388	1850	PC +0000000+00 +1000000+01						
1389	1850	PC +0000000+00 +1000000+01						
1390	1850	PC +0000000+00 +1000000+01						

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 9 of 20)

IE	NIC	NICT	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS					
IN	UIO	OIAY	A0	A1	A2	A3	A4	A5
IT	MIR	ILP						
IR	BIR	IIE						
Y	E	B						
R	I	R						
A	T	A						
I	T	I						
I	O	I						
I	N	I						
1391	1850	IPC	+0000000+001+1000000+011					
1392	1850	IPC	+0000000+001+1000000+011					
1393	1850	IPC	+0000000+001+1000000+011					
1394	1850	IPC	+0000000+001+1000000+011					
1395	1850	IPC	+0000000+001+1000000+011					
1396	1850	IPC	+0000000+001+1000000+011					
1397	1850	IPC	+0000000+001+1000000+011					
1398	1850	IPC	+0000000+001+1000000+011					
1399	1850	IPC	+0000000+001+1000000+011					
1400	1850	IPC	+0000000+001+1000000+011					
1401	1850	IPC	+0000000+001+1000000+011					
1402	1850	IPC	+0000000+001+1000000+011					
1403	1850	IPC	+0000000+001+1000000+011					
1404	1850	IPC	+0000000+001+1000000+011					
1405	1850	IPC	+0000000+001+1000000+011					
1406	1850	IPC	+0000000+001+1000000+011					
1407	1850	IPC	+0000000+001+1000000+011					
1408	1850	IPC	+0000000+001+1000000+011					
1409	1850	IPC	+0000000+001+1000000+011					
1410	1850	IPC	+0000000+001+1000000+011					
1411	1850	IPC	+0000000+001+1000000+011					
1412	1850	IPC	+0000000+001+1000000+011					
1413	1850	IPC	+0000000+001+1000000+011					
1414	1850	IPC	+0000000+001+1000000+011					
1415	1850	IPC	+0000000+001+1000000+011					
1417	1850	IPC	+0000000+001+1000000+011					
1418	1850	IPC	+0000000+001+1000000+011					
1419	1850	IPC	+0000000+001+1000000+011					
1421	1850	IPC	+0000000+001+1000000+011					
1422	1850	IPC	+0000000+001+1000000+011					
1423	1850	IPC	+0000000+001+1000000+011					
1	1	1	1	1	1	1	1	1
0	0	0	2	4	5	6	7	1
3	5	7	8	9	0	2	8	9

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 10 of 20)

IE	NIC	NICT	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS					
IN	U	O	A	Y	I	P	I	
425 850 IPC +0000000+001 +1000000+011								41 6
427 850 IPC +0000000+001 +1000000+011								41 6
428 850 IPC +0000000+001 +1000000+011								41 6
429 850 IPC +0000000+001 +1000000+011								41 6
431 850 IPC +0000000+001 +1000000+011								41 6
432 850 IPC +0000000+001 +1000000+011								41 6
433 850 IPC +0000000+001 +1000000+011								41 6
435 850 IPC +0000000+001 +1000000+011								41 6
437 850 IPC +0000000+001 +1000000+011								41 6
438 850 IPC +0000000+001 +1000000+011								41 6
439 850 IPC +0000000+001 +1000000+011								41 6
441 850 IPC +0000000+001 +1000000+011								41 6
442 850 IPC +0000000+001 +1000000+011								41 6
443 850 IPC +0000000+001 +1000000+011								41 6
445 850 IPC +0000000+001 +1000000+011								41 6
447 850 IPC +0000000+001 +1000000+011								41 6
448 850 IPC +0000000+001 +1000000+011								41 6
449 850 IPC +0000000+001 +1000000+011								41 6
451 850 IPC +0000000+001 +1000000+011								41 6
452 850 IPC +0000000+001 +1000000+011								41 6
453 850 IPC +0000000+001 +1000000+011								41 6
455 850 IPC +0000000+001 +1000000+011								41 6
457 850 IPC +0000000+001 +1000000+011								41 6
458 850 IPC +0000000+001 +1000000+011								41 6
459 850 IPC +0000000+001 +1000000+011								41 6
461 850 IPC +0000000+001 +1000000+011								41 6
462 850 IPC +0000000+001 +1000000+011								41 6
463 850 IPC +0000000+001 +1000000+011								41 6
470 850 IPC +0000000+001 +1000000+011								41 6
471 850 IPC +0000000+001 +1000000+011								41 6
472 850 IPC +0000000+001 +1000000+011								41 6

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 11 of 20)

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 12 of 20)

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 13 of 20)

IE	NIC	NIC#	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS				
IN	UIO	OLAYI					
IT	MIR	ILP					
IR	BIR	IE					
IY	E	IB					
IR	R	IA					
IT	A	A0					
II							
IO							
IN							
1047	1851	IPC	+00000000+001+10000000+011				141161
1048	1851	IPC	+00000000+001+10000000+011				141161
1049	1851	IPC	+00000000+001+10000000+011				141161
1050	1851	IPC	+00000000+001+10000000+011				141161
1051	1851	IPC	+00000000+001+10000000+011				141161
1052	1851	IPC	+00000000+001+10000000+011				141161
1053	1851	IPC	+00000000+001+10000000+011				141161
1054	1851	IPC	+00000000+001+10000000+011				141161
1055	1851	IPC	+00000000+001+10000000+011				141161
1056	1851	IPC	+00000000+001+10000000+011				141161
1057	1851	IPC	+00000000+001+10000000+011				141161
1058	1851	IPC	+00000000+001+10000000+011				141161
1059	1851	IPC	+00000000+001+10000000+011				141161
1060	1851	IPC	+00000000+001+10000000+011				141161
1061	1851	IPC	+00000000+001+10000000+011				141161
1062	1851	IPC	+00000000+001+10000000+011				141161
1063	1851	IPC	+00000000+001+10000000+011				141161
1064	1851	IPC	+00000000+001+10000000+011				141161
1065	1851	IPC	+00000000+001+10000000+011				141161
1066	1851	IPC	+00000000+001+10000000+011				141161
1067	1851	IPC	+00000000+001+10000000+011				141161
1068	1851	IPC	+00000000+001+10000000+011				141161
1069	1851	IPC	+00000000+001+10000000+011				141161
1070	1851	IPC	+00000000+001+10000000+011				141161
1071	1851	IPC	+00000000+001+10000000+011				141161
1072	1851	IPC	+00000000+001+10000000+011				141161
1073	1851	IPC	+00000000+001+10000000+011				141161
1074	1851	IPC	+00000000+001+10000000+011				141161
1075	1851	IPC	+00000000+001+10000000+011				141161
1076	1851	IPC	+00000000+001+10000000+011				141161
1077	1851	IPC	+00000000+001+10000000+011				141161

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 14 of 20)

IE	N	C	T	IE	O	A	Y	LP	IE	B	I	R	R	A	T	I	O	IN	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS						
																				A0	A1	A2	A3	A4	A5
1078	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1079	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1080	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1081	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1082	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1083	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1084	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1085	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1086	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1087	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1088	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1089	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1090	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1091	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1092	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1093	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1094	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1095	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1096	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1097	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1098	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1099	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1100	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1101	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1102	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1103	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1104	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1105	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1106	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1107	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	
1108	1851	PC +0	0	0	0	0	0	0	-0	0	+	1	0	0	0	0	0	0	0	0	0	0	0	0	

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 15 of 20)

IE	NIC	NICT	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS					
IN	UIO	OAY						
IT	MIR	LP	E	R	I	T	X	
IR	B.R	I.E	I.B	I.R	I.A	I.T	I.X	
Y	E	R	A	T	A0	A1	A2	
1109 851 PC +00000000+00 +10000000+01								1111 6
1110 851 PC +00000000+00 +10000000+01								1112 6
1111 851 PC +00000000+00 +10000000+01								1113 6
1112 851 PC +00000000+00 +10000000+01								1114 6
1113 851 PC +00000000+00 +10000000+01								1115 6
1114 851 PC +00000000+00 +10000000+01								1116 6
1115 851 PC +00000000+00 +10000000+01								1117 6
1116 851 PC +00000000+00 +10000000+01								1118 6
1117 851 PC +00000000+00 +10000000+01								1119 6
1118 851 PC +00000000+00 +10000000+01								1119 6
1119 851 PC +00000000+00 +10000000+01								1120 6
1120 851 PC +00000000+00 +10000000+01								1121 6
1121 851 PC +00000000+00 +10000000+01								1122 6
1122 851 PC +00000000+00 +10000000+01								1123 6
1123 851 PC +00000000+00 +10000000+01								1124 6
1124 851 PC +00000000+00 +10000000+01								1125 6
1125 851 PC +00000000+00 +10000000+01								1126 6
1126 851 PC +00000000+00 +10000000+01								1127 6
1127 851 PC +00000000+00 +10000000+01								1128 6
1128 851 PC +00000000+00 +10000000+01								1129 6
1129 851 PC +00000000+00 +10000000+01								1130 6
1130 851 PC +00000000+00 +10000000+01								1131 6
1131 851 PC +00000000+00 +10000000+01								1132 6
1132 851 PC +00000000+00 +10000000+01								1133 6
1133 851 PC +00000000+00 +10000000+01								1134 6
1134 851 PC +00000000+00 +10000000+01								1135 6
1135 851 PC +00000000+00 +10000000+01								1136 6
1136 851 PC +00000000+00 +10000000+01								1137 6
1137 851 PC +00000000+00 +10000000+01								1138 6
1138 851 PC +00000000+00 +10000000+01								1139 6
1139 851 PC +00000000+00 +10000000+01								

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 16 of 20)

IE	N	C	N	C	T	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS
IN	U	O	A	Y		
T	M	R	L	P	E T	
R	B	R	I	E	X A	---
Y	E	B	I	P	B	---
R	R	A	A		L	---
A	T	A0	A1		I B	---
I	O				D	---
N						---
140 851 PC +00000000+001 +10000000+01						41 6
141 851 PC +00000000+001 +10000000+01						41 6
142 851 PC +00000000+001 +10000000+01						41 6
143 851 PC +00000000+001 +10000000+01						41 6
144 851 PC +00000000+001 +10000000+01						41 6
145 851 PC +00000000+001 +10000000+01						41 6
146 851 PC +00000000+001 +10000000+01						41 6
147 851 PC +00000000+001 +10000000+01						41 6
148 851 PC +00000000+001 +10000000+01						41 6
149 851 PC +00000000+001 +10000000+01						41 6
150 851 PC +00000000+001 +10000000+01						41 6
151 851 PC +00000000+001 +10000000+01						41 6
152 851 PC +00000000+001 +10000000+01						41 6
153 851 PC +00000000+001 +10000000+01						41 6
154 851 PC +00000000+001 +10000000+01						41 6
155 851 PC +00000000+001 +10000000+01						41 6
156 851 PC +00000000+001 +10000000+01						41 6
157 851 PC +00000000+001 +10000000+01						41 6
158 851 PC +00000000+001 +10000000+01						41 6
159 851 PC +00000000+001 +10000000+01						41 6
160 851 PC +00000000+001 +10000000+01						41 6
161 851 PC +00000000+001 +10000000+01						41 6
162 851 PC +00000000+001 +10000000+01						41 6
163 851 PC +00000000+001 +10000000+01						41 6
164 851 PC +00000000+001 +10000000+01						41 6
165 851 PC +00000000+001 +10000000+01						41 6
166 851 PC +00000000+001 +10000000+01						41 6
167 851 PC +00000000+001 +10000000+01						41 6
168 851 PC +00000000+001 +10000000+01						41 6
169 851 PC +00000000+001 +10000000+01						41 6
170 851 PC +00000000+001 +10000000+01						41 6
1	1	1	1	1	1	1
0	0	0	1	2	6	1
3	5	7	8	9	2	3
						9 0

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 17 of 20)

E NIC NICT		CALIBRATION COEFFICIENTS/LINEAR SEGMENTS	
N UIO OAY	I	I	T
T MIR	LP	X	A
R BIR	IE	I	P
Y EI	B	L	B
R	R	I	
A	A	D	
T	A0	A5	
I	A1		
O	A2		
N	A3		
	A4		
1171	851 PCI +00000000+001+10000000+01	41 6	
1172	851 PCI +00000000+001+10000000+01	41 6	
1173	851 PCI +00000000+001+10000000+01	41 6	
1174	851 PCI +00000000+001+10000000+01	41 6	
1175	851 PCI +00000000+001+10000000+01	41 6	
1176	851 PCI +00000000+001+10000000+01	41 6	
1177	851 PCI +00000000+001+10000000+01	41 6	
1178	851 PCI +00000000+001+10000000+01	41 6	
1179	851 PCI +00000000+001+10000000+01	41 6	
1180	851 PCI +00000000+001+10000000+01	41 6	
1181	851 PCI +00000000+001+10000000+01	41 6	
1182	851 PCI +00000000+001+10000000+01	41 6	
1183	851 PCI +00000000+001+10000000+01	41 6	
1184	851 PCI +00000000+001+10000000+01	41 6	
1185	851 PCI +00000000+001+10000000+01	41 6	
1186	851 PCI +00000000+001+10000000+01	41 6	
1187	851 PCI +00000000+001+10000000+01	41 6	
1188	851 PCI +00000000+001+10000000+01	41 6	
1189	851 PCI +00000000+001+10000000+01	41 6	
1190	851 PCI +00000000+001+10000000+01	41 6	
1191	851 PCI +00000000+001+10000000+01	41 6	
1192	851 PCI +00000000+001+10000000+01	41 6	
1193	851 PCI +00000000+001+10000000+01	41 6	
1194	851 PCI +00000000+001+10000000+01	41 6	
1195	851 PCI +00000000+001+10000000+01	41 6	
1196	851 PCI +00000000+001+10000000+01	41 6	
1197	851 PCI +00000000+001+10000000+01	41 6	
1198	851 PCI +00000000+001+10000000+01	41 6	
1199	851 PCI +00000000+001+10000000+01	41 6	
1200	851 PCI +00000000+001+10000000+01	41 6	
1201	851 PCI +00000000+001+10000000+01	41 6	

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 18 of 20)

		CALIBRATION COEFFICIENTS/LINEAR SEGMENTS						
		A0	A1	A2	A3	A4	A5	
I	E							
E	N							
M	C							
N	I							
U	O							
V	A							
M	R							
R	I							
B	R							
E	I							
R	R							
A	A							
T	T							
I	I							
O	O							
N	N							
202	851 PC +0000000+00 +1000000+01							
203	851 PC +0000000+00 +1000000+01							
204	851 PC +0000000+00 +1000000+01							
205	851 PC +0000000+00 +1000000+01							
206	851 PC +0000000+00 +1000000+01							
207	851 PC +0000000+00 +1000000+01							
208	851 PC +0000000+00 +1000000+01							
209	851 PC +0000000+00 +1000000+01							
210	851 PC +0000000+00 +1000000+01							
211	851 PC +0000000+00 +1000000+01							
212	851 PC +0000000+00 +1000000+01							
213	851 PC +0000000+00 +1000000+01							
214	851 PC +0000000+00 +1000000+01							
215	851 PC +0000000+00 +1000000+01							
216	851 PC +0000000+00 +1000000+01							
217	851 PC +0000000+00 +1000000+01							
218	851 PC +0000000+00 +1000000+01							
219	851 PC +0000000+00 +1000000+01							
220	851 PC +0000000+00 +1000000+01							
221	851 PC +0000000+00 +1000000+01							
222	851 PC +0000000+00 +1000000+01							
223	851 PC +0000000+00 +1000000+01							
224	851 PC +0000000+00 +1000000+01							
225	851 PC +0000000+00 +1000000+01							
226	851 PC +0000000+00 +1000000+01							
227	851 PC +0000000+00 +1000000+01							
228	851 PC +0000000+00 +1000000+01							
229	851 PC +0000000+00 +1000000+01							
230	851 PC +0000000+00 +1000000+01							
231	851 PC +0000000+00 +1000000+01							
232	851 PC +0000000+00 +1000000+01							
		1	1	1	1	1	1	1
		0	0	2	4	5	6	7
		3	5	9	0	1	2	3
		7	8					9
								0

TABLE 1.7.4. POIC DISPLAY REQUIREMENTS (Sheet 19 of 20)

IE	NIC	NIC#	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS
IN	UO	OAY	
IT	MIR	LP	
IR	BIR	IE	
IY	EI	I	
IR	I	R	
I	T	A	
I	I	I	
I	O	O	
I	N	N	
1233	1851	PCI +0000000+00 +1000000+01	
1234	1851	PCI +0000000+00 +1000000+01	E T
1235	1851	PCI +0000000+00 +1000000+01	X A
1236	1851	PCI +0000000+00 +1000000+01	P B
1237	1851	PCI +0000000+00 +1000000+01	L
1238	1851	PCI +0000000+00 +1000000+01	I B
1239	1851	PCI +0000000+00 +1000000+01	D
1240	1851	PCI +0000000+00 +1000000+01	
1241	1851	PCI +0000000+00 +1000000+01	
1242	1851	PCI +0000000+00 +1000000+01	
1243	1851	PCI +0000000+00 +1000000+01	
1244	1851	PCI +0000000+00 +1000000+01	
1245	1851	PCI +0000000+00 +1000000+01	
1246	1851	PCI +0000000+00 +1000000+01	
1247	1851	PCI +0000000+00 +1000000+01	
1248	1851	PCI +0000000+00 +1000000+01	
1249	1851	PCI +0000000+00 +1000000+01	
1250	1851	PCI +0000000+00 +1000000+01	
1251	1851	PCI +0000000+00 +1000000+01	
1252	1851	PCI +0000000+00 +1000000+01	
1253	1851	PCI +0000000+00 +1000000+01	
1254	1851	PCI +0000000+00 +1000000+01	
1255	1851	PCI +0000000+00 +1000000+01	
1256	1851	PCI +0000000+00 +1000000+01	
1257	1851	PCI +0000000+00 +1000000+01	
1258	1851	PCI +0000000+00 +1000000+01	
1259	1851	PCI +0000000+00 +1000000+01	
1260	1851	PCI +0000000+00 +1000000+01	
1261	1851	PCI +0000000+00 +1000000+01	
1262	1851	PCI +0000000+00 +1000000+01	
1263	1851	PCI +0000000+00 +3000000-01	
1	1	1	1
0	0	0	2
3	5	7	9
			1
			5
			6
			2
			1
			3
			9
			0

TABLE 1.7-4. POIC DISPLAY REQUIREMENTS (Sheet 20 of 20)

IE NIC NICT		CALIBRATION COEFFICIENTS/LINEAR SEGMENTS					
IN	UIO OAY	LP					
IT	M R						
IR	B R						
IE							
Y E	B						
R	R						
I A	A						
I T	T						
I I	I						
I O	O						
I N	N						
126518511PC1+0000000+001+1000000+011							
1	1						
0	0	1					
3	5	8	2	4	5	6	1
		9	0	1	2	3	7
						9	8
						0	0

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 1 of 4)

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 2 of 14)

IC N	WARNING VALUES (YELLOW LINE)	Critical Values (RED LINE)	EXCEPTION MONITOR MESSAGE	DI STATE CODE
IE NIO OIMT	OY			1//1//1
IN U R	INP			1//1//1
IT M R	IE	UPPER	UPPER	1 E [T]
IR B I	T	LIMIT	LOWER	1 X [A]
Y E	T	LIMIT	LIMIT	1 P [B]
R I	IO			1 I [L]
	IR			1 D [E]
1029 1850				
1030 1850				
031 1850				
1032 1850				
1033 1850				
1034 1850				
1035 1850				
1036 1850				
1037 1850				
1038 1850				
1039 1850				
1040 1850				
1041 1850				
1042 1850				
1043 1850				
1044 1850				
1045 1850				
1046 1850 [EM]				
1047 1850 [EM]				
1048 1850				
1049 1850				
1050 1850				
1051 1850				
1052 1850 [EM]				
1053 1850 [EM]				
1054 1850				
1055 1850				
1056 1850				
1057 1850				
1058 1850				
1059 1850				
1060 1850				
1061 1850				
1 1	1	1	1 1	1 1 1 1
0 0	0	1	2 2	6 6 7 7
3 5	2	0	8 6 8	2 9 1 3

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 3 of 14)

IC NI	WARNING VALUES (YELLOW LINE)	Critical Values (RED LINE)	EXCEPTION MONITOR MESSAGE	DI STATE CODE
I E NIO OIMT				1///1
I N UIR	OY			1--1
I T M R	NP			1E T
I R B	IIE	UPPER	LOWER	I X A
I Y E	T	LOWER	LIMIT	I P B
I R	IO	LIMIT	LIMIT	I I L
I R	IR	LIMIT	EXPECTED	I D E
10621850				1ON OFF 41 7
10631850				1OFF ON 41 7
10641850				1ON OFF 41 7
10651850				1OFF ON 41 7
10661850				1ON OFF 41 7
10671850				1OFF ON 41 7
10681850				1ON OFF 41 7
10691850				1OFF ON 41 7
10701850				1ON OFF 41 7
10711850				1OFF ON 41 7
10721850				1ON OFF 41 7
10731850				1OFF ON 41 7
10741850				1ON OFF 41 7
10751850				1OFF ON 41 7
10761850				1ON OFF 41 7
10771850				1OFF ON 41 7
10781850				1YES NO 41 7
10791850				1NO YES 41 7
10801850				1YES NO 41 7
10811850				1NO YES 41 7
10821850				1YES NO 41 7
10831850				1NO YES 41 7
10841850				1CLS OPN 41 7
10851850				1OPN CLS 41 7
10861850				1ON OFF 41 7
10871850				1OFF ON 41 7
10881850				1ON OFF 41 7
10891850				1OFF ON 41 7
10901850				1ON OFF 41 7
10911850				1OFF ON 41 7
10921850				1ON OFF 41 7
10931850				1OFF ON 41 7
10941850				1ON OFF 41 7
1	1	1	1	1
0	0	1	2	6
3	5	2	0	7
				7
				8
				8
				3
				2
				6
				6
				8
				9
				1
				1

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 4 of 14)

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 5 of 14)

DI STATE CODE	DI STATE	MESSAGE	MONITOR EXCEPTION	VALUES CRITICAL (RED LINE)	WARNING VALUES (YELLOW LINE)	NI IC	MT O	IN IO	IN UH	IN NP	IT MTR	IR BI	IE I	Y E	R I	O I	I R
141171	OFF	MAIN BUS CURRENT	MAIN EXP BUS	3740	3740	IHI	IEXP	IHI	IEXP	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	ON	VOLTAGE COOL	MAIN BUS VOLTAGE	2396	2396	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	OFF	LOWER HUMIDITY	LOWER ATMOS HUMIDITY	410	819	IHI	IFEA	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	ON	UPPER HUMIDITY	UPPER ATMOS HUMIDITY	410	819	IHI	IFEA	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	OFF	PRESSURE 1 COOL	PRESSURE 1 COOL	1911	887	IHI	IFEA	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	ON	PRESSURE 2 COOL	PRESSURE 2 COOL	1911	887	IHI	IFEA	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	OFF	LOWER ATMOS TEMP	LOWER ATMOS TEMP	2035	1979	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	ON	UPPER ATMOS TEMP	UPPER ATMOS TEMP	2035	1979	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	OFF	WATER INLET TEMP	WATER INLET TEMP	585	585	IHI	IFEA	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	ON	WATER OUTLET TEMP	WATER OUTLET TEMP	907	907	IHI	IFEA	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	OFF	COLD SHELL TEMP	COLD SHELL TEMP	827	907	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	ON	HOT SHELL TEMP	HOT SHELL TEMP	827	907	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	OFF	STEP MTR PHASE A CURRENT	STEP MTR PHASE A CURRENT	2007	2007	IHI	STEP	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	ON	MTR PHASE B CURRENT	MTR PHASE B CURRENT	2163	2163	IHI	STEP	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	OFF	STEP MTR PHASE B VOLTAGE	STEP MTR PHASE B VOLTAGE	2007	2007	IHI	STEP	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	ON	MOTOR TEMP	STEPPER MOTOR TEMP	2163	2163	IHI	STEP	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	OFF	FTS STEPPER TEMP	GUARD HTR CURRENT	1067	1067	IHI	FTS	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	ON	GUARD HTR CURRENT	COLD GUARD HTR VOLTAGE	3003	3003	IHI	GUARD	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	OFF	PRIM HTR CURRENT	COLD PRIM HTR VOLTAGE	1536	1536	IHI	COLD	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
141171	ON	HTR CURRENT	PRIM HTR VOLTAGE	3003	3003	IHI	COLD	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI	IHI
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
0	0	1	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3
3	5	2	0	8	6	6	6	6	6	6	6	6	6	6	6	6	6

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 6 of 14)

IC N	WARNING VALUES (YELLOW LINE)	Critical Values (RED LINE)	Exception Monitor Message	DI STATE CODE
IE MIO OMT IN UIR OY				
IT MIR IR BI IY E R I	INP IE T I R I	UPPER LIMIT LIMIT STATE	UPPER LIMIT LIMIT/ EXPECTED STATE	0= 1= I E IT I P B I I I L I I D E I
I271 850 LS	1536	1536	IHI COLD PRIM HTR VOLTAGE	41 7
I272 850 LS	3003	3003	IHI COLD RED HTR CURRENT	41 7
I273 850 LS	1536	1536	IHI COLD RED HTR VOLTAGE	41 7
I274 850 LS	3003	3003	IHI BOOST HTR CURRENT	41 7
I275 850 LS	3072	3072	IHI BOOST HTR VOLTAGE	41 7
I276 850 LS	3003	3003	IHI HOT GUARD HTR CURRENT	41 7
I277 850 LS	1536	1536	IHI HOT GUARD HTR VOLTAGE	41 7
I278 850 LS	3003	3003	IHI HOT PRIM HTR CURRENT	41 7
I279 850 LS	3072	3072	IHI HOT PRIM HTR VOLTAGE	41 7
I280 850 LS	3003	3003	IHI HOT RED HTR CURRENT	41 7
I281 850 LS	3072	3072	IHI HOT RED HTR VOLTAGE	41 7
I282 850 LS	827	907	IHI CJ TEMP - COLD ZONE #1	41 7
I283 850 LS	827	907	IHI CJ TEMP - COLD ZONE #2	41 7
I284 850 LS	827	907	IHI CJ TEMP - HOT ZONE #1	41 7
I285 850 LS	827	907	IHI CJ TEMP - HOT ZONE #2	41 7
I286 850 LS	827	907	IHI CJ TEMP-SAMPLE 1 SENSOR 1	41 7
I287 850 LS	827	907	IHI CJ TEMP-SAMPLE 1 SENSOR 2	41 7
I288 850 LS	827	907	IHI CJ TEMP-SAMPLE 2 SENSOR 1	41 7
I289 850 LS	827	907	IHI CJ TEMP-SAMPLE 2 SENSOR 2	41 7
I290 850 LS	827	907	IHI CJ TEMP-SAMPLE 3 SENSOR 1	41 7
I291 850 LS	827	907	IHI CJ TEMP-SAMPLE 3 SENSOR 2	41 7
I292 850 LS	827	907	IHI CJ TEMP-SAMPLE 4 SENSOR 1	41 7
I293 850 LS	827	907	IHI CJ TEMP-SAMPLE 4 SENSOR 2	41 7
I294 850 LS	827	907	IHI CJ TEMP-SAMPLE 5 SENSOR 1	41 7
I295 850 LS	827	907	IHI CJ TEMP-SAMPLE 5 SENSOR 2	41 7
I296 850 LS	827	907	IHI CJ TEMP-SAMPLE 6 SENSOR 1	41 7
I297 850 LS	827	907	IHI CJ TEMP-SAMPLE 6 SENSOR 2	41 7
I313 850 LS	987	1227	IHI ALIGN ARM TEMP	41 7
I314 850 LS	827	907	IHI SEM TRACK TEMP	41 7
I465 850				
I466 850				
I467 850				
I468 850				
0 0	1	1	1 1	1 1 1 1
3 5	2	0	2 3 3	6 7 7 8 8
			8 6 8	2 9 1 3

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 7 of 14)

	IC	NI	WARNING VALUES (YELLOW LINE)	Critical Values (RED LINE)	EXCEPTION MONITOR MESSAGE	IDI STATE CODE
IN	N	O	MT	(Y)		
IN	U	R	OY			- - - - -
IT	M	R	INP			E T
IR	B	I	IE	UPPER	LOWER	X A
YE	T	L	LIMIT	LOWER	LIMIT	P B
RI	I	O	LIMIT	LIMIT	EXPECTED	I L
IR	I	R	STATE			ID E
469	1850				NO	141 7
489	1850				OK	FAIL
490	1850				OK	FAIL
491	1850				OK	FAIL
492	1850				OK	FAIL
493	1850				OK	FAIL
494	1850				OK	FAIL
495	1850				OK	FAIL
496	1850				OK	FAIL
497	1850				OK	FAIL
498	1850				OK	FAIL
499	1850				OK	FAIL
500	1850				OK	FAIL
501	1850				OK	FAIL
502	1850				OK	FAIL
503	1850				OK	FAIL
504	1850				OK	FAIL
505	1850				OK	FAIL
506	1850				OK	FAIL
507	1850				OK	FAIL
508	1850				OK	FAIL
509	1850				OK	FAIL
510	1850				OK	FAIL
511	1850				OK	FAIL
512	1850				OK	FAIL
513	1850				OK	FAIL
514	1850				OK	FAIL
515	1850				OK	FAIL
516	1850				OK	FAIL
517	1850				OK	FAIL
518	1850				OK	FAIL
519	1850				OK	FAIL
520	1850				OK	FAIL
	1	1	1	1	1	1
0	0	0	1	2	2	7
3	5	2	2	0	8	6
					6	8
					6	9
					6	1
					6	3
					6	2
					6	8
					6	9
					6	1

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 8 of 14)

IC NI	WARNING VALUES (YELLOW LINE)	Critical Values (RED LINE)	EXCEPTION MONITOR MESSAGE	DI STATE CODE
IN NIO OM				1//1//1
IN UIR	IOY			1//1//1
IT MIR	NP			1//1//1
IR BI	IE	UPPER LOWER	LOWER	E IT
YE	T	LIMIT	LIMIT	X IA
R	O			P IB
	I			I IL
	IR			D IE
1521 850				
1522 850			OK	FAIL 41 7
1523 850			OK	FAIL 41 7
1524 850			OK	FAIL 41 7
1525 850			OK	FAIL 41 7
1526 850			OK	FAIL 41 7
1527 850			OK	FAIL 41 7
1528 850			OK	FAIL 41 7
1529 850			OK	FAIL 41 7
1530 850			OK	FAIL 41 7
1531 850			OK	FAIL 41 7
1532 850			OK	FAIL 41 7
1533 850			OK	FAIL 41 7
1534 850			OK	FAIL 41 7
1535 850			OK	FAIL 41 7
1536 850			OK	FAIL 41 7
1537 850			OK	FAIL 41 7
1538 850			OK	FAIL 41 7
1539 850			OK	FAIL 41 7
1540 850			OK	FAIL 41 7
1541 850			OK	FAIL 41 7
1542 850			OK	FAIL 41 7
1543 850			OK	FAIL 41 7
1544 850			OK	FAIL 41 7
1545 850			OK	FAIL 41 7
1546 850			OK	FAIL 41 7
1547 850			OK	FAIL 41 7
1548 850			OK	FAIL 41 7
1549 850			OK	FAIL 41 7
1550 850			OK	FAIL 41 7
1551 850			OK	FAIL 41 7
1552 850			OK	FAIL 41 7
1553 850			OK	FAIL 41 7
0 0	1	1	1	1 1 1 1 1
3 5	2	0	8	6 6 7 7 8 8
				6 2 9 1 3

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 9 of 14)

IC N	WARNING VALUES (YELLOW LINE)	Critical Values (RED LINE)	EXCEPTION MONITOR MESSAGE	DI STATE CODE
1E NIO OIMT 1E NIO OYI				1= 1= 1= 1= 1=
IN UIR IT MIR				E T I P B I I I D E I
IR BI Y EI	UPPER LIMIT	LOWER LIMIT	LOWER LIMIT / EXPECTED STATE	
R I	IO IR			
1554 18501				FAIL 41171
1555 18501				FAIL 41171
1556 18501				FAIL 41171
1557 18501				FAIL 41171
1558 18501				FAIL 41171
1559 18501				FAIL 41171
1560 18501				FAIL 41171
1561 18501				FAIL 41171
1562 18501				FAIL 41171
1563 18501				FAIL 41171
1564 18501				FAIL 41171
1565 18501				FAIL 41171
1566 18501				FAIL 41171
1567 18501				FAIL 41171
1568 18501				FAIL 41171
1569 18501				FAIL 41171
1570 18501				FAIL 41171
1571 18501				FAIL 41171
1572 18501				FAIL 41171
1573 18501				FAIL 41171
1574 18501				FAIL 41171
1575 18501				FAIL 41171
1576 18501				FAIL 41171
1577 18501				FAIL 41171
1578 18501				FAIL 41171
1579 18501				FAIL 41171
1580 18501				FAIL 41171
1581 18501				FAIL 41171
1582 18501				FAIL 41171
1583 18501				FAIL 41171
1584 18501				FAIL 41171
1585 18501				FAIL 41171
1586 18501				FAIL 41171
				1 1 1 1 1
				6 7 7 8 8
				6 2 9 1 3
				6 6 6 6 6

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 10 of 14)

IC N	WARNING VALUES IE NO O M/T IN U IR	CRITICAL VALUES (YELLOW LINE) IOY	EXCEPTION MONITOR MESSAGE	DI STATE CODE
IT M/R	INP	UPPER LOWER	LIMIT / EXPECTED	0= 1=
IR B/I	IE	LIMIT	LIMIT / EXPECTED	I E T I X A I P B I I L ID E/I
1587 850				
1588 850			OK	FAIL 41 7
1589 850			OK	FAIL 41 7
1590 850			OK	FAIL 41 7
1591 850			OK	FAIL 41 7
1592 850			OK	FAIL 41 7
1593 850			OK	FAIL 41 7
1594 850			OK	FAIL 41 7
1595 850			OK	FAIL 41 7
1596 850			OK	FAIL 41 7
1597 850			OK	FAIL 41 7
1598 850			OK	FAIL 41 7
1599 850			OK	FAIL 41 7
1600 850			OK	FAIL 41 7
1601 850			OK	FAIL 41 7
1602 850			OK	FAIL 41 7
1603 850			OK	FAIL 41 7
1604 850			OK	FAIL 41 7
1605 850			OK	FAIL 41 7
1606 850			OK	FAIL 41 7
1607 850			OK	FAIL 41 7
1608 850			OK	FAIL 41 7
1609 850			OK	FAIL 41 7
1610 850			OK	FAIL 41 7
1611 850			OK	FAIL 41 7
1612 850			OK	FAIL 41 7
1613 850			OK	FAIL 41 7
1614 850			OK	FAIL 41 7
1615 850			OK	FAIL 41 7
1616 850			OK	FAIL 41 7
1617 850			OK	FAIL 41 7
1618 850			OK	FAIL 41 7
1619 850			OK	FAIL 41 7
			1 1	1 1 1 1 1 1
0 0	1	2	3 3	6 6 7 7 8 8
3 5	2	0	6 8	2 9 1 3

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 11 of 14)

IC N	WARNING VALUES (YELLOW LINE)	Critical Values (RED LINE)	EXCEPTION MONITOR MESSAGE	DOI STATE CODE
IE NIO O MFT				1E IT
IN UIR OY				1X A
IT MIR NP				1P B
IR BI IE	UPPER	LOWER	LIMIT /	1T L
Y EI T	LIMIT	LIMIT	EXPECTED	1D IE
R I	IO			
IR I				
1620 1850				1FAIL 141171
1621 1850				1OK 141171
1622 1850				1FAIL 141171
1623 1850				1OK 141171
1624 1850				1FAIL 141171
1625 1850				1OK 141171
1626 1850				1FAIL 141171
1627 1850				1OK 141171
1628 1850				1FAIL 141171
1629 1850				1OK 141171
1630 1850				1FAIL 141171
1631 1850				1OK 141171
1632 1850				1FAIL 141171
1633 1850				1OK 141171
1634 1850				1FAIL 141171
1635 1850				1OK 141171
1636 1850				1FAIL 141171
1637 1850				1OK 141171
1638 1850				1FAIL 141171
1639 1850				1OK 141171
1640 1850				1FAIL 141171
1641 1850				1OK 141171
1642 1850				1FAIL 141171
1643 1850				1OK 141171
1644 1850				1FAIL 141171
1645 1850				1OK 141171
1646 1850				1FAIL 141171
1647 1850				1OK 141171
1648 1850				1FAIL 141171
1649 1850				1OK 141171
1650 1850				1FAIL 141171
1651 1850				1OK 141171
1652 1850				
				1 1 1 1 1
				6 7 7 8 8
				6 2 9 1 3
3 5	2	0	8 6 8	

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 12 of 14)

IC	NI	WARNING VALUES (YELLOW LINE)	Critical Values (RED LINE)			DI STATE CODE	
I	E	NIO	OIMT	IN	UIR	OY	
1653	850						
1654	850						
1655	850						
1656	850						
1657	850						
1658	850						
1659	850						
1660	850						
1661	850						
1662	850						
1663	850						
1664	850						
1665	850						
1666	850						
1667	850						
1668	850						
1669	850						
1670	850						
1671	850						
1672	850						
1673	850						
1674	850						
1675	850						
1676	850						
1677	850						
1678	850						
1679	850						
1680	850						
1681	850						
1682	850						
1683	850						
1684	850						
1685	850						
0	0	1	1	1	2	2	1
3	5	2	0	8	0	8	1
6	6	6	6	8	8	8	3
6	2	9	6	2	7	7	2
6	6	9	6	8	8	8	3

TABLE 1.7.5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 13 of 14)

IC	N	O	M	T	WARNING VALUES (YELLOW LINE)	Critical Values (RED LINE)	EXCEPTION MONITOR MESSAGE	IDI STATE CODE
I	E	N	O	I	MT			
I	E	N	O	I	Y			- - - - -
I	N	U	R	I	Y			
I	T	M	R	I	Y			
I	R	B	I	E	Y			
I	R	B	I	E	T			
I	R	I	I	E	L			
I	R	I	I	O	L			
I	R	I	I	R	S			
686	1850						0 =	E T
687	1850						1 =	X A
688	1850							P B
689	1850							I L
690	1850							D E
691	1850							
692	1850							
693	1850							
694	1850							
695	1850							
696	1850							
697	1850							
698	1850							
699	1850							
700	1850							
701	1850							
702	1850							
703	1850							
704	1850							
705	1850							
706	1850							
707	1850							
708	1850							
709	1850							
710	1850							
711	1850							
712	1850							
713	1850							
714	1850							
715	1850							
716	1850							
717	1850							
718	1850							

TABLE 1.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 14 of 14)

C	N	WARNING VALUES IE NO O MT IN UIR		CRITICAL VALUES (YELLOW LINE) I OY		DI STATE CODE	
I	T	MIR		NP		---	
R	B	IE	UPPER	LOWER	EXCEPTION MONITOR MESSAGE	0=	1=
I	E	T	LIMIT	LIMIT	LIMIT/ EXPECTED	X IA	E IT
R	O	I				IP IB	IP IB
I	R	I				I I LI	I I LI
			STATE			ID IE	ID IE
1719	1850	1				OK	FAIL 7
1720	1850	1				OK	FAIL 7
1721	1850	1				OK	FAIL 7
1722	1850	1				OK	FAIL 7
1723	1850	1				OK	FAIL 7
1724	1850	1				OK	FAIL 7
1725	1850	1				OK	FAIL 7
1726	1850	1				OK	FAIL 7
1727	1850	1				OK	FAIL 7
1728	1850	1				OK	FAIL 7
1729	1850	1				OK	FAIL 7
1730	1850	1				OK	FAIL 7
1731	1850	1				OK	FAIL 7
1732	1850	1				OK	FAIL 7
1733	1850	1				OK	FAIL 7
1734	1850	1				OK	FAIL 7
1735	1850	1				OK	FAIL 7
1736	1850	1				OK	FAIL 7
1737	1850	1				OK	FAIL 7
1738	1850	1				OK	FAIL 7
1739	1850	1				OK	FAIL 7
1740	1850	1				OK	FAIL 7
1741	1850	1				OK	FAIL 7
1742	1850	1				OK	FAIL 7
1743	1850	1				OK	FAIL 7
1744	1850	1				OK	FAIL 7
1745	1850	1				OK	FAIL 7
1746	1850	1				OK	FAIL 7
1747	1850	1				OK	FAIL 7
1748	1850	1				OK	FAIL 7
1749	1850	1				OK	FAIL 7
1750	1850	1				OK	FAIL 7
1264	1851	1				IRUN	WAIT 7
1266	1851	1				INO	YES 42 7
		1	1	1	1	1	1
		0	0	2	2	6	6
		3	5	0	8	7	2
						7	9
						8	1
						9	3

1.8. FLIGHT SOFTWARE REQUIREMENTS

This section of the Experiment/Facility Requirements Document (E/FRD) defines the Space Station Freedom (SSF) Data Management System (DMS) software functions required to support the Space Station Furnace Facility (SSFF).

The SSFF Core Control Unit (CCU) software will interface to the SSF Payload Executive Software (PES) for DMS services and executive-level control. The SSFF Furnace Control Unit (FCU) and Furnace Actuator Unit (FAU) software provides networking, data processing, storage, and data acquisition and control for Furnace Module-1. The SSFF software external interface diagram is shown in Figure 1.8-1. The SSFF software component tree is shown in Figure 1.8-2. These components will reside in the DMS hardware. The following subsections define the required resources and data handling requirements.

1.8.1 COMMAND SUPPORT

The SSF via the PES software will support the issuance of commands and SSFF activation given by the ground, onboard crew, or Tier 1.

1.8.2 HEALTH AND STATUS DATA

The PES will acquire health and status data from the SSFF and distribute it to Tier 1 on board and to the Payload Operations Integration Center (POIC) on the ground.

1.8.3 ONBOARD STORAGE

The SSF will provide storage for SSFF and/or Furnace Module-1 program loads, operations, status, and science data.

1.8.4 DISPLAY

The SSF multipurpose application console (MPAC) will provide backup support of the SSFF crew interface for onboard SSFF configuration and preparations for Furnace Module-1 experiment operations.

1.8.5 PROGRAM LOADS AND MODIFICATIONS DOWNLOADING

The SSF software shall support the downloading of SSFF program loads and modifications.

1.8.6 ANCILLARY DATA

The SSF shall support requests for ancillary data.




FIGURE 1.8-1. SSFF SOFTWARE EXTERNAL INTERFACE DIAGRAM





FIGURE 1.8-2. SOFTWARE COMPONENT TREE



1.9. PHYSICAL INTEGRATION

1.9.1 RACK INTEGRATION AND CHECKOUT

Physical integration during prelaunch consists of checkout and integration of Furnace Module-1, the individual Core Rack and Experiment Rack-1, and finally the SSFF as an integrated system. Interfaces are progressively verified as the buildup of the Space Station Furnace Facility (SSFF) is performed. Following shipment to Kennedy Space Center (KSC), the facility is visually checked for physical integrity, and a limited functional test is performed to ensure operability and Space Station Freedom (SSF) interface compatibility. The prelaunch activities flow is shown in Figure 1.9-1. Table 1.9-1 provides the integration facility requirements for each stage of integration. Table 1.9-2 describes the requirements and activities at each step of the integration process.

1.9.1.1 Core Rack Checkout

Tests, using the appropriate ground support equipment (GSE) including SSF and experiment rack interface simulators, will be performed to verify proper operations of the Core Rack. Testing will include operation of each SSFF subsystem and component to its operational limits, and an integrated SSFF exercising each of the interface functions, through the use of simulators, with the SSF and the experiment rack.

1.9.1.2 Experiment Rack-1 Checkout

The pre-experiment rack checkout will consist of verifying the performance of the SSFF distributed subsystems in Experiment Rack-1 and its interfaces to the Core Rack and Furnace Module-1.

1.9.1.3 Furnace Module-1 Checkout

Furnace Module-1 tests will be used to verify the performance to operational limits with the exception that heater limits will only be to the extent that they prove operability. The Furnace Module-1 interface to Experiment Rack-1 will be verified through the functional performance tests and the physical connects of the experiment rack simulator.

1.9.1.4 Integrated Furnace Rack Checkout

Following integration of Furnace Module-1 into Experiment Rack-1, the rack performance and interfaces will be verified using a Core Rack simulator and test set. Tests will be limited to only those required to verify Furnace Module-1 to Experiment Rack-1 interfaces.




FIGURE 1.9-1. PHYSICAL INTEGRATION FLOW

TABLE 1.9-1. SSFF INTEGRATION GROUND PROCESSING REQUIREMENTS

- (X) Experiment/Facility Preintegration
 () Experiment/Facility Preparation
 () Postmission Requirements

Description of Planned Activities:**Rack Integration, Rack Functional Tests, SSFF Systems Integrated Tests**Total Floor Space Required Including Space for GSE: 2000 ft²Ceiling Height Required: 10 ftOverhead Crane Required: X Yes No Hook Height 8 ftFacility Power Required: X 120 V, 1 F, 60 Hz
 208 V, 3 F, 60 Hz
 OtherOther Facility Support: Gases X GN₂ Liquids Single Phase
 GHe Precooled
 GAr Other H₂OEnvironment: X Standard OtherHazardous Operations: Yes X NoTotal Anticipated Use Time: 45 Days**Other Facility Support Description:****GSE Test sets including the following interface simulators:**

- * Furnace Module-to-Experiment
- * Core Rack-to-Experiment Rack
- * Experiment Rack-to-Core Rack
- * SSF-to-Core Rack
- * Experiment Rack Subsystem-to-Furnace Module

TABLE 1.9-2. SSFF INTEGRATION REQUIREMENTS

Description of Special Alignment, Calibration, Servicing, or Performance Verification and Estimated Time to Perform:

- * Vent & Purge test of Furnace Module-1 - 60 min
- * Calibration of Analog Sensors - 90 min

Identification of Any Constraints on Experiment/Facility Operations During Tests:

None Identified

Description of Time-Critical Operations and Time Constraints:

None Identified

1.9.1.5 SSFF Facility Checkout

Following checkout of the individual racks, an overall SSFF integrated systems test will be performed. Tests will be limited to verify Core Rack-to-Experiment Rack-1 interfaces and to SSF.

1.9.2 KSC VERIFICATION

Physical integration at KSC will be limited to receiving/inspection of the SSFF hardware complement and to reverification of the physical and functional interfaces with the SSF.

1.9.3 POSTLANDING

Postlanding activities consist of the following: (1) Removing the SSFF equipment and experiment samples from the returning Mini-Pressurized Logistics Module (MPLM); (2) returning the Furnace Module-1 samples to the Payload Investigator; (3) removing the Furnace Module-1 from Experiment Rack-1 and returning it to the PED; and (4) refurbishing Experiment Rack-1. These activities are shown in Table 1.9-3 and Figure 1.9-2.

TABLE 1.9-3. SSFF POSTLANDING GROUND PROCESSING REQUIREMENTS

- () Experiment/Facility Preintegration
 () Experiment/Facility Preparation
 (X) Postmission Requirements

Description of Planned Activities:

Remove flight samples from stowage and return to Experimenter.
 Remove flight rack from MPLM.
 Remove furnace module from experiment rack and return to PED.
 Move experiment rack to the rack refurb area and refurbish experiment rack.
 Ship rack to the rack integration and checkout area.

Total Floor Space Required Including Space for GSE: 2000 ft²

Ceiling Height Required: 10 ft

Overhead Crane Required: X Yes No Hook Height 8 ft

Facility Power Required:

_____	120 V, 1 F, 60 Hz N/A
_____	208 V, 3 F, 60 Hz
_____	Other

Other Facility Support: Gases N/A _____ GN₂ Liquids N / A
 _____ GHe _____
 _____ Other _____

Environment: X Standard _____ Other

Hazardous Operations: _____ Yes X No

Total Anticipated Use Time: 3 Days

Other Facility Support Description:

Module shipping container
 Rack shipping container
 Rack rotation stand





FIGURE 1.9-2. PHYSICAL DEINTEGRATION FLOW



1.10. OPERATIONS SUPPORT

Table 1.10-1 describes the physical and operational support required at the Ground Science Operations Control Center during flight of the Space Station Furnace Facility (SSFF).

TABLE 1.10-1. SSFF MISSION OPERATIONS SUPPORT

COMMUNICATIONS REQUIREMENTS:**Downlink Data**

TBD

Uplink Commands/data

TBD

Voice Communications

TBD

Video

TBD

SUPPORT EQUIPMENT:**Description**

TBD

Dimensions

TBD

Power Requirements

TBD

Data Interface

TBD

REMOTE SITE INTERFACE**Location**

TBD

Describe interfaces

TBD

1.11. TRAINING OBJECTIVES

Table 1.11-1 correlates the training requirements with the appropriate trainees and trainers, and identifies the source of the training requirements. Table 1.11-2 summarizes the requirements for each training objective.

TABLE 1.11-1. TRAINING PARTICIPATION

-PED/PI Defined	Training Objectives	Trainee	Trainer
TBD			
	-PAM and PED/PI Jointly Defined		
		TBD	
			-PAM Defined
			TBD

TABLE 1.11-2. TRAINING OBJECTIVES (Sheet 1 of 4)

NO.	TRAINING OBJECTIVE	TRAIINEE	RESPON-SIBILITY	SIMULATOR			COMMENTS
				FIDELITY	Y/N	H/W	
1.0	SCIENCE BACKGROUND			PED/PI	N		
1.1	Present science basis and significance of the SSFF	payload crew, cadre	PED/PI	PED/PI	N		
1.2	Present operational objectives	payload crew, cadre	PED/PI	PED/PI	N		
1.3	Present SSFF operational theory	payload crew, cadre	PED/PI	PED/PI	N		
1.4	Present operations philosophy	payload crew, cadre	PED/PI	PED/PI	N		
2.0	SSFF SYSTEMS FAMILIARIZATION			PED/PI	Y		PED/PI
2.1	Characterize the SSFF hardware elements	payload crew, cadre			a	Y	
2.1.1	Rack location of the FM-1, rack location of the Core						
2.1.2	FM-1 and subsystem components						
2.1.3	Module stowage						
2.1.4	DMS						

TABLE 1.11-2. TRAINING OBJECTIVES (Sheet 2 of 4)

NO.	TRAINING OBJECTIVE	TRAINEE	RESPON-SIBILITY	SIMULATOR			COMMENTS
				Y/N	H/W	S/W	
				FIDELITY	Y/N	PED/PI	
2.2	Characterize FM-1 software associated with the following:	payload crew, cadre	PED/PI	Y	a	Y	PED/PI
2.2.1	DMS						
2.2.2	FM-1 command capabilities						
2.2.3	In-flight computer requirements						
2.2.4	Timeline requirements						
2.2.5	Furnace Control Units						
2.3	Characterize FM-1 data collection	payload crew, cadre	PED/PI	Y	a	Y	PED/PI
2.3.1	Onboard routing/recording						
2.3.2	Downlink data and voice						
2.4	Characterize FM-1 GSE	payload crew, cadre	PED/PI	Y	a	Y	PED/PI
2.5	Characterize SSF interface	payload crew, cadre	PED/PI	Y	a	Y	PED/PI
2.5.1	Power, fluids, and thermal interfaces						
2.6	Characterize the following SSFF operational requirements and constraints:	payload crew, cadre	PED/PI	Y			PED/PI
2.6.1	Specific attitudes or conditions						
2.6.2	Microgravity requirements (limiting crew motion and g-level constraints)						

TABLE 1.11-2. TRAINING OBJECTIVES (Sheet 3 of 4)

NO.	TRAINING OBJECTIVE	TRAINEE	RESPON-SIBILITY	SIMULATOR		PROVIDER	COMMENTS		
				Y/N	H/W	S/W	FIDELITY	Y/N	
3.0	FM-1 OPS FAMILIARIZATION								
3.1	Characterize FM-1 nominal operating procedures	payload crew, cadre	PED/PI						PED/PI
3.1.1	Power on								
3.1.2	Sample changeout								
3.1.3	Power off								
3.1.4	FM-1 sailing and stowage								
4.0	FM-1 PROFICIENCY OBJECTIVES								
4.1	Provide proficiency training in FM-1 operations	payload crew, cadre	PI/PAM	Y					PED/PI/PAM
4.2	Characterize malfunction/ alternate procedures including fault definition	payload crew, cadre	PI/PAM	Y					PED/PI/PAM
5.0	INTEGRATED TIMELINE PROFICIENCY								
5.1	Provide additional proficiency training in FM-1 ops as it relates to the joint operations	payload crew, cadre	PI/PAM	Y					PED/PI/PAM
5.2	Provide additional training as it pertains to off-nominal procedures for joint operations	payload crew, cadre	PI/PAM	Y					PED/PI/PAM
5.3	Provide proficiency training in integrated FM-1 ops including hardware/software, SSF/Orbiter/PI interfaces	payload crew, cadre	PI/PAM	Y					PED/PI/PAM

TABLE 1.11-2. TRAINING OBJECTIVES (Sheet 4 of 4)

NO.	TRAINING OBJECTIVE	TRAIINEE	RESPON-SIBILITY	SIMULATOR			PROVIDER	COMMENTS
				Y/N	H/W	S/W		
6.0	SIMULATIONS	payload crew, cadre	PAM	Y			PED/Pi/ PAM	
6.1	Conduct MSFC simulations in order to develop proficiency in the following: console operations, handover, voice protocols, crew/cadre/MCC interfaces, integrated payload operations, STS/SSF payload contingency operations							
6.2	Conduct joint integrated simulations in order to demonstrate proficiency in the following: console positions, handover, voice protocols, crew/cadre/MCC interfaces, payload operations, furnace contingency operations, data retrieval systems, operational interfaces between ground control facilities, mission flight rules							
7.0	MISSION-INDEPENDENT TRAINING							
7.1	Provide STS/SSF mission-independent training	payload crew					PAM/JSC	
7.2	Provide mission-independent training	cadrePi/Sim Team					PAM	N

1.12. ENVIRONMENTAL CONTAMINATION DATA REQUIREMENTS

Tables 1.12-1 and 1.12-2 illustrate the environmental contamination data requirements for the Space Station Furnace Facility (SSFF).

TABLE 1.12-1. FLIGHT ENVIRONMENT LIMITS

SENSITIVITY LIMIT		EXPERIMENT GENERATED				NON-OPERATING	
OPERATING	NON-OPERATING	OPERATING				NON-OPERATING	
MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX
PARTICULATES Size (micrometers)							
Number/m ³							
Composition							
GASES Composition							
Concentration							
Pressure (kN/m ²)							

PARTICULATES Size (micrometers)
 Number/m³ • <1 micron normal operations
 • 0.1 to 50 microns following filter changeout
 • <1,000 normal operations
 • <100,000 following filter changeout
 Composition • Ceramic fibers, copper, steel, platinum, wire insulation, organic particles, and sample-sourced materials, including molybdenum, boron nitride, nickel alloys, quartz, silica, and semiconductor materials

GASES Composition
 Cabin air, or Inert pressurant with cleaning solvents and/or water contaminant

Concentration
Pressure (kN/m²)
 TBD • <101.3 for experiment venting
 • 66.7 for vent of inert pressurants

TABLE 1.12-2. EXTERNAL CONTAMINATION SOURCES

Does experiment/facility release (vent, purge) any material overboard on orbit?
Yes _____ No X

PARAMETER	DESCRIPTION
FOs of Occurrence	
Frequency	.
Duration	
Composition	
Phase State (solid, liquid, or gas)	
Quantity or Rate of Release	



DATA REQUIREMENT (DR) - 10

**EXPERIMENT/FACILITY REQUIREMENTS DOCUMENT FOR THE
SPACE STATION FURNACE FACILITY**

SECTION 2: FURNACE MODULE-1 INPUT

MAY 1992



FOREWORD

The Space Station Furnace Facility (SSFF) Core is designed to accommodate and support a variety of furnace modules throughout the operational lifetime of the facility. Since the SSFF will be operational for 30 years, and various furnace modules will be accommodated, the Experiment/Facility Requirements Document (E/FRD) is divided into two separate sections. Section 1 describes the integrated SSFF-to-SSF interface, which includes the SSFF Core subsystem requirements and the furnace module requirements based on the information obtained from the Furnace Developer's Section 2, and Section 2 describes the furnace module-to-SSFF interface. Multiple Section 2s may be required for each E/FRD, depending on how many furnace modules the SSFF will accommodate per mission, since a separate Section 2 will be written for each furnace module. Both sections will be replaced for each mission with the appropriate mission-peculiar furnace module and interface requirements.

This section describes the Furnace Module-1 requirements. Furnace Module-1 is scheduled to be an upgrade of the present Crystal Growth Furnace (CGF), and this section reflects the requirements of that module.



TABLE OF CONTENTS

<u>SECTION</u>	<u>TITLE</u>	<u>PAGE</u>
2.1	FUNCTIONAL OBJECTIVES AND EQUIPMENT IDENTIFICATION	2.1-1
2.1.1	System Description.....	2.1-1
2.1.2	Functional Objectives	2.1-3
2.1.3	Equipment Identification.....	2.1-3
2.1.4	Operational Functional Flows.....	2.1-3
2.2	STRUCTURAL/MECHANICAL	2.2-1
2.2.1	Equipment List and Mass Properties	2.2-1
2.2.2	Interface Detail	2.2-1
2.2.2.1	Furnace Module-1 to SSFF Experiment Rack-1 Interface	2.2-1
2.2.2.2	Furnace Module-1 Cooling Jacket-to-SSFF TCS.....	2.2-1
2.2.2.3	Furnace Module-1 Electrical Connection-to-SSFF PCDS	2.2-5
2.2.2.4	Furnace Module-1 to SSFF-Supplied Argon and Nitrogen.....	2.2-5
2.2.2.5	Furnace Module-1 to SSFF-Supplied Vacuum Vent.....	2.2-5
2.2.2.6	Furnace Module-1 DMS Connections-to-SSFF DMS.....	2.2-5
2.2.2.7	Furnace Module-1 Software-to-SSFF Software	2.2-5
2.2.2.8	Furnace Module-1 to Crew Interface	2.2-5
2.3	POINTING/STABILIZATION AND ALIGNMENT	2.3-1
2.4	ORBITAL REQUIREMENTS AND CONSTRAINTS	2.4-1
2.5	ELECTRICAL REQUIREMENTS	2.5-1
2.6	THERMAL/FLUID REQUIREMENTS	2.6-1
2.6.1	Heat Transfer Characteristics.....	2.6-1
2.6.2	Fluid/Vent Requirements	2.6-1
2.7	DATA SYSTEM REQUIREMENTS	2.7-1
2.7.1	Signal Interface Definition.....	2.7-1
2.7.2	Signal Interface Definition Expansion	2.7-1
2.7.3	Event/Exception Monitoring Requirements	2.7-1
2.7.4	POIC Display Requirements	2.7-1
2.7.5	POIC Limit Sensing/Exception Monitoring Requirements	2.7-1
2.8	FLIGHT SOFTWARE REQUIREMENTS	2.8-1
2.8.1	Command Support	2.8-1
2.8.2	Data Acquisition	2.8-1
2.8.3	Data Processing.....	2.8-1
2.8.4	Data Routing/Formatting	2.8-1
2.8.5	Downloading Application Software and Data	2.8-1
2.8.6	Downloading Ancillary Data	2.8-1

TABLE OF CONTENTS (Cont.)

<u>SECTION</u>	<u>TITLE</u>	<u>PAGE</u>
2.8.7	FDIR Support.....	2.8-1
2.8.8	Operating System Services	2.8-2
2.8.9	Health and Status Data	2.8-2
2.9	PHYSICAL INTEGRATION	2.9-1
2.10	OPERATIONS SUPPORT	2.10-1
2.11	TRAINING OBJECTIVES	2.11-1
2.11.1	PI/PED Defined Training	2.11-1
2.11.2	PIM and PI/PED Jointly Defined Training	2.11-4
2.11.3	PIM Defined Training.....	2.11-6
2.11.3.1	Increment Independent Training - Crew.....	2.11-6
2.11.3.2	Increment Independent Training - PI/PED Team.....	2.11-6
2.11.3.3	Increment Independent Training - POIC Cadre.....	2.11-6
2.11.4	Training Simulation	2.11-6
2.11.5	Training Participation	2.11-7
2.12	ENVIRONMENTAL CONTAMINATION DATA REQUIREMENTS	2.12-1

LIST OF FIGURES

<u>FIGURE</u>	<u>TITLE</u>	<u>PAGE</u>
2.1-1	Furnace Module-1 Pictorial Representation	2.1-2
2.1-2	Furnace Module-1 Component Tree	2.1-20
2.1-3	Furnace Module-1 to SSFF/SSF Interface Diagram	2.1-21
2.2-1	Furnace Module-1 EAC Connector Locations	2.2-4
2.5-1	Power Profiles by FOs	2.5-2
2.9-1	Physical Integration Flow	2.9-2

LIST OF TABLES

<u>TABLE</u>	<u>TITLE</u>	<u>PAGE</u>
2.1-1	Furnace Module-1 Functional Objectives.....	2.1-4
2.1-2	Functional Objective Requirements Sheets	2.1-7
2.1-3	Furnace Module-1 Operational Functional Flow.....	2.1-22
2.2-1	List of Equipment Properties	2.2-2
2.2-2	Furnace Module-1 Stowage List.....	2.2-3
2.6-1	On-Orbit Thermal Requirements	2.6-2
2.6-2	Fluid Requirements.....	2.6-3
2.7-1	Signal Interface Definition	2.7-2
2.7-2	Signal Interface Definition Expansion.....	2.7-3
2.7-3	Event/Exception Monitoring.....	2.7-41
2.7-4	POIC Display Requirements	2.7-42
2.7-5	POIC Limit Sensing/Exception Monitor Requirements	2.7-62
2.9-1	Furnace Module-1 Ground Processing Requirements.....	2.9-3
2.9-2	Furnace Module-1 Integration Requirements.....	2.9-5
2.10-1	Furnace Module-1 Mission Operations Support	2.10-2
2.11-1	Training Participation	2.11-2
2.11-2	Furnace Module-1 Training Objectives.....	2.11-3
2.11-3	Knowledge Levels.....	2.11-5
2.11-4	Skill Proficiency Levels.....	2.11-5
2.12-1	Flight Environmental Limits.....	2.12-3
2.12-2	External Contamination Sources	2.12-3
2.12-3	On-Orbit External Contamination Control Sensitivity	2.12-4

2.1. FUNCTIONAL OBJECTIVES AND EQUIPMENT IDENTIFICATION

2.1.1. SYSTEM DESCRIPTION

The function of Furnace Module-1 is to grow crystals of semiconductor materials and metal and alloys using the directional solidification and vapor transport crystal growth techniques in a microgravity environment (at temperatures up to 1600 °C). Directional solidification is achieved by melting the sample and solidifying the same while applying a thermal gradient along the longitudinal axis of the sample and translating the furnace or the sample. In the case of Furnace Module-1, the furnace is translated.

The Furnace Module-1 system is shown in Figure 2.1-1. It consists of the following primary elements: the Sample Ampoule/Cartridge Assembly (SACA), the base ring, and the experiment apparatus container (EAC) in which the reconfigurable furnace module (RFM), the furnace translation mechanism (FTM), the sample exchange mechanism (SEM), the sample insertion port (SIP) and the internal support structure (ISS) are housed. The ISS, in addition to providing the structural support for the RFM, the FTM, and attach hardware for the plumbing, provides an interface for the SEM which will have the capability to hold up to six sample ampoules. The bottom section of the EAC is attached to the base ring, which includes the feedthroughs for power, data, fluid, and vent lines.

The Space Station Furnace Facility (SSFF) Thermal Control Subsystem (TCS) water loop will provide cooling for the RFM outer shell, the FTS stepping motor, and the SEM ampoule holding head.

The SSFF Gas Distribution Subsystem (GDS) will supply argon and nitrogen to the EAC in order to provide an inert processing atmosphere for crystal growth.

The SACA consists of a sealed ampoule in which the experiment sample material is contained. The SACA accommodates up to six sample thermocouples and has interfaces for sample ampoule/cartridge failure detection sensors.

At least three levels of containment will be provided during sample processing: The SACA, negative ΔP inside the EAC during processing, and the EAC.

At least two levels of containment will be provided during manual sample exchange: The SACA and the flexible glovebox container.

Multiple purge/vent/backfill will be performed prior to manual sample exchange. In addition, a view port is provided on the EAC for visual inspection of the sample ampoules by a crew-member. It is also planned to mount mirrored witness plates inside the EAC to augment




FIGURE 2.1-1. FURNACE MODULE-1 PICTORIAL REPRESENTATION

visual inspection for detecting any vapor deposition that may have resulted from the sample ampoule/cartridge failure. The design will be compatible with the SSFF.

2.1.2 FUNCTIONAL OBJECTIVES

There are nine functional objectives (FOs) for Furnace Module-1 which are structured as one FO for sample exchange, one FO for venting and purging, five FOs for sample processing, one FO for sample loading or shutdown, and one FO for calibration/bakeout. The actual FO numbering is as follows:

- FO-3 Furnace Module-1 Sample Exchange
- FO-4 Furnace Module-1 Vent/Purge
- FO-5 Furnace Module-1 Process Sample HgCdTe
- FO-6 Furnace Module-1 Process Sample HgZnTe
- FO-6A Furnace Module-1 Process Sample Extended HgZnTe
- FO-7 Furnace Module-1 Process Sample CdTe
- FO-8 Furnace Module-1 Process Sample GaAs
- FO-9 Configure Furnace Module-1 for Sample Loading or Shutdown
- FO-11 Furnace Module-1 Process Calibration/Bakeout

Table 2.1-1 shows a listing of the Furnace Module-1 FOs along with the equipment associated with each step of each FO. Step duration, crew time requirements, and average power requirements for each step of each FO are defined in Table 2.1-2, Functional Objective Requirements Sheets.

2.1.3 EQUIPMENT IDENTIFICATION

Figure 2.1-2 identifies the Furnace Module-1 components in a block diagram format. Figure 2.1-3 identifies the Furnace Module-1 to SSFF interfaces.

2.1.4 OPERATIONAL FUNCTIONAL FLOWS

Preliminary functional flows are shown in Table 2.1-3 for each FO. Functional flows define the function performed, the performing element, and decisions involved in accomplishing each FO.

TABLE 2.1-1. FURNACE MODULE-1 FUNCTIONAL OBJECTIVES (Sheet 1 of 3)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-3	Manual Sample Exchange	Crew Interaction Required
Step 1	Command Manual Exchange	DMS
Step 2	Vent/Fill EAC	GDS
Step 3	Equalize EAC Pressure	GDS, DMS
Step 4	Prep Equipment	
Step 5	Open SIP	EAC
Step 6	Insert Samples	EAC
Step 7	Close Sip	EAC
Step 8	Open Valves	
Step 9	Command Man. Exchange Off	DMS
Step 10	Perform Seal Check	DMS, GDS
Step 11	Load List process	DMS
FO-4	Purge EAC	
Step 1	GN ₂ Purge Furnace	DMS, GDS
Step 2	Argon Backfill	DMS, GDS
Step 3	Command Sample Process	DMS
Step 4	TCS Configured	TCS
FO-5	Vapor Crystal Growth of HgCdTe	
Step 1	Activate Furnace for Processing	GDS, TCS, DMS
Step 2	Activate and Process Heat Cycle	GDS, TCS, DMS
Step 3	Anneal Sample	GDS, TCS, DMS
Step 4	Initiate Vapor Crystal Growth Processing	GDS, TCS, DMS
Step 5	Cool Sample and Extract	GDS, TCS, DMS
Step 6	Cool and Stow	

TABLE 2.1-1. FURNACE MODULE-1 FUNCTIONAL OBJECTIVES (Sheet 2 of 3)

FUNCTIONAL OBJECTIVE		EQUIPMENT REQUIRED
NUMBER	TITLE	ITEM
FO-6	Meltback and Regrowth of HgZnTe	
Step 1	Activate Furnace for Processing	GDS, TCS, DMS
Step 2	Process Heat Cycle	GDS, TCS, DMS
Step 3	Initial Soak	GDS, TCS, DMS
Step 4	Translation to Growth Position	GDS, TCS, DMS
Step 5	Final Soak	GDS, TCS, DMS
Step 6	Directional Solidification	GDS, TCS, DMS
Step 7	Cool Sample	GDS, TCS, DMS
Step 8	Stow Sample	GDS, TCS, DMS
FO-6A	Meltback and Regrowth of HgZnTe (extended)	
Step 1	Activate Furnace for Processing	GDS, TCS, DMS
Step 2	Process Heat Cycle	GDS, TCS, DMS
Step 3	Initial Soak	GDS, TCS, DMS
Step 4	Translation to Growth Position	GDS, TCS, DMS
Step 5	Final Soak	GDS, TCS, DMS
Step 6	Directional Solidification	GDS, TCS, DMS
Step 7	Cool Sample	GDS, TCS, DMS
Step 8	Stow Sample	GDS, TCS, DMS
FO-7	Growth of CdTe by Dir. Solidification	
Step 1	Activate Furnace for Processing	GDS, TCS, DMS
Step 2	Process Heat Cycle	GDS, TCS, DMS
Step 3	Soak	GDS, TCS, DMS
Step 4	Process Sample, Directional Solidification	GDS, TCS, DMS
Step 5	Cool Sample to 400 °C	GDS, TCS, DMS
Step 6	Cool Sample to 200 °C and Stow Sample	GDS, TCS, DMS

TABLE 2.1-1. FURNACE MODULE-1 FUNCTIONAL OBJECTIVES (Sheet 3 of 3)

NUMBER	FUNCTIONAL OBJECTIVE	EQUIPMENT REQUIRED
	TITLE	ITEM
FO-8	Growth of GaAs by Dir. Solidification	
Step 1	Activate Furnace Processing	GDS, TCS, DMS
Step 2	Preheat Cycle	GDS, TCS, DMS
Step 3	Process Heat Cycle	GDS, TCS, DMS
Step 4	Soak	GDS, TCS, DMS
Step 5	Translate Furnace/Process Sample	GDS, TCS, DMS
Step 6	Cool Down to 800 °C	GDS, TCS, DMS
Step 7	Cool Down to 200 °C and Stow	GDS, TCS, DMS
FO-9	Configure Furnace for Shutdown/Sample Loading	
Step 1	Verify Furnace Is in Home Position	DMS
Step 2	Furnace Specific Tests	DMS
Step 3	Secure Power From Furnace Module	DMS
FO-11	Furnace Calibration/Bakeout	
Step 1	Activate Calibration/Bakeout	DMS
Step 2	Initiate Calibration	DMS
Step 3	Bakeout/Calibration Process	DMS

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 1 of 13)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>		FO NUMBER: <u>3</u>					
FO NAME: <u>Manual Sample Exchange</u>		PREREQUISITE: <u>FO-2</u>					
NO. OF PERFORMANCES: MIN. _____ DES. _____		SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____		JOINT OPS WITH: _____					
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	1:00	32:00	10:00	10:00	7:00	20:00
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED	1		1	1	1	1
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		0	0	0	0	0	0
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DOWNLINK DIGITAL (MBPS)						
	REALTIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POCC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Command "Manual Sample Exchange" on						
2	Vent/fill furnace module						
3	Equalize furnace module pressure						
4	Prep equipment						
5	Open SIP						
6	Insert samples						

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 2 of 13)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>3</u>						
FO NAME: <u>Manual Sample Exchange</u>	PREREQUISITE: <u>FO-2</u>						
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____						
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____						
STEP NUMBER		7	8	9	10	11	
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	3:00	3:00	1:00	65:00	4:00	
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED	1	1	1	1	1	
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		0	0	0	0	0	
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DOWNLINK DIGITAL (MBPS)						
	REALTIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POCC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
7	Close SIP						
8	Open valves						
9	Command "Manual Sample Exchange" off						
10	Perform seal check						
11	Load list process						

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 3 of 13)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>			FO NUMBER: <u>4</u>					
FO NAME: <u>Purge Furnace Module</u>			PREREQUISITE: <u>FO-3</u>					
NO. OF PERFORMANCES: MIN. _____ DES. _____			SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____			JOINT OPS WITH: _____					
STEP NUMBER		1	2	3	4	5	6	
STEP DURATION (MINS:SECS)		MINIMUM						
		MAXIMUM						
		PREFERRED	32:00	10:00	2:00	2:00		
STEP DELAY (HRS:MINS)		MINIMUM						
		MAXIMUM						
		PREFERRED						
CREW		NUMBER						
		PREFERRED						
MICROGRAVITY (g's)								
VACUUM VENT								
CONSUMABLES								
AVERAGE POWER REQUIRED (kW)		0	0	0	0			
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS							
	EXPERIMENT APPLICATIONS							
DATA	DLINK DIGITAL (MBPS)							
	REALTIME (RT) OR DUMP (D)							
	COMMANDING							
	PES (P), ISE (I), MPAC (M), POCC (PC)							
	VIDEO STANDARD/NONSTANDARD NTSC							
	REAL-TIME/DUMP/STORE							
SPECIAL EQUIPMENT OR CONSTRAINTS								
STEP NO.		STEP DESCRIPTION						
1	GN2 purge furnace							
2	Argon backfill							
3	Command sample process							
4	TCS configured							

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 4 of 13)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>5</u>						
FO NAME: <u>Vapor Crystal Growth of HgCdTe</u>	PREREQUISITE: <u>FO-3</u>						
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____						
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____						
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	3:00	188:00	60:00	480:00	240:00	21:00
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		.120	1.116	.466	.466	.120	.120
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DLINK DIGITAL (MBPS)						
	REALTIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POCC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Activate furnace for processing						
2	Activate and process heat cycle						
3	Anneal sample						
4	Initiate vapor crystal growth processing						
5	Cool sample and extract						
6	Cool and stow						

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 5 of 13)

<u>EXPERIMENT NAME: Space Station Furnace Facility</u>		<u>FO NUMBER: 6</u>					
<u>FO NAME: Mettback and Regrowth of HgZnTe</u>		<u>PREREQUISITE: FO-3</u>					
<u>NO. OF PERFORMANCES: MIN. _____ DES. _____</u>		<u>SEQUENCE: _____</u>					
<u>REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____</u>		<u>JOINT OPS WITH: _____</u>					
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)		MINIMUM					
		MAXIMUM					
		PREFERRED	3:00	340:00	120:00	125:00	600:00
STEP DELAY (HRS:MINS)		MINIMUM					
		MAXIMUM					
		PREFERRED					
CREW		NUMBER					
		PREFERRED					
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		.120	.598	.516	.516	516	516
ONBOARD COMPUTER SUPPORT		CORE APPLICATIONS					
		EXPERIMENT APPLICATIONS					
DATA	DLINK DIGITAL (MBPS)						
	REALTIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POCC (PC)						
	VIDEO						
	STANDARD/NONSTANDARD NTSC						
REAL-TIME/DUMP/STORE							
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.		STEP DESCRIPTION					
1		Activate furnace for processing					
2		Process heat cycle					
3		Initial soak					
4		Translation to growth position					
5		Final soak					
6		Directional solidification					

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 6 of 13)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>6</u>					
FO NAME: <u>Meltback & Regrowth of HgZnTe</u>	PREREQUISITE: <u>FO-3</u>					
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____					
STEP NUMBER		7	8			
STEP DURATION (MINS:SECS)	MINIMUM					
	MAXIMUM					
	PREFERRED	372:00	115:00			
STEP DELAY (HRS:MINS)	MINIMUM					
	MAXIMUM					
	PREFERRED					
CREW	NUMBER					
	PREFERRED					
MICROGRAVITY (g's)						
VACUUM VENT						
CONSUMABLES						
AVERAGE POWER REQUIRED (kW)		.191	.061			
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS					
	EXPERIMENT APPLICATIONS					
DATA	DOWNLINK DIGITAL (MBPS)					
	REALTIME (RT) OR DUMP (D)					
	COMMANDING					
	PES (P), ISE (I), MPAC (M), POCC (PC)					
	VIDEO					
	STANDARD/NONSTANDARD NTSC					
REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS						
STEP NO.		STEP DESCRIPTION				
7 Cool sample						
8 Stow sample						

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 7 of 13)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>		FO NUMBER: <u>6A</u>					
FO NAME: <u>Meltback and Regrowth of HgZnTe (Extended)</u>		PREREQUISITE: <u>FO-3</u>					
NO. OF PERFORMANCES: MIN. _____ DES. _____		SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____		JOINT OPS WITH: _____					
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	3:00	340:00	120:00	125:00	600:00	59957:00
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		.120	.598	.516	.516	.516	.516
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DOWLINK DIGITAL (MBPS)						
	REALTIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POCC (PC)						
	VIDEO STANDARD/NONSTANDARD: NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Activate furnace for processing						
2	Process heat cycle						
3	Initial soak						
4	Translation to growth position						
5	Final soak						
6	Directional solidification						

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 8 of 13)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>		FO NUMBER: <u>6A</u>				
FO NAME: <u>Meltback and Regrowth of HgZnTe (Extended)</u>		PREREQUISITE: <u>FO-3</u>				
NO. OF PERFORMANCES: MIN. _____ DES. _____		SEQUENCE: _____				
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____		JOINT OPS WITH: _____				
STEP NUMBER		7	8			
STEP DURATION (MINS:SECS)	MINIMUM					
	MAXIMUM					
	PREFERRED	372:00	115:00			
STEP DELAY (HRS:MINS)	MINIMUM					
	MAXIMUM					
	PREFERRED					
CREW	NUMBER					
	PREFERRED					
MICROGRAVITY (g's)						
VACUUM VENT						
CONSUMABLES						
AVERAGE POWER REQUIRED (kW)		.191	.061			
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS					
	EXPERIMENT APPLICATIONS					
DATA	DLINK DIGITAL (MBPS)					
	REALTIME (RT) OR DUMP (D)					
	COMMANDING					
	PES (P), ISE (I), MPAC (M), POCC (PC)					
	VIDEO STANDARD/NONSTANDARD NTSC					
	REAL-TIME/DUMP/STORE					
SPECIAL EQUIPMENT OR CONSTRAINTS						
<u>STEP NO.</u>		<u>STEP DESCRIPTION</u>				
7		Cool sample				
8		Internally stow sample				

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 9 of 13)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>7</u>						
FO NAME: <u>Growth of CdTe by Directional Solidification</u>	PREREQUISITE: <u>FO-3</u>						
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____						
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____						
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	3:00	538:00	120:00	4278:00	438:00	208:00
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		.120	1.345	1.241	1.166	.591	.241
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DOWLINK DIGITAL (MBPS)						
	REALTIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POCC (PC)						
	VIDEO						
	STANDARD/NONSTANDARD NTSC						
REAL-TIME/DUMP/STORE							
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Activate furnace module for processing						
2	Process heat cycle						
3	Soak						
4	Process sample, directional solidification						
5	Cool sample to 400 °C						
6	Cool sample to 200 °C and internally stow sample						

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 10 of 13)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>8</u>						
FO NAME: <u>Growth of GaAs by directional Solidification</u>	PREREQUISITE: <u>FO-3</u>						
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____						
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____	JOINT OPS WITH: _____						
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	3:00	45:00	227:00	68:00	720:00	210:00
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		.120	.858	2.353	1.344	1.259	.668
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DOWLINK DIGITAL (MBPS)						
	REALTIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POCC (PC)						
	VIDEO STANDARD/NONSTANDARD NTSC						
	REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Activate furnace module processing						
2	Preheat cycle						
3	Process heat cycle						
4	Soak						
5	Translate furnace/process sample						
6	Cool down to 800 °C						

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 11 of 13)

<u>EXPERIMENT NAME: Space Station Furnace Facility</u>		<u>FO NUMBER: 8</u>						
<u>FO NAME: Growth of GaAs by Directional Solidification</u>		<u>PREREQUISITE: FO-3</u>						
<u>NO. OF PERFORMANCES: MIN. _____ DES. _____</u>		<u>SEQUENCE: _____</u>						
<u>REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____</u>		<u>JOINT OPS WITH: _____</u>						
STEP NUMBER		7						
STEP DURATION (MINS:SECS)		MINIMUM						
		MAXIMUM						
		PREFERRED	466:00					
STEP DELAY (HRS:MINS)		MINIMUM						
		MAXIMUM						
		PREFERRED						
CREW		NUMBER						
		PREFERRED						
MICROGRAVITY (g's)								
VACUUM VENT								
CONSUMABLES								
AVERAGE POWER REQUIRED (kW)		.120						
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS							
	EXPERIMENT APPLICATIONS							
DATA	DLINK DIGITAL (MBPS)							
	REALTIME (RT) OR DUMP (D)							
	COMMANDING							
	PES (P), ISE (I), MPAC (M), POCC (PC)							
	VIDEO							
	STANDARD/NONSTANDARD NTSC							
REAL-TIME/DUMP/STORE								
SPECIAL EQUIPMENT OR CONSTRAINTS								
STEP NO.		STEP DESCRIPTION						
7		Cool down to 200 °C and internally stow						

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 12 of 13)

EXPERIMENT NAME: <u>Space Station Furnace Facility</u>	FO NUMBER: <u>9</u>					
FO NAME: <u>Configure Furnace for Shutdown/Sample loading</u>	PREREQUISITE: _____					
NO. OF PERFORMANCES: MIN. _____ DES. _____	SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. ____ MAX. _____	JOINT OPS WITH: _____					
STEP NUMBER	1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM					
	MAXIMUM					
	PREFERRED	3:00	5:00	1:00		
STEP DELAY (HRS:MINS)	MINIMUM					
	MAXIMUM					
	PREFERRED					
CREW	NUMBER					
	PREFERRED					
MICROGRAVITY (g's)						
VACUUM VENT						
CONSUMABLES						
AVERAGE POWER REQUIRED (kW)	0	0	0			
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS					
	EXPERIMENT APPLICATIONS					
DATA	DOWNLINK DIGITAL (MBPS)					
	REALTIME (RT) OR DUMP (D)					
	COMMANDING					
	PES (P), ISE (I), MPAC (M), POCC (PC)					
	VIDEO					
	STANDARD/NONSTANDARD NTSC					
REAL-TIME/DUMP/STORE						
SPECIAL EQUIPMENT OR CONSTRAINTS						
STEP NO.	STEP DESCRIPTION					
1	Verify furnace is in home position					
2	Furnace specific tests					
3	CCU secures power from furnace module					

TABLE 2.1-2. FUNCTIONAL OBJECTIVE REQUIREMENTS SHEET (Sheet 13 of 13)

EXPERIMENT NAME: Space Station Furnace Facility		FO NUMBER: 11					
FO NAME: Furnace Calibration/Bakeout		PREREQUISITE: FO-3					
NO. OF PERFORMANCES: MIN. _____ DES. _____		SEQUENCE: _____					
REQUIRED TIMEFRAME (MET): MIN. _____ MAX. _____		JOINT OPS WITH: _____					
STEP NUMBER		1	2	3	4	5	6
STEP DURATION (MINS:SECS)	MINIMUM						
	MAXIMUM						
	PREFERRED	1:00	1:00	300:00			
STEP DELAY (HRS:MINS)	MINIMUM						
	MAXIMUM						
	PREFERRED						
CREW	NUMBER						
	PREFERRED						
MICROGRAVITY (g's)							
VACUUM VENT							
CONSUMABLES							
AVERAGE POWER REQUIRED (kW)		2.1336	2.1336	2.330			
ONBOARD COMPUTER SUPPORT	CORE APPLICATIONS						
	EXPERIMENT APPLICATIONS						
DATA	DOWNLINK DIGITAL (MBPS)						
	REALTIME (RT) OR DUMP (D)						
	COMMANDING						
	PES (P), ISE (I), MPAC (M), POCC (PC)						
	VIDEO						
	STANDARD/NONSTANDARD NTSC						
REAL-TIME/DUMP/STORE							
SPECIAL EQUIPMENT OR CONSTRAINTS							
STEP NO.	STEP DESCRIPTION						
1	Activate calibration/bakeout						
2	Initiate calibration						
3	Bakeout/calibration process						




FIGURE 2.1-2. FURNACE MODULE-1 COMPONENT TREE




FIGURE 2.1-3. FURNACE MODULE 1 TO SSFF INTERFACE DIAGRAM

TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 1 of 12)




TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 2 of 12)




TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 3 of 12)




TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 4 of 12)




TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 5 of 12)




TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 6 of 12)




TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 7 of 12)




TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 8 of 12)




TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 9 of 12)




TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 10 of 12)




TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 11 of 12)





TABLE 2.1-3. FURNACE MODULE-1 OPERATIONAL FUNCTIONAL FLOW (Sheet 12 of 12)





2.2. STRUCTURAL/MECHANICAL

Furnace Module-1 will be mounted in the Space Station Furnace Facility (SSFF) Experiment Rack-1. The physical and functional interfaces defined herein between Furnace Module-1 and SSFF, and Furnace Module-1 and Space Station Freedom (SSF) are as follows:

- Furnace Module-1 to SSFF Experiment Rack-1
- Furnace Module-1 cooling jacket to SSFF Thermal Control System (TCS)
- Furnace Module-1 electrical connection to SSFF Power Conditioning and Distribution System (PCDS)
- Furnace Module-1 to SSFF-supplied argon and nitrogen
- Furnace Module-1 to SSFF-supplied vacuum vent
- Furnace Module-1 Data Management System (DMS) connections to SSFF DMS
- Furnace Module-1 software to SSFF software
- Furnace Module-1 to crew interface

2.2.1 EQUIPMENT LIST AND MASS PROPERTIES

Mass properties of Furnace Module-1 are shown in Table 2.2-1. Stowage items and their properties are shown in Table 2.2-2.

2.2.2 INTERFACE DETAIL

2.2.2.1 Furnace Module-1 to SSFF Experiment Rack-1

The Furnace Module-1 will interface with the experiment rack by way of the experiment apparatus container (EAC) base ring. The EAC connector locations for the TCS, PCDS, argon, nitrogen, vacuum vent, and DMS are identified in Figure 2.2-1. Further information on each of these interfaces is available in this section of this document.

All services will be provided to Furnace Module-1 by the Core Rack, except avionics air and fire detection and suppression, which will be provided at Experiment Rack-1 via the SSFF furnace interface panel. Other furnace-unique services which might be required will be the responsibility of the Furnace Developer and will be located in Experiment Rack-1.

2.2.2.2 Furnace Module-1 Cooling Jacket-to-SSFF TCS

Furnace Module-1 will interface with the SSFF TCS via quick disconnects located at the Furnace Module-1 base ring.

TABLE 2.2-1. LIST OF EQUIPMENT PROPERTIES

Equipment Nomenclature	Mass (kg)	Mass Maturity (%)		Mounting Preferred	Center of Gravity Station (cm)			Moment of Inertia (kg-m ²)			Product of Inertia (kg-m ²)		
		est.	cal.		X	Y	Z	I _x	I _y	I _z	I _{xy}	I _{xz}	I _{yz}
Furnace Module-1	327.0	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Utilities Interface Panel	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD
Interface Cables and Fluid Lines	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD	TBD

TABLE 2.2-2. FURNACE MODULE-1 STOWAGE LIST

Item	Number Required	Mass Each (kg)	Dimensions (cm) LxWxH or LxDia	Stowage Responsibility	Stowage Phase	Special Requirements
				Ex	PL	L O R
Sample Ampoule/Cartridge Assembly with Stowage Bag (5 flight and 5 spares)	10	1.60	73.7 x 13.2 dia.		>	>>>>
Work Bag	TBD	0.07	45.7 x 5.1 dia.		>	>>>>
Glovebox Cover	1	TBD	TBD		>	>>>>
Flexible Glovebox	1	0.31	24.1 x 2.1 X 1.9		>	>>>>
Torque Wrench, 1/4 in. (30-200 in-lb)	1	0.09	5.1 x 1.7 dia.		>	>>>>
Socket, 1/2 in. deep, (1/4-in. drive)	1	0.10	25.4 x 1.3 dia.		>	>>>>
Extender, 10 in. (1/4-in. drive)	1	0.01	5.2 x 1.3 dia.		>	>>>>
Hex Head Driver, 5/32 in. (3/8-in. drive)	1	0.01	5.2 x 1.3 dia.		>	>>>>
Hex Head Driver, 1/4 in. (3/8-in. drive)	1	0.02	2.4 x 1.3 dia.		>	>>>>
Adapter, 1/4 to 3/8 in. (1/4-in. drive)	1	0.41	14.0 x 22.9 x 3.8		>	>>>>
Viton Gloves (pair)	10	0.01	15.2 x 15.2 x 0.5		>	>>>>
Filter Test Bags	1	0.26	76.2 x 5.2 dia.		>	>>>>
SACA Wrench	1	0.40	17.8 x 3.2 dia.		>	>>>>
Torque Wrench (0-30 in-lb)	10	0.26	20.6 x 9.1 dia.		>	>>>>
Transfer Units						

TBD

FIGURE 2.2-1. FURNACE MODULE-1 EAC CONNECTOR LOCATIONS

2.2.2.3 Furnace Module-1 Electrical Connection-to-SSFF PCDS

The furnace module will interface with the SSFF PCDS via the furnace junction box located within Experiment Rack-1 to the Furnace Module-1 base ring connection.

2.2.2.4 Furnace Module-1 to SSFF-Supplied Argon and Nitrogen

Furnace Module-1 will interface with the SSFF Core Rack-supplied argon and nitrogen through a connection at the Furnace Module-1 base ring.

2.2.2.5 Furnace Module-1 to SSFF-Supplied Vacuum Vent

Furnace Module-1 will interface with the SSF-supplied vacuum vent through a connection at the Furnace Module-1 base ring.

2.2.2.6 Furnace Module-1 DMS Connections-to-SSFF DMS

The furnace module will interface with the SSFF DMS via the Furnace Data Acquisition and Control System (FDACS) located within Experiment Rack-1.

2.2.2.7 Furnace Module-1 Software-to-SSFF Software

The Furnace Module-1 software will require an interface with the SSFF software to support operation of the furnace module. This interface will include (1) downloading software and data to the Furnace Module-1 software; (2) collecting and processing (if necessary) data received from the Furnace Module-1 software; (3) responding to requests for SSFF resources such as power, gas, cooling, etc.; (4) retrieving stored data to be output to Furnace Module-1 for analysis; (5) network management of the local area network (LAN) connected to the Furnace Module-1 processor; (6) fault, detection, isolation, and recovery (FDIR) services; and (6) operating system services. Furnace Module-1 will also require interface from the SSFF software to the furnace heating system, the furnace translation system (if present), the furnace cavity pressure system, and the furnace current pulsing system.

2.2.2.8 Furnace Module-1 to Crew Interface


There are two ways the crew may interface with Furnace Module 1. The first way is through the top end of the EAC where the crew interfaces with the integrated furnace enclosure apparatus (IFEA) via the sample insertion port during manual sample exchange.

The second way the crew may interface with Furnace Module-1 is through the crew interface to the SSFF DMS (display and keyboard). Through the display and keyboard, a crewmember can direct the furnace to perform any number of operations including changing temperature profiles or rotating and loading a different sample into the processing position.



2.3. POINTING/STABILIZATION AND ALIGNMENT

Furnace Module-1 requires specific alignment of the center line of the sample during processing. This requirement is that the residual dc acceleration vector (i.e., dc component of the acceleration vector at the sample due to all factors such as drag, orbital mechanics, etc.) should be aligned with the center line of the sample precisely enough that the component of the acceleration perpendicular to the center line is less than $10^{-7}g$. The direction of the vector may be required to be from hot zone to cold zone of the furnace or the opposite direction. The required direction will be determined separately for each sample.



2.4. ORBITAL REQUIREMENTS AND CONSTRAINTS


Furnace Module-1 requires specific Orbiter attitudes during processing in order to satisfy the requirement for orienting the reconfiguring furnace module (RFM) axis in relation to the residual dc acceleration vector. Details of the attitude requirements are to meet the requirements of Section 2.3.



2.5. ELECTRICAL REQUIREMENTS

All power conditioning will be accomplished by Space Station Furnace Facility (SSFF) prior to any distribution to Furnace Module-1. Furnace Module-1 heaters will interface with the Power Conditioning and Distribution System (PCDS) at the furnace junction boxes. The operational power profile defining the use of the SSFF-provided power to Furnace Module-1 during each functional objective (FO) is shown in Figure 2.5-1. The power profile data shown in these figures represent power requirement estimates to cover any of the the SSFF-accommodated furnace needs. Only FO-5 through FO-8 power profiles are shown since no power is associated with the furnace in FO-3, FO-4, FO-9, or FO-11. The power levels defined in Figure 2.5-1 are considered maximums. Time duration for peak power requirements is 72 h. The maximum peak power required is 1650 W. The average power required is 570 W.

FO-5 HgCdTe



FO-6 HgZnTe





FIGURE 2.5-1. POWER PROFILES BY FO (Sheet 1 of 3)

FO-6A HgZnTe



FO-7 CdTe




FIGURE 2.5-1. POWER PROFILES BY FO (Sheet 2 of 3)

FG-8 GaAs




FIGURE 2.5-1. POWER PROFILES BY FO (Sheet 3 of 3)

2.6. THERMAL/FLUID REQUIREMENTS

2.6.1 HEAT TRANSFER CHARACTERISTICS

Furnace Module-1 utilizes the Space Station Furnace Facility (SSFF) water cooling loop for experiment cooling and will not require avionics air cooling. Thermal requirements for Furnace Module-1 are shown in Table 2.6-1. Maximum water-cooled heat dissipation from Experiment Rack-1 is 1500 W for Furnace Module-1. Required inlet temperature of the cooling water for Furnace Module-1 is 39.9 °C.

2.6.2 FLUID/VENT REQUIREMENTS

Furnace Module-1 requires an argon processing atmosphere. Argon required by Furnace Module-1 for the Integrated Configuration-1 (IC1) mission is 7.5 kg. The supplied argon is required to be research grade having the following contaminant levels:

99.9995 % pure	N ₂ < 3.0 ppm
CO ₂ < 0.5 ppm	N ₂ O < 0.1 ppm
CO < 1.0 ppm	O ₂ < 1.0 ppm
H ₂ < 1.0 ppm	THC < 0.5 ppm
CH ₄ < 0.5 ppm	H ₂ O < 0.5 ppm
dewpoint = -112 °F	

During nominal operating conditions, the vent products for Furnace Module-1 will be argon and nitrogen. Vent products during off-nominal conditions are TBD. Gas and vacuum requirements for Furnace Module-1 are shown in Table 2.6-2.

Furnace Module-1 has two paths to the SSF Vacuum System. The use of these paths is defined as follows:

- Path One - Active Pressure Control
 - Path one is used for Gas Distribution System (GDS)-controlled, or nominal venting.
 - Path one requires access to the Space Station Freedom (SSF) Vacuum System during the sample processing phases of Furnace Module-1 operations.
 - Venting episodes using path one will be SSF timelined activities. Typical vents will occur every 15 min to 1 h.


- Path Two - Emergency Pressure Relief
 - Path two provides for emergency relief of experiment apparatus container (EAC) overpressure through redundant pressure relief valves.
 - Path two must have access to the SSF Vacuum System during all on-orbit phases after installation into the U.S. Laboratory module.

TABLE 2.6-1. ON-ORBIT THERMAL REQUIREMENTS

Equipment Item and FO No.	Heat Sink Type			Cooling Load (W)		Min/Max Temp (°C)		Thermal Capacitance (W·h·°C)	Special Considerations (as applicable)
	Rack Air (ducted)	Rack Air (nonducted)	Exp Coldplate (Module)	SSFF Core IX	Standby	Peak or other	Operate		
FO-3			X	0	0	0/50	0/50	TBD	
FO-4			X	0	0	0/50	0/50	TBD	
FO-5			X	TBD	232	270	0/50	0/50	TBD
FO-6			X	TBD	274	285	0/50	0/50	TBD
FO-6A			X	TBD	283	285	0/50	0/50	TBD
FO-7			X	TBD	525	580	0/50	0/50	TBD
FO-8			X	TBD	524	697	0/50	0/50	TBD
FO-9			X	0	0	0/50	0/50	0/50	TBD
FO-11			X	0	0	0/50	0/50	0/50	TBD

TABLE 2.6-2. FLUID REQUIREMENTS

Equipment Item and FO No.	Functional Requirement (Pressure, Purge, Vent Vacuum)	Gas or Liquid Parameters				Vent	When Required and Duration	Vacuum Vent Rate: torr-1/sec	Special Considerations (as applicable)
		Type	Quantity Stored (kg)	Pressure Limit (N/m ²)	Flow-rate (kg/h)				
FO-3 Step 2	Vacuum Vent	Argon	0	1.38x10 ⁵	>4.1	TBD	0.133	TBD	1.2 x 10 ⁻³
FO-4 Step 1 Step 2	Vacuum Vent Pressurize	Nitrogen Argon	0 0	1.38x10 ⁵ 1.38x10 ⁵	TBD >4.1	TBD TBD	0.133 0.133	TBD TBD	1.2 x 10 ⁻³ 1.2 x 10 ⁻³
FO-5	N/A								
FO-6	N/A								
FO-6A	N/A								
FO-7	N/A								
FO-8	N/A								
FO-9	Vent		0				0.133	TBD	1.2 x 10 ⁻³
FO-11	N/A								



2.7. DATA SYSTEM REQUIREMENTS

Furnace Module-1 will require the use of the Furnace Data Acquisition and Control System (FDACS) consisting of a Furnace Control Unit (FCU) and a Furnace Actuator Unit (FAU), which will monitor and collect data from Furnace Module-1 and provide control stimulus as needed for the positioning of samples. The requirements from the Furnace Module-1 to the SSFF Core are defined in subsections 2.7.1 through 2.7.5 and in Tables 2.7-1 through 2.7-5..

2.7.1 SIGNAL INTERFACE DEFINITION

Table 2.7-1 defines the following data signals and control to perform the following data handling and operations functions:

- Furnace Module-1 activation and control
- Acquisition, formatting, and routing of Furnace Module-1 housekeeping data
- Acquisition, formatting, and routing of Furnace Module-1 science data

2.7.2 SIGNAL INTERFACE DEFINITION EXPANSION

Table 2.7-2 is an expansion of the input and output data streams identified in Table 2.7-1.

2.7.3 EVENT/EXCEPTION MONITORING REQUIREMENTS

Onboard event and exception monitoring requirements for data transmitted to the SSFF are defined in Table 2.7-3.

2.7.4 PAYOUT OPERATIONS INTEGRATION CENTER DISPLAY REQUIREMENTS

The Payload Operations Integration Center (POIC) controls all payload operations and is equipped with consoles for data management, operations control, and mission planning. The data to provide this capability are shown in Table 2.7-4.

2.7.5 POIC LIMIT SENSING/EXCEPTION MONITORING REQUIREMENTS

Limit sensing and exception monitoring are provided to the POIC via downlink and are defined in Table 2.7-5.

TABLE 2.7-1. SIGNAL INTERFACE DEFINITION

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 1 of 38)

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 2 of 38)

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 3 of 38)

ENTIC NO.		DESCRIPTION		MONIC	/MONIC	DATA DESCRIPTION	DATA	MIN NM SITI	REQ A	REQ C	/REQ C
N	O										
1261	106	Argon	Fill Valve Closed Status	ID1	011	B 25 08 25 08					
1262	106	Argon	Fill Valve Open Status	ID1	011	B 25 09 25 09					
1263	106	Hot Main Red Mod	A RCCB Off Stat	ID1	011	B 25 10 25 10					
1264	106	Hot Main Red Mod	A RCCB On Stat	ID1	011	B 25 11 25 11					
1265	106	Water	Outlet Valve Normal Stat	ID1	011	B 25 12 25 12					
1266	106	Water	Outlet Valve Bypass Stat	ID1	011	B 25 13 25 13					
1267	106	Water	Inlet Valve Normal Status	ID1	011	B 25 14 25 14					
1268	106	Water	Inlet Valve Bypass Status	ID1	011	B 25 15 25 15					
1269	106	Fail Safe Brake	RCCB Off Status	ID1	011	B 26 00 26 00					
1270	106	Fail Safe Brake	RCCB On Status	ID1	011	B 26 01 26 01					
1271	106	Core Hold Down	Not Retracted	ID1	011	B 26 02 26 02					
1272	106	Core Hold Down	Retracted	ID1	011	B 26 03 26 03					
1273	106	Core Hold Down	Not Extended	ID1	011	B 26 04 26 04					
1274	106	Core Hold Down	Extended	ID1	011	B 26 05 26 05					
1275	106	HD Motor	RCCB Off Status	ID1	011	B 26 06 26 06					
1276	106	HD Motor	RCCB On Status	ID1	011	B 26 07 26 07					
1277	106	Step Motor	Clutch RCCB Off Stat	ID1	011	B 26 08 26 08					
1278	106	Step Motor	Clutch RCCB On Status	ID1	011	B 26 09 26 09					
1279	106	Step Motor	Drive RCCB Off Stat	ID1	011	B 26 10 26 10					
1280	106	Step Motor	Drive RCCB On Stat	ID1	011	B 26 11 26 11					
1281	106	Rapid Xlation	Clutch RCCB Off Stat	ID1	011	B 26 12 26 12					
1282	106	Rapid Xlation	Clutch RCCB On Stat	ID1	011	B 26 13 26 13					
1283	106	Rapid Xlation	Mtr RCCB Off Stat	ID1	011	B 26 14 26 14					
1284	106	Rapid Xlation	Mtr RCCB On Status	ID1	011	B 26 15 26 15					
1285	106	Furnace Position	Not Home	ID1	011	B 27 00 27 00					
1286	106	Furnace Position	Home	ID1	011	B 27 01 27 01					
1287	106	Furn Extreme	Trvl Not Exceeded	ID1	011	B 27 02 27 02					
1288	106	Furn Extreme	Trvl Exceeded	ID1	011	B 27 03 27 03					
1289	106	Ampoule Alignment	Not Retracted	ID1	011	B 27 04 27 04					
1290	106	Ampoule Alignment	Retracted	ID1	011	B 27 05 27 05					

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 4 of 38)

		ICU	IN/NM/SIT	DATA DESCRIPTION	MONIC	REQ A
ENTIC N	NO. IO O	IMIS	ISO/OSI/Y			
IR .	IR .	IDIA	G . /G	P START END DATA VALUE	CIRC STD E T	
IR .	IR .	G	W F E	----- ----- ----- -----	D IO NO. JX A	
IR .	IR .	I E	D I	WD BT WD BT Y	T D	P B
IR .	IR .	L	S X	#	P	I L
IR .	IR .	K	/ D	I	? E	ID E
IR .	IR .			E	T P F	
1291 106 Ampoule Alignment Not Extended		DI 0 1	IB 27 06 27 06			
1292 106 Ampoule Alignment Extended		DI 0 1	IB 27 07 27 07			
1293 106 Ampoule Align Mtr RCCB Off Stat		DI 0 1	IB 27 08 27 08			
1294 106 Ampoule Align Mtr RCCB On Stat		DI 0 1	IB 27 09 27 09			
1295 106 Ampoule Support Not Retracted		DI 0 1	IB 27 10 27 10			
1296 106 Ampoule Support Retracted		DI 0 1	IB 27 11 27 11			
1297 106 Ampoule Support Not Secure		DI 0 1	IB 27 12 27 12			
1298 106 Ampoule Support Secure		DI 0 1	IB 27 13 27 13			
1299 106 Ampoule Spt Plt Mtr RCCB Off St		DI 0 1	IB 27 14 27 14			
1300 106 Ampoule Spt Plt Mtr RCCB On Stat		DI 0 1	IB 27 15 27 15			
1301 106 Cold Guard Mod RCCB Off Status		DI 0 1	IB 28 00 28 00			
1302 106 Cold Guard Mod RCCB On Status		DI 0 1	IB 28 01 28 01			
1303 106 Carousel Spacer Plt Gap Lim-Not		DI 0 1	IB 28 02 28 02			
1304 106 Carousel Spacer Plt Gap Limit		DI 0 1	IB 28 03 28 03			
1305 106 Indexing Cam Not Stowed		DI 0 1	IB 28 04 28 04			
1306 106 Indexing Cam Stowed		DI 0 1	IB 28 05 28 05			
1307 106 Carousel Trk Extr Left Lim-Not		DI 0 1	IB 28 06 28 06			
1308 106 Carousel Trk Extr Left Limit		DI 0 1	IB 28 07 28 07			
1309 106 Carousel Trk Extr Right Lim-Not		DI 0 1	IB 28 08 28 08			
1310 106 Carousel Trk Extr Right Lim		DI 0 1	IB 28 09 28 09			
1311 106 Hot Main Red Mod B RCCB Off Stat		DI 0 1	IB 28 10 28 10			
1312 106 Hot Main Red Mod B RCCB On Stat		DI 0 1	IB 28 11 28 11			
1313 106 SEM Index Motor RCCB Off Status		DI 0 1	IB 28 12 28 12			
1314 106 SEM Index Motor RCCB On Status		DI 0 1	IB 28 13 28 13			
1315 106 SEM Indexing Jog CCW Status		DI 0 1	IB 28 14 28 14			
1316 106 SEM Indexing Jog CW Status		DI 0 1	IB 28 15 28 15			
1317 106 Ampoule Not Processing		DI 0 1	IB 29 00 29 00			
1318 106 Ampoule Processing		DI 0 1	IB 29 01 29 01			
1319 106 System Bus Relay Off Status		DI 0 1	IB 29 02 29 02			
1320 106 System Bus Relay On Status		DI 0 1	IB 29 03 29 03			
1	1					
0	0					
3	6					

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 5 of 38)

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 6 of 38)

ENTIC N NO. 10 O	DESCRIPTION	ICU	INN INM SITI	DATA DESCRIPTION	MON C		REQ A	
		MIS	ISO OS JOY	G. G	P START	END DATA VALUE	-- L	C R C S ID E T
		DIA	I G	I F E	-- T	-- T	E E .	D I O N O .
		I G	I W	I D I	WD BT	WD BT Y	V X C	T D
		I E	I S	I S X	#	#	N C O	? E
		I L	I /	I D I	#	#	T P F	D E
		I K	/	/	#	#	/	/
029 850 SEM Indexing Jog CW Status			1 02					1 4 2
030 850 Ampoule Not Processing			1 02					1 4 2
031 850 Ampoule Processing			1 02					1 4 2
032 850 Indexing Cam Not Stowed			1 02					1 4 2
033 850 Indexing Cam Stowed			1 02					1 4 2
034 850 Pelletier Connector Not Retracted			1 02					1 4 2
035 850 Pelletier Connector Retracted			1 02					1 4 2
036 850 Pelletier Connector Not Extended			1 02					1 4 2
037 850 Pelletier Connector Extended			1 02					1 4 2
038 850 Ampoule 4 Failure 2 Status			1 02					1 4 2
039 850 Ampoule 4 Failure 1 Status			1 02					1 4 2
040 850 Ampoule 3 Failure 2 Status			1 02					1 4 2
041 850 Ampoule 3 Failure 1 Status			1 02					1 4 2
042 850 Ampoule 2 Failure 2 Status			1 02					1 4 2
043 850 Ampoule 2 Failure 1 Status			1 02					1 4 2
044 850 Ampoule 1 Failure 2 Status			1 02					1 4 2
045 850 Ampoule 1 Failure 1 Status			1 02					1 4 2
046 850 PDS Airflow 1 Status			1 02					1 4 2
047 850 PCS Airflow 1 Status			1 02					1 4 2
048 850 IFE A ABS Press 2 RCCB Off Status			1 02					1 4 2
049 850 IFE A ABS Press 2 RCCB On Status			1 02					1 4 2
050 850 Spare RCCB Off Stat			1 02					1 4 2
051 850 Spare RCCB On Stat			1 02					1 4 2
052 850 IFE A Coolant Flow 1 Status			1 02					1 4 2
053 850 SCS Airflow 1 Status			1 02					1 4 2
054 850 Cartridge 2 Failure 2 Status			1 02					1 4 2
055 850 Cartridge 2 Failure 1 Status			1 02					1 4 2
056 850 Cartridge 1 Failure 2 Status			1 02					1 4 2
057 850 Cartridge 1 Failure 1 Status			1 02					1 4 2
058 850 Ampoule 6 Failure 2 Status			1 02					1 4 2
			1 1	1 1	1 1	1 1	1 1	1 1
0 0			3 4	4 4	4 4	5 5	6 6	7 7
3 6 7			9 0	3 5	7 8	1 3	5 7	5 6

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 7 of 38)

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 8 of 38)

ENTIC N		ICIU	IMN	NM	SIT	DATA	DESCRIPTION	MONIC	
NO.	IO	IMIS	ISO	OS	OY	-	-	-	-
IR .	IR .	DIA	G . I	G /I	P START	END	DATA VALUE	L	C RC S1D E T
.	.	IUE	I G	I W	F E	---	T	E E .	. D10 NO.
.	.	IL	I D	I D	W D BT	W D BT Y	V X C	T D	P B
.	.	IK	I S	I X	#	#	P	? E	I L
.	.	IK	I /	I D	I	I	E	T P F	D E
1089	850	Ampoule Align Mtr	RCCB	On	Stat	102			1 41 2
1090	850	Water Inlet Valve	RCCB	Off	Stat	102			1 41 2
1091	850	Water Inlet Valve	RCCB	On	Stat	102			1 41 2
1092	850	Argon Fill Valve	RCCB	Off	Stat	102			1 41 2
1093	850	Argon Fill Valve	RCCB	On	Stat	102			1 41 2
1094	850	System Bus Relay Off	Status			102			1 41 2
1095	850	System Bus Relay On	Status			102			1 41 2
1096	850	IFEA Coolant Flow	#2	Status		102			1 41 2
1097	850	PCS Airflow	2	Status		102			1 41 2
1098	850	Cartridge 6 Failure	2	Status		102			1 41 2
1099	850	Cartridge 6 Failure	1	Status		102			1 41 2
1100	850	Cartridge 5 Failure	2	Status		102			1 41 2
101	850	Cartridge 5 Failure	1	Status		102			1 41 2
102	850	Cartridge 4 Failure	2	Status		102			1 41 2
103	850	Cartridge 4 Failure	1	Status		102			1 41 2
104	850	Cartridge 3 Failure	2	Status		102			1 41 2
105	850	Cartridge 3 Failure	1	Status		102			1 41 2
106	850	PCS Utility RCCB	Off	Status		102			1 41 2
107	850	PCS Utility RCCB	On	Status		102			1 41 2
108	850	Step Motor Drive	RCCB	Off	Stat	02			1 41 2
109	850	Step Motor Drive	RCCB	On	Stat	02			1 41 2
110	850	IFEA ABS Press 1	RCCB	Off	Stat	02			1 41 2
111	850	IFEA ABS Press 1	RCCB	On	Stat	02			1 41 2
112	850	Peltier Conn Motor	RCCB	Off	Stat	02			1 41 2
113	850	Peltier Conn Motor	RCCB	On	Stat	02			1 41 2
114	850	Step Motor Clutch	RCCB	Off	Stat	02			1 41 2
115	850	Step Motor Clutch	RCCB	On	Stat	02			1 41 2
116	850	Rapid Xlation Clutch	RCCB	Off	Stat	02			1 41 2
117	850	Rapid Xlation Clutch	RCCB	On	Stat	02			1 41 2
118	850	Rapid Xlation Mtr	RCCB	Off	Stat	02			1 41 2

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 9 of 38)

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 10 of 38)

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 11 of 38)

		ICU	IMN	INMISITI	DATA DESCRIPTION	IMONIC	//////////
ENT	C N	IMIS	ISO/OSI/OIY			IREQA	
NO.	O	ID A	G. I/G	P START	END DATA VALUE	-- L	CIRC SID E IT
R .	.	I G	I W	F E	-- T	E E .	D IO NO.
R	.	I U E	I D	I I	WD BT WD BT Y	V X C	T D
I .	.	I L	I S	I X I	I P	N C O	P B
I	.	I K	I /	I D	I E	I T P F	I I L
							I D E
1179	3*	01 Last	Command	Received	Word #25	1 02	41 2
1180	1850	1Last	Command	Received	Word #26	1 02	41 2
1181	1850	1Last	Command	Received	Word #27	1 02	41 2
1182	1850	1Last	Command	Received	Word #28	1 02	41 2
1183	1850	1Last	Command	Received	Word #29	1 02	41 2
1184	1850	1Last	Command	Received	Word #30	1 02	41 2
1185	1850	1Last	Command	Received	Word #31	1 02	41 2
1186	1850	1Invalid	Command	Flag		0 2	41 2
1187	1850	1User	Requested	Data		0 2	41 2
1188	1850	1ECS	Next	Timeline	Record	0 2	41 2
1189	1850	1FTS	Next	Timeline	Record	0 2	41 2
1190	1850	1FHS	Cold	Guard	Next Timeline Rec	0 2	41 2
1191	1850	1FHS	Cold	Zone	Next Timeline Rec	0 2	41 2
1192	1850	1FHS	Booster	Next	Timeline Rec	0 2	41 2
1193	1850	1FHS	Hot	Zone	Next Timeline Rec	0 2	41 2
1194	1850	1FHS	Hot	Guard	Next Timeline Rec	0 2	41 2
1195	1850	1SIDS	Next	Timeline	Record	0 2	41 2
1196	1850	1ECS	Current	Segment	Start Time	0 2	41 2
1197	1850	1ECS	Current	Segment	Stop Time	0 2	41 2
1198	1850	1FTS	Current	Segment	Start Time	0 2	41 2
1199	1850	1FTS	Current	Segment	Stop Time	0 2	41 2
1200	1850	1FHS	Cold	Guard	Cur Seg Start Tim	0 2	41 2
1201	1850	1FHS	Cold	Guard	Cur Seg Stop Tim	0 2	41 2
1202	1850	1FHS	Cold	Zone	Cur Seg Start Tim	0 2	41 2
1203	1850	1FHS	Cold	Zone	Cur Seg Stop Tim	0 2	41 2
1204	1850	1FHS	Booster	Cur Seg	Start Time	0 2	41 2
1205	1850	1FHS	Booster	Cur Seg	Stop Time	0 2	41 2
1206	1850	1FHS	Hot	Zone	Cur Seg Start Time	0 2	41 2
1207	1850	1FHS	Hot	Zone	Cur Seg Stop Time	0 2	41 2
1208	1850	1FHS	Hot	Guard	Cur Seg Start Time	0 2	41 2
1		1	1	1	1	1	1
0	0	3	4	4	4	5	6
3	6	9	0	3	5	7	7
							8
						1	0
						2	5
						3	8

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 12 of 38)

		ICIU	IMN	INMISITI	DATA DESCRIPTION	IMONIC	IMONISID	REQA
ENTIC N	NO. IO O	IMIS	ISO1010Y					
IO R .	DESCRIPTION	IDIA	IG . / GI	P START	END DATA VALUE	--(L)	CIRC(SID	E T
IO R .		I G	I W	I FIE	--(T)	I E I .	DIOINO.	I X A
IO R .		I U E	I D	I WDIBT	I WDIBT(Y	I VIXCI	T D	I P IB
IO R .		J L	I S	I X	I P	I NCIO	I ? E	I T L
IO R .		I K I	I /	I D I	I E I	I T IPF	I	I D IEI
1209 850 IFHS	Hot Guard	Cur Seg	Stop Time	102	1	1	1	1 41 2
1210 850 SIDS	Current Segment	Start Time		102	1	1	1	1 41 2
1211 850 SIDS	Current Segment	Stop Time		102	1	1	1	1 41 2
1212 850 Experiment	Main Bus	Current		102	1	1	1	1 41 2
1213 850 Experiment	Main Bus	Voltage		102	1	1	1	1 41 2
1214 850 IFEA	Lower Humidity			102	1	1	1	1 41 2
1215 850 IFEA	Upper Humidity			102	1	1	1	1 41 2
1216 850 IFEA	Absolute Pressure 1			102	1	1	1	1 41 2
1217 850 IFEA	Absolute Pressure 2			102	1	1	1	1 41 2
1218 850 IFEA	Lower Atmosphere Temp			102	1	1	1	1 41 2
1219 850 IFEA	Upper Atmosphere Temp			102	1	1	1	1 41 2
1220 850 IFEA	Water Inlet Temp			102	1	1	1	1 41 2
1221 850 IFEA	Water Outlet Temp			102	1	1	1	1 41 2
1222 850 RFM	Cold End Shell Temp			102	1	1	1	1 41 2
1223 850 RFM	Hot End Shell Temp			102	1	1	1	1 41 2
1224 850 RFM	Water Outlet Temp			102	1	1	1	1 41 2
1225 850 Sample	1 Temp 1			102	1	1	1	1 41 2
1226 850 Sample	1 Temp 2			102	1	1	1	1 41 2
1227 850 Sample	1 Temp 3			102	1	1	1	1 41 2
1228 850 Sample	1 Temp 4			102	1	1	1	1 41 2
1229 850 Sample	1 Temp 5			102	1	1	1	1 41 2
1230 850 Sample	1 Temp 6			102	1	1	1	1 41 2
1231 850 Sample	2 Temp 1			102	1	1	1	1 41 2
1232 850 Sample	2 Temp 2			102	1	1	1	1 41 2
1233 850 Sample	2 Temp 3			102	1	1	1	1 41 2
1234 850 Sample	2 Temp 4			102	1	1	1	1 41 2
1235 850 Sample	2 Temp 5			102	1	1	1	1 41 2
1236 850 Sample	2 Temp 6			102	1	1	1	1 41 2
1237 850 Sample	3 Temp 1			102	1	1	1	1 41 2
1238 850 Sample	3 Temp 2			102	1	1	1	1 41 2
0	0				3 4	4 4	5 5	6 6 6 7 7 8
3	6				9 0	3 5 7 8	1 3 5 7	5 6 7 1 2 5 8 0

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 13 of 38)

		ICU	MN1	MN2	S[T]	DATA DESCRIPTION	MNC	MONIC	
ENTIC N		MS	SO1OS1OY	---	---	---	REQA	---	
NO. IO O	DESCRIPTION	DIA	G./G.	IP	START	END	DATA VALUE	--[L]	CIRCISID IE IT
IR .		IG	IW	FE	---	---	T	E[E]	IDIO NO.
IR		IE	ID	I	WDIBT	WDIBT	Y	V[X]C	T D
IR		IL	IS	X	#	*	P	N[C]O	? E
.		IK	I	/	ID	I	E	TP[F]	ID[E]
1239	1850 Sample 3 Temp 3	-	-	02	-	-	-	-	41 2
1240	1850 Sample 3 Temp 4	-	-	02	-	-	-	-	41 2
1241	1850 Sample 3 Temp 5	-	-	02	-	-	-	-	41 2
1242	1850 Sample 3 Temp 6	-	-	02	-	-	-	-	41 2
1243	1850 Sample 4 Temp 1	-	-	02	-	-	-	-	41 2
1244	1850 Sample 4 Temp 2	-	-	02	-	-	-	-	41 2
1245	1850 Sample 4 Temp 3	-	-	02	-	-	-	-	41 2
1246	1850 Sample 4 Temp 4	-	-	02	-	-	-	-	41 2
1247	1850 Sample 4 Temp 5	-	-	02	-	-	-	-	41 2
1248	1850 Sample 4 Temp 6	-	-	02	-	-	-	-	41 2
1249	1850 Sample 5 Temp 1	-	-	02	-	-	-	-	41 2
1250	1850 Sample 5 Temp 2	-	-	02	-	-	-	-	41 2
1251	1850 Sample 5 Temp 3	-	-	02	-	-	-	-	41 2
1252	1850 Sample 5 Temp 4	-	-	02	-	-	-	-	41 2
1253	1850 Sample 5 Temp 5	-	-	02	-	-	-	-	41 2
1254	1850 Sample 5 Temp 6	-	-	02	-	-	-	-	41 2
1255	1850 Sample 6 Temp 1	-	-	02	-	-	-	-	41 2
1256	1850 Sample 6 Temp 2	-	-	02	-	-	-	-	41 2
1257	1850 Sample 6 Temp 3	-	-	02	-	-	-	-	41 2
1258	1850 Sample 6 Temp 4	-	-	02	-	-	-	-	41 2
1259	1850 Sample 6 Temp 5	-	-	02	-	-	-	-	41 2
1260	1850 Sample 6 Temp 6	-	-	02	-	-	-	-	41 2
1261	1850 Stepping Motor Phase A Current	02	-	-	-	-	-	-	41 2
1262	1850 Stepping Motor Phase A Voltage	02	-	-	-	-	-	-	41 2
1263	1850 Stepping Motor Phase B Current	02	-	-	-	-	-	-	41 2
1264	1850 Stepping Motor Phase B Voltage	02	-	-	-	-	-	-	41 2
1265	1850 Furnace Linear Position	02	-	-	-	-	-	-	41 2
1266	1850 FTS Stepping Motor Temp	02	-	-	-	-	-	-	41 2
1267	1850 Rapid Translation Motor RPM	02	-	-	-	-	-	-	41 2
1268	1850 (Cold Guard Heater Current	1	02	-	-	-	-	-	41 2
		1	1	1	1	1	1	1	1
		3	4	4	4	5	5	6	6
		9	0	3	5	7	8	7	7
		3	6	7	1	3	5	2	8
		0	0	0	0	0	0	0	0

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 14 of 38)

			IC U	MN NM S T	DATA DESCRIPTION	I MON C	
			M S	SO O Y		REQ A	
			D A	G / G	P START END DATA VALUE	C R C S D E T	-----
			I G	W F E	----- T	D I O NO.	X A
			I E	D I	WD BT WD BT Y	V X C	T D
			L	S X	H P	N C O	? E
			K	/ D	E	T P F	ID E
			1269 850 Cold	Guard Heater Voltage	02		
			1270 850 Cold	Main Primary Heater Current	02		
			1271 850 Cold	Main Primary Heater Voltage	02		
			1272 850 Cold	Main Red Heater Current	02		
			1273 850 Cold	Main Red Heater Voltage	02		
			1274 850 Hot	Boost Heater Current	02		
			1275 850 Hot	Boost Heater Voltage	02		
			1276 850 Hot	Guard Heater Current	02		
			1277 850 Hot	Guard Heater Voltage	02		
			1278 850 Hot	Main Primary Heater Current	02		
			1279 850 Hot	Main Primary Heater Voltage	02		
			1280 850 Hot	Main Red Heater Current	02		
			1281 850 Hot	Main Red Heater Voltage	02		
			1282 850 Cold	Zone CJ Block Temp 1	02		
			1283 850 Cold	Zone CJ Block Temp 2	02		
			1284 850 Hot	Zone CJ Block Temp 1	02		
			1285 850 Hot	Zone CJ Block Temp 2	02		
			1286 850 Sample 1	CJ Block Temp 1	02		
			1287 850 Sample 1	CJ Block Temp 1	02		
			1288 850 Sample 2	CJ Block Temp 2	02		
			1289 850 Sample 2	CJ Block Temp 2	02		
			1290 850 Sample 3	CJ Block Temp 1	02		
			1291 850 Sample 3	CJ Block Temp 2	02		
			1292 850 Sample 4	CJ Block Temp 1	02		
			1293 850 Sample 4	CJ Block Temp 2	02		
			1294 850 Sample 5	CJ Block Temp 1	02		
			1295 850 Sample 5	CJ Block Temp 2	02		
			1296 850 Sample 6	CJ Block Temp 1	02		
			1297 850 Sample 6	CJ Block Temp 2	02		
			1298 850 Booster	Heater Control Temp 1	02		
			1	1	1	1	1
			0	9 0	3 4	4 4	4 4
			3	6 7	9 0	3 5	7 8

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 15 of 38)

TABLE 1.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 15 of 38)

ENT	C N	MN	NM	S T	DATA	DESCRIPTION	MON	C I
NO.	O	SO	OS	O Y			[REQ]	
R .	R .	D A	G .	P	START	END	DATA	VALUE
.	.	G	W	F	E	T	E	E
		U E	D	I	W D	B T Y	V X C	I A
		L	S	X	#	P	N C O	P B
		K	/	D	/	E	T P F	I L
								D E
1	299	850	Booster Heater Control Temp	2	02			
1	300	850	Cold Guard Heater Control Temp	1	02			
1	301	850	Cold Guard Heater Control Temp	2	02			
1	302	850	Cold Main Prim Htr Cntrl Temp	1	02			
1	303	850	Cold Main Prim Htr Cntrl Temp	2	02			
1	304	850	Cold Main Red Htr Control Temp	1	02			
1	305	850	Cold Main Red Htr Control Temp	2	02			
1	306	850	Hot Guard Heater Control Temp	1	02			
1	307	850	Hot Guard Heater Control Temp	2	02			
1	308	850	Hot Main Prim Htr Control Temp	1	02			
1	309	850	Hot Main Prim Htr Control Temp	2	02			
1	310	850	Hot Main Red Htr Control Temp	1	02			
1	311	850	Hot Main Red Htr Control Temp	2	02			
1	312	850	Indexing CAM Rotary Position		02			
1	313	850	Ampoule Alignment Arm Temp		02			
1	314	850	SEM Track Temp		02			
1	315	850	RTD Mux 1 Calibration - High		02			
1	316	850	RTD Mux 1 Calibration - Low		02			
1	317	850	RTD Mux 2 Calibration - High		02			
1	318	850	RTD Mux 2 Calibration - Low		02			
1	319	850	RTD Mux 3 Calibration - High		02			
1	320	850	RTD Mux 3 Calibration - Low		02			
1	321	850	RTD Mux 4 Calibration - High		02			
1	322	850	RTD Mux 4 Calibration - Low		02			
1	323	850	RTD Mux 5 Calibration - High		02			
1	324	850	RTD Mux 5 Calibration - Low		02			
1	325	850	RTD Mux 6 Calibration - High		02			
1	326	850	RTD Mux 6 Calibration - Low		02			
1	327	850	RTD Mux 7 Calibration - High		02			
1	328	850	RTD Mux 7 Calibration - Low		02			

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 17 of 38)

			ICIU	IMN	NM	SIT	DATA	DESCRIPTION	IMON	C					
ENT	C	N	MIS	SO	OS	JOY	--	--REQA	ICRC	SID	E	I	T	I	I
NO.	O	O	DA	G.	/G	P	START	END	DATA	VALU	--L	I	D	IO	I
..	.	.	I	G	/F	E	--	--	T	E	E	E	E	X	A
R			I	E	D	I	WD	BT	WD	BT	P	P	B	D	I
L			I	S	I	X	*	*	P	N	E	E	L	E	I
K			I	I	I	D	I	I	E	T	P	F	E	T	I
1359	1850	Unused													
1360	1850	Cold Guard Zone Setpoint Temp					02								
1361	1850	Cold Main Zone Setpoint Temp					02								
1362	1850	Booster Zone Setpoint Temp					02								
1363	1850	Hot Main Zone Setpoint Temp					02								
1364	1850	Hot Guard Zone Setpoint Temp					02								
1365	1850	Hot Guard Htr Calc Temp 1					02								
1366	1850	Cold Guard Htr Calc Temp 2					02								
1367	1850	Unused					02								
1368	1850	Unused					02								
1369	1850	Cold Main Prim Htr Calc Temp 1					02								
1370	1850	Cold Main Prim Htr Calc Temp 2					02								
1371	1850	Cold Main Red Htr Calc Temp 1					02								
1372	1850	Cold Main Red Htr Calc Temp 2					02								
1373	1850	Booster Htr Calc Temp 1					02								
1374	1850	Booster Htr Calc Temp 2					02								
1375	1850	Unused					02								
1376	1850	Unused					02								
1377	1850	Hot Main Prim Htr Calc Temp 1					02								
1378	1850	Hot Main Prim Htr Calc Temp 2					02								
1379	1850	Hot Main Red Htr Calc Temp 1					02								
1380	1850	Hot Main Red Htr Calc Temp 2					02								
1381	1850	Hot Guard Htr Calc Temp 1					02								
1382	1850	Hot Guard Htr Calc Temp 2					02								
1383	1850	Unused					02								
1384	1850	Unused					02								
1385	1850	Cold Guard Zone Act Temp					02								
1386	1850	Cold Main Zone Act Temp					02								
1387	1850	Booster Zone Act Temp					02								
1388	1850	Hot Main Zone Act Temp					02								

TABLE 2.7.2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 18 of 38)

			ICU	IMN	MISITI	DATA DESCRIPTION	MONIC	
ENTIC	N	NO.	IM	IS	SOIOSIO(Y)	DATA VALUE	REQ(A)	--
O	O	O	DIA	G.	/G	P START END	C RCSID	E T
I	R	.		I	G	W F E	E E .	D IO NO.
I	R	.	DESCRIPTION	I	E	D I WD BT Y	V X C	T D
I	.	.		L	S X	# P	N C O	? E
I	I	I		K	I D	# E	T P F	I L
							D	E
1389	850	Hot Guard Zone Act Temp	-	-	02	-	-	41 2
1390	850	Cold Guard Zone Delta Temp	-	-	02	-	-	41 2
1391	850	Cold Main Zone Delta Temp	-	-	02	-	-	41 2
1392	850	Booster Zone Delta Temp	-	-	02	-	-	41 2
1393	850	Hot Main Zone Delta Temp	-	-	02	-	-	41 2
1394	850	Hot Guard Zone Delta Temp	-	-	02	-	-	41 2
1395	850	Cold Guard Zone Uncpld Power	-	-	02	-	-	41 2
1396	850	(Cold Main Zone Uncpld Power	-	-	02	-	-	41 2
1397	850	Booster Zone Uncpld Power	-	-	02	-	-	41 2
1398	850	Hot Main Zone Uncpld Power	-	-	02	-	-	41 2
1399	850	Hot Guard Zone Uncpld Power	-	-	02	-	-	41 2
1400	850	(Cold Guard Zone Prop Power	-	-	02	-	-	41 2
1401	850	(Cold Main Zone Prop Power	-	-	02	-	-	41 2
1402	850	Booster Zone Prop Power	-	-	02	-	-	41 2
1403	850	Hot Main Zone Prop Power	-	-	02	-	-	41 2
1404	850	Hot Guard Zone Prop Power	-	-	02	-	-	41 2
1405	850	(Cold Guard Zone Int Power	-	-	02	-	-	41 2
1406	850	(Cold Main Zone Int Power	-	-	02	-	-	41 2
1407	850	Booster Zone Int Power	-	-	02	-	-	41 2
1408	850	Hot Main Zone Int Power	-	-	02	-	-	41 2
1409	850	Hot Guard Zone Int Power	-	-	02	-	-	41 2
1410	850	(Cold Guard Zone Power	-	-	02	-	-	41 2
1411	850	(Cold Main Zone Power	-	-	02	-	-	41 2
1412	850	Booster Zone Power	-	-	02	-	-	41 2
1413	850	Hot Main Zone Power	-	-	02	-	-	41 2
1414	850	Hot Guard Zone Power	-	-	02	-	-	41 2
1415	850	(Cold Guard Htr Calc Voltage	-	-	02	-	-	41 2
1416	850	Unused	-	-	02	-	-	41 2
1417	850	Cold Main Prim Htr Calc Voltage	-	-	02	-	-	41 2
1418	850	Cold Main Red Htr Calc Voltage	-	-	02	-	-	41 2
1	1				1	1	1	*
0	0	0			3 4	4 4	5 5	6 6
3	6	7			9 0	3 5	7 8	7 7

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 19 of 38)

		ICU	IMNI	MIS	T	DATA DESCRIPTION	IMONIC	REQA	-----
ENTC	N		SOL	SOY					CRCISID
NO.	O	ID	G.	/G	P	START	END	DATA VALUE	E T
IR .			W	FIE		---	---	T	DIO NO.
IR .		ID	I	W	WDIBT	WDIBTY	I	EIEI	X A
IR .		IS	X	I	I	P	I	VXIC	P B
IR .		IK	I	/D	I	E	I	NCIO	I L
IR .								TIPIFI	D E
419	850	Booster Htr Calc Voltage		02					41 2
420	850	Unused		02					41 2
421	850	Hot Main Prim Htr Calc Voltage		02					41 2
422	850	Hot Main Red Htr Calc Voltage		02					41 2
423	850	Hot Guard Htr Calc Voltage		02					41 2
424	850	Unused		02					41 2
425	850	Cold Guard Htr Act Current		02					41 2
426	850	Unused		02					41 2
427	850	Cold Main Prim Htr Act Current		02					41 2
428	850	Cold Main Red Htr Act Current		02					41 2
429	850	Booster Htr Act Current		02					41 2
430	850	Unused		02					41 2
431	850	Hot Main Prim Htr Act Current		02					41 2
432	850	Hot Main Red Htr Act Current		02					41 2
433	850	Hot Guard Htr Act Current		02					41 2
434	850	Unused		02					41 2
435	850	Cold Guard Htr Calc Resistance		02					41 2
436	850	Unused		02					41 2
437	850	Cold Main Prim Htr Calc Resistance		02					41 2
438	850	Cold Main Red Htr Calc Resistance		02					41 2
439	850	Booster Htr Resistance		02					41 2
440	850	Unused		02					41 2
441	850	HOT Main Prim Htr Calc Resistance		02					41 2
442	850	Hot Main Red Htr Calc Resistance		02					41 2
443	850	Hot Guard Htr Calc Resistance		02					41 2
444	850	Unused		02					41 2
445	850	Cold Guard Htr Limited Power		02					41 2
446	850	Unused		02					41 2
447	850	Cold Main Prim Htr Limited Power		02					41 2
448	850	Cold Main Red Htr Limited Power		02					41 2
				1	1	1	1	1	1
				3	4	4	4	5	6
				0	0	5	7	6	7
				9	0	3	8	7	8
				3	6	7		5	0

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 20 of 38)

			ICU	IMN NM S/T	DATA DESCRIPTION	IMON/C	
ENT C N	NO . O	IR .	IMIS	SO OS CY	-REQ/A	-----	-----
ENT C N	NO . O	IR .	DESCRIPTION	D/G /G P START END DATA VALUE	--- L	C R C S D E T	
ENT C N	NO . O	IR .		I G W F E ----- ----- T	E E .	D Y O (NO .	
ENT C N	NO . O	IR .		I E D I W D B T Y	V X C	I T D	
ENT C N	NO . O	IR .		I L S X # P	N C O	? E	
ENT C N	NO . O	IR .		I K I D I E	T P F		
ENT C N	NO . O	IR .		I C I D E			
449 850 Booster Htr Limited Power			102			141 2	
450 850 Unused			102			141 2	
451 850 Hot Main Prim Htr Limited Power			102			141 2	
452 850 Hot Main Red Htr Limited Power			102			141 2	
453 850 Hot Guard Htr Limited Power			102			141 2	
454 850 Unused			102			141 2	
455 850 Cold Guard Htr Des Current			102			141 2	
456 850 Unused			102			141 2	
457 850 Cold Main Prim Htr Des Current			102			141 2	
458 850 Cold Main Red Htr Des Current			102			141 2	
459 850 Booster Htr Des Current			102			141 2	
460 850 Unused			102			141 2	
461 850 Hot Main Prim Htr Des Current			102			141 2	
462 850 Hot Main Red Htr Des Current			102			141 2	
463 850 Hot Main Guard Htr Des Current			102			141 2	
464 850 Unused			102			141 2	
465 850 Cold Guard Zone Saturation Flag			02			141 2	
466 850 Cold Main Zone Saturation Flag			02			141 2	
467 850 Booster Zone Saturation Flag			02			141 2	
468 850 Hot Main Zone Saturation Flag			02			141 2	
469 850 Hot Guard Zone Saturation Flag			02			141 2	
470 850 Integral Power Fault Time			02			141 2	
471 850 Fault Sum Delta Power			02			141 2	
472 850 Fault Integral Gain			02			141 2	
473 850 Fault Proportional Gain			02			141 2	
474 850 Fault Intermediate Calc. Value 1			02			141 2	
475 850 Fault Intermediate Calc. Value 2			02			141 2	
476 850 Fault Delta Power - Previous			02			141 2	
477 850 Fault Delta Power - 2nd Previous			02			141 2	
478 850 Faulted Zone			102			141 2	
0 0 0			3 4	4 4 4	5 5 5	6 6 6	7 7 7
3 6 7			3 5 7	8 1 3	5 7	5 6 7	1 2 5
9 0							

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 2) of 38

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 22 of 38)

ENTIC N	NO.	DESCRIPTION	INN	INM	ISIT	DATA DESCRIPTION	MONIC	REQA
	O O		MIS	ISOIOSIOY				
R .	DIA	G . /G	P	S	START	END	DATA VALUE	--L
R	IG	IW	F	E	--	--	--T	CIRCISID IE IT
.	UE	D	I	WD	BT	WD	BT Y	DITO NO. IX IA
L	IS	X	#	I	P		VIXC	IT D P B
K	I	ID	E	E	TIP	F	INCIO	I L I
							D	E
1509 850 FF	Core Hold Down Not Extended		1	02				4 2
1510 850 FF	Core Hold Down Extended		1	02				4 2
1511 850 FF	Core HD Motor RCCB Off		1	02				4 2
1512 850 FF	Core HD Motor RCCB On		1	02				4 2
1513 850 FF	Ampoule Support Not Retracted		1	02				4 2
1514 850 FF	Ampoule Support Retracted		1	02				4 2
1515 850 FF	Ampoule Support Not Secure		1	02				4 2
1516 850 FF	Ampoule Support Secure		1	02				4 2
1517 850 FF	Ampoule Spt Plt Mtr RCCB Off		1	02				4 2
1518 850 FF	Ampoule Spt Plt Mtr RCCB On		1	02				4 2
1519 850 FF	Ampoule Align Not Retracted		1	02				4 2
1520 850 FF	Ampoule Align Retracted		1	02				4 2
1521 850 FF	PCS Utility RCCB Off		1	02				4 2
1522 850 FF	PCS Utility RCCB On		1	02				4 2
1523 850 FF	System Bus Relay Off		1	02				4 2
1524 850 FF	System Bus Relay On		1	02				4 2
1525 850 FF	Furnace Position Not Home		1	02				4 2
1526 850 FF	Furnace Position Home		1	02				4 2
1527 850 FF	Furn Extreme Trvl Not Exceeded		1	02				4 2
1528 850 FF	Furn Extreme Trvl Exceeded		1	02				4 2
1529 850 FF	Step Motor Drive RCCB Off		1	02				4 2
1530 850 FF	Step Motor Drive RCCB On		1	02				4 2
1531 850 FF	Step Motor Clutch RCCB Off		1	02				4 2
1532 850 FF	Step Motor Clutch RCCB On		1	02				4 2
1533 850 FF	Rapid Xlation Mtr RCCB Off		1	02				4 2
1534 850 FF	Rapid Xlation Mtr RCCB On		1	02				4 2
1535 850 FF	Rapid Xlation Clutch RCCB Off		1	02				4 2
1536 850 FF	Rapid Xlation Clutch RCCB On		1	02				4 2
1537 850 FF	Water Inlet Valve RCCB Off		1	02				4 2
1538 850 FF	Water Inlet Valve RCCB On		1	02				4 2
1	1		1	1	1	1	1	1
0	0	3 4	4 4	4 4	5 5	5 5	6 6 6	7 7 7
3	6 7	9 0	3 5	7 8	1 3	5 7	5 6 7	1 2 5 8

320REQ0007

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 23 of 38)

			ICU	MN	NM	S/T	DATA DESCRIPTION	MNC	MONIC	REQ/A	
ENTIC	N	.		IMIS	ISO1010(Y)						
NO.10	O			IDIA	IG./G.	P/START	END	DATA VALUE	--L	ICIRC	SID E T
IR .				IG	W	F/E	--	--	T	D10	NO. X A
IR				IUE	D	D	WD	BTWDIBTY		EIE	
IR.				IL	S	X	4	4	P	VXC	
IR				IKI	I	D			E	NCIO	
										TPIF	
										D	EI
1539	850	FF	Vacuum	Vent	Valve	Closed		02			
1540	850	FF	Vacuum	Vent	Valve	Open		02			
1541	850	FF	Vacuum	Vent	Vlv	RCCB Off		02			
1542	850	FF	Vacuum	Vent	Vlv	RCCB On		02			
1543	850	FF	IFEA	ABS	Press	2	RCCB Off	02			
1544	850	FF	IFEA	ABS	Press	2	RCCB On	02			
1545	850	FF	IFEA	ABS	Press	1	RCCB Off	02			
1546	850	FF	IFEA	ABS	Press	1	RCCB On	02			
1547	850	FF	Argon	Fill	Valve	Closed		02			
1548	850	FF	Argon	Fill	Valve	Open		02			
1549	850	FF	Argon	Fill	Valve	RCCB Off		02			
1550	850	FF	Argon	Fill	Valve	RCCB On		02			
1551	850	FF	SEM	Indexing	Jog	CW	Status	02			
1552	850	FF	SEM	Indexing	Jog	CCW	Status	02			
1553	850	FF	Ampoule	5	Ampoule	5	Failure	2	Status		
1554	850	FF	Ampoule	5	Ampoule	5	Failure	1	Status		
1555	850	FF	Ampoule	4	Ampoule	4	Failure	2	Status		
1556	850	FF	Ampoule	4	Ampoule	4	Failure	1	Status		
1557	850	FF	Ampoule	3	Ampoule	3	Failure	2	Status		
1558	850	FF	Ampoule	3	Ampoule	3	Failure	1	Status		
1559	850	FF	Ampoule	2	Ampoule	2	Failure	2	Status		
1560	850	FF	Ampoule	2	Ampoule	2	Failure	1	Status		
1561	850	FF	Ampoule	1	Ampoule	1	Failure	2	Status		
1562	850	FF	Ampoule	1	Ampoule	1	Failure	1	Status		
1563	850	FF	Water	Outlet	Valve	Bypass		02			
1564	850	FF	Water	Outlet	Valve	Normal		02			
1565	850	FF	Water	Outlet	Vlv	RCCB Off		02			
1566	850	FF	Water	Outlet	Vlv	RCCB On		02			
1567	850	FF	Water	Inlet	Valve	Bypass		02			
1568	850	FF	Water	Inlet	Valve	Normal		02			
1	1										
0	0	0									
3	6	7									

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 24 of 38)

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 25 of 38)

			ICLU	IMN	INM	S	T	DATA DESCRIPTION	IMONIC	REQ/A	ICRC SID	E	T
ENTC N	NO.	O/O	IMIS	ISO	OS	O/Y		END DATA VALUE	---	L	IDIO NO.	X	A
IR .	IR .	DESCRIPTION	IDIA	G.	I/G	P	START	T	E/E .	T D	P	B	
IR .	IR .		IDIE	I	W	D	BT	WD	BT Y	VIX/C	I? E	L	
IR .	IR .		IDL	I	S	I	X	I	P	INICIO	I?	E	
IR .	IR .		IKI	I	/	ID	I	E	T P/F	ID E/I	I	E	
1599	1850	FF	Peltier	Pulsing	Drv	RCCB	Off		02				
1600	1850	FF	Peltier	Pulsing	Drv	RCCB	On		02				
1601	1850	FF	SCS	Airflow	1	Status			02				
1602	1850	FF	PDS	Airflow	1	Status			02				
1603	1850	FF	PCS	Airflow	2	Status			02				
1604	1850	FF	PCS	Airflow	1	Status			02				
1605	1850	FF	Hot	Main	Red	Mod	B	RCCB	Off				
1606	1850	FF	Hot	Main	Red	Mod	B	RCCB	On				
1607	1850	FF	Hot	Main	Red	Mod	A	RCCB	Off				
1608	1850	FF	Hot	Main	Red	Mod	A	RCCB	On				
1609	1850	FF	Hot	Main	Prim	Mod	B	RCCB	Off				
1610	1850	FF	Hot	Main	Prim	Mod	B	RCCB	On				
1611	1850	FF	HotMain	Prim	Mod	A	RCCB	Off					
1612	1850	FF	HotMain	Prim	Mod	A	RCCB	On					
1613	1850	FF	Hot	Guard	Module	RCCB	Off		02				
1614	1850	FF	Hot	Guard	Module	RCCB	On		02				
1615	1850	FF	Hot	Boost	Mod	B	RCCB	Off					
1616	1850	FF	Hot	Boost	Mod	B	RCCB	On					
1617	1850	FF	Hot	Main	Prim	Htr	Ctl	Temp	1				
1618	1850	FF	Cold	Main	Red	Htr	Ctl	Temp	1				
1619	1850	FF	TC	Group	A	Calibration	Type	B					
1620	1850	FF	TC	Group	A	Calibration	Type	S					
1621	1850	FF	TC	Group	A	Calibration	Type	K					
1622	1850	FF	TC	Group	B	Guard	Heater	Ctl	Temp	2			
1623	1850	FF	Cold	Main	Prim	Htr	Ctl	Temp	2				
1624	1850	FF	Booster	Heater	Ctl	Temp	2						
1625	1850	FF	Hot	Main	Red	Htr	Ctl	Temp	2				
1626	1850	FF	Hot	Main	Prim	Htr	Ctl	Temp	2				
1627	1850	FF	Hot	Guard	Heater	Ctl	Temp	2					
1628	1850	FF	TC	Group	B	Calibration	Type	B					

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 26 of 38)

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 27 of 38)

		ICU	MN	NM	S[T]	DATA DESCRIPTION	I	MONIC	
		MIS	SO	OS	OY		REQ[A]		
		D/A	G.	/G	P	START	END	DATA VALUE	---[L]
		G	W	F	E	I	T	E E	CIRC SID E T
	DESCRIPTION	U E	D I	WD BT WD BT Y	IV X C	T D	P B A	D O NO.	X A
		L	S X	#	#	P	? E	I L	T P F
		K	/ D		E			D E	
ENTIC N		1659 850 FF	Sample 4	Temp 2		102			4 1 2
NO. O O		1660 850 FF	Sample 3	Temp 2		102			4 1 2
R .		1661 850 FF	Sample 2	Temp 2		102			4 1 2
R .		1662 850 FF	Sample 1	Temp 2		102			4 1 2
.		1663 850 FF	Sample 6	Temp 1		102			4 1 2
.		1664 850 FF	Sample 5	Temp 1		102			4 1 2
.		1665 850 FF	Sample 6	Temp 6		102			4 1 2
.		1666 850 FF	Sample 5	Temp 6		102			4 1 2
.		1667 850 FF	Sample 4	Temp 6		102			4 1 2
.		1668 850 FF	Sample 3	Temp 6		102			4 1 2
.		1669 850 FF	Sample 2	Temp 6		102			4 1 2
.		1670 850 FF	Sample 1	Temp 6		102			4 1 2
.		1671 850 FF	Sample 6	Temp 5		102			4 1 2
.		1672 850 FF	Sample 5	Temp 5		102			4 1 2
.		1673 850 FF	Sample 4	Temp 5		102			4 1 2
.		1674 850 FF	Sample 3	Temp 5		102			4 1 2
.		1675 850 FF	Sample 2	Temp 5		102			4 1 2
.		1676 850 FF	Sample 1	Temp 5		102			4 1 2
.		1677 850 FF	Sample 6	Temp 4		102			4 1 2
.		1678 850 FF	Sample 5	Temp 4		102			4 1 2
.		1679 850 FF	Sample 4	Temp 4		102			4 1 2
.		1680 850 FF	Sample 3	Temp 4		102			4 1 2
.		1681 850 FF	Sample 4	CJ Block Temp 1		102			4 1 2
.		1682 850 FF	Sample 3	CJ Block Temp 2		102			4 1 2
.		1683 850 FF	Sample 3	CJ Block Temp 1		102			4 1 2
.		1684 850 FF	Sample 2	CJ Block Temp 2		102			4 1 2
.		1685 850 FF	Sample 2	CJ Block Temp 1		102			4 1 2
.		1686 850 FF	Sample 1	CJ Block Temp 2		102			4 1 2
.		1687 850 FF	Sample 1	CJ Block Temp 1		102			4 1 2
.		1688 850 FF	RFM Water Outlet Temp			102			4 1 2
1		1	1	1	1	1	1	1	1
0		3	4	4	4	5	5	6	6
3		9	0	3	5	7	8	1	7
6		7						2	5
3								8	0

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 28 of 38)

		ICIU	MN	IN	MS	IT	DATA DESCRIPTION	IMONIC	
ENT	C N	IMIS	(SO)	SO	IO Y	-	REQ A		
NO.	IO O	IDIA	IG.	/G	P	START	END (DATA VALUE	-- L	CIRC(SID E T
R .	R .	I G	W	FILE	-	-	- T	E E .	D IOINO.
R .	R .	U E	D	I	WD BT WD BT Y	VIX C	T D	P B	I L
.	.	L	S	X	#	P	N C O ? E	T P F	D E
.	.	K	/	D	-	E	T P F	D E	D E
689	1850IFF	Cold Zone	CJ	Block Temp	2	1	102	1	1 41 2
690	1850IFF	Cold Zone	CJ	Block Temp	1	102	1	1	1 41 2
691	1850IFF	Hot Zone	CJ	Block Temp	1	102	1	1	1 41 2
692	1850IFF	Hot Zone	CJ	Block Temp	2	102	1	1	1 41 2
693	1850IFF	RPM	Hot End	Shell Temp		102	1	1	1 41 2
694	1850IFF	RPM	Cold End	Shell Temp		102	1	1	1 41 2
695	1850IFF	IFEA Water	Inlet	Temp		102	1	1	1 41 2
696	1850IFF	IFEA Water	Outlet	Temp		102	1	1	1 41 2
697	1850IFF	RTD Mux	3	Calibration	- Low	102	1	1	1 41 2
698	1850IFF	RTD Mux	3	Calibration	- High	102	1	1	1 41 2
699	1850IFF	RTD Mux	2	Calibration	- Low	102	1	1	1 41 2
700	1850IFF	RTD Mux	2	Calibration	- High	102	1	1	1 41 2
701	1850IFF	RTD Mux	1	Calibration	- Low	102	1	1	1 41 2
702	1850IFF	RTD Mux	1	Calibration	- High	102	1	1	1 41 2
703	1850IFF	IFEA Upper	Atmosphere	Temp		102	1	1	1 41 2
704	1850IFF	IFEA Lower	Atmosphere	Temp		102	1	1	1 41 2
705	1850IFF	FTS	Stepping Motor	Temp		102	1	1	1 41 2
706	1850IFF	SEM	Track	Temp		102	1	1	1 41 2
707	1850IFF	Ampoule Alignment	Arm	Temp		102	1	1	1 41 2
708	1850IFF	Sample	6	CJ	Block Temp	2	102	1	1 41 2
709	1850IFF	Sample	6	CJ	Block Temp	1	102	1	1 41 2
710	1850IFF	Sample	5	CJ	Block Temp	2	102	1	1 41 2
711	1850IFF	Sample	5	CJ	Block Temp	1	102	1	1 41 2
712	1850IFF	Sample	4	CJ	Block Temp	2	102	1	1 41 2
713	1850IFF	Cold Main	Red Heater	Current		102	1	1	1 41 2
714	1850IFF	Cold Main	Red Heater	Voltage		102	1	1	1 41 2
715	1850IFF	Cold Main	Primary Heater	Cur		102	1	1	1 41 2
716	1850IFF	Cold Main	Primary Heater	Volt		102	1	1	1 41 2
717	1850IFF	Cold Guard	Heater	Current		102	1	1	1 41 2
718	1850IFF	Cold Guard	Heater	Voltage		102	1	1	1 41 2
1	1	1	1	1	1	1	1	1	1
0	0	3 4	4	4	4	5	5	5	6 6 6
3	6 7	9 0	3 5	7 8	1 3	5	7	5 6 7	7 7 8

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 29 of 38)

		ICU	IMN	INMISITI	DATA DESCRIPTION	IMONC1	IMONC2
ENTIC N	NO.	IO O	SO	OSIO(Y)		REQ/A	
DESCRIPTION		ID/A	G./G	P/START	END (DATA VALUE)	--L	ICIRC/SID
		I/G	W	F/E	--T	E/E	I/T
1719 850 FF	RTD Mux 8	Calibration - Low		02			4 2
1720 850 FF	RTD Mux 8	Calibration - High		02			4 2
1721 850 FF	RTD Mux 7	Calibration - Low		02			4 2
1722 850 FF	RTD Mux 7	Calibration - High		02			4 2
1723 850 FF	RTD Mux 6	Calibration - Low		02			4 2
1724 850 FF	RTD Mux 6	Calibration - High		02			4 2
1725 850 FF	RTD Mux 5	Calibration - Low		02			4 2
1726 850 FF	RTD Mux 5	Calibration - High		02			4 2
1727 850 FF	RTD Mux 4	Calibration - Low		02			4 2
1728 850 FF	RTD Mux 4	Calibration - High		02			4 2
1729 850 FF	IFE A Lower Humidity			02			4 2
1730 850 FF	Rapid Translation Motor RPM			02			4 2
1731 850 FF	Indexing CAM Rotary Position			02			4 2
1732 850 FF	Furnace Linear Position			02			4 2
1733 850 FF	Stepping Motor Phase B Cur			02			4 2
1734 850 FF	Stepping Motor Phase B Volt			02			4 2
1735 850 FF	Stepping Motor Phase A Cur			02			4 2
1736 850 FF	Stepping Motor Phase A Volt			02			4 2
1737 850 FF	Hot Main Red Heater Current			02			4 2
1738 850 FF	Hot Main Red Heater Voltage			02			4 2
1739 850 FF	Hot Main Primary Heater Cur			02			4 2
1740 850 FF	Hot Main Primary Heater Volt			02			4 2
1741 850 FF	Hot Guard Heater Current			02			4 2
1742 850 FF	Hot Guard Heater Voltage			02			4 2
1743 850 FF	Hot Boost Heater Current			02			4 2
1744 850 FF	Hot Boost Heater Voltage			02			4 2
1745 850 FF	SMS Board Velocity Reading			02			4 2
1746 850 FF	Experiment Main Bus Voltage			02			4 2
1747 850 FF	Experiment Main Bus Current			02			4 2
1748 850 FF	IFE A Absolute Pressure 2			02			4 2
1	1	1	1	1	1	1	
0	0	0	3 4	4 4	4 4	5 5	6 6 6
3	6	7	9 0	3 7 8	1 3 5	7 7 7	7 7 8
						5 8	0

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 30 of 38)

			ICL	MN	NM	SIT	DATA DESCRIPTION	MON	C	
ENTIC	N		IMIS	ISOIOS	OY	-	REQA	---		-----
NO.	IO	O	IDIA	I.G.	I/G	P START	END DATA VALUE	-- L	C RCSID	E T
IR	.		IG	I.W	F E	-	- T	E E	D IOINO.	X A
IR	.		IUE	I.D	I.I	WD BT WD BT Y	D	V X C	T	P B
I.	.		IL	I.S	I.X	I.	P	N C O	? E	I L
I.	K		IK	I.Y	I.D	I.	E	T P F	I	D E
1749	850	FF	IFEA	Absolute Pressure	1		102			
1750	850	FF	IFEA	Upper Humidity			102			
1001	851	IRC	SEM	Index Motor	RCCB On Stat		102			
1002	851	IRC	SEM	Index Motor	RCCB Off Stat		102			
1003	851	IRC	Ampoule	Not Processing			102			
1004	851	IRC	Ampoule	Processing			102			
1005	851	IRC	Indexing Cam	Not Stowed			102			
1006	851	IRC	Indexing Cam	Stowed			102			
1007	851	IRC	Car Spacer	Plt Gap Lim-Not			102			
1008	851	IRC	Car Spacer	Plt Gap Lim			102			
1009	851	IRC	Car Trk	Extr Left Limit-Not			102			
1010	851	IRC	Car Trk	Extr Left Limit			102			
1011	851	IRC	Car Trk	Extr Right Lim-Not			102			
1012	851	IRC	Car Trk	Extr Right Lim			102			
1013	851	IRC	Ampoule	Align Mtr RCCB Off			102			
1014	851	IRC	Ampoule	Align Mtr RCCB On			102			
1015	851	IRC	Ampoule	Align Not Extended			102			
1016	851	IRC	Ampoule	Align Extended			102			
1017	851	IRC	Ampoule	Align Not Retracted			102			
1018	851	IRC	Ampoule	Align Retracted			102			
1019	851	IRC	Ampoule	Spt Plt Mtr RCCB Off			102			
1020	851	IRC	Ampoule	Spt Plt Mtr RCCB On			102			
1021	851	IRC	Ampoule	Support Not Secure			102			
1022	851	IRC	Ampoule	Support Secure			102			
1023	851	IRC	Ampoule	Support Not Retracted			102			
1024	851	IRC	Ampoule	Support Retracted			102			
1025	851	IRC	Core HD	Motor RCCB Off			102			
1026	851	IRC	Core HD	Motor RCCB On			102			
1027	851	IRC	Core Hold Down	Not Extended			102			
1028	851	IRC	Core Hold Down	Extended			102			

1
0
3
9

0
0
5
0

6
7

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 31 of 38)

			ICU	IMN	NM	S/T	DATA DESCRIPTION	IMON/C		REQ/A	- - -	
ENTIC N	NO.	IO O	IMIS	ISO	OS	O/Y	---	---	---	---	- - -	
			IDIA	G.	/G	P	START	END	DATA VALUE	--L	C RC SID E T	
			IG	IW	FE	---	---	---	T	E E -	D IO NO. X A	
			UE	ID	I	WD	BT	WD	BT	VIX C	T D	
			LI	IS	X	#	IP	IE	NC O	? E	P B	
			RK	I	/	ID	I	I	TP F	I	I L	
										D E		
1029	1851	RC	Core Hold Down	Not Retracted		I	02					41 2
1030	1851	RC	Core Hold Down	Retracted		I	02					41 2
1031	1851	RC	Fail Safe	Brake RCCB Off		I	02					41 2
1032	1851	RC	Fail Safe	Brake RCCB On		I	02					41 2
1033	1851	RC	Rapid Xlation	Clutch RCCB Off		I	02					41 2
1034	1851	RC	Rapid Xlation	Clutch RCCB On		I	02					41 2
1035	1851	RC	Rapid Xlation	Mtr RCCB Off		I	02					41 2
1036	1851	RC	Rapid Xlation	Mtr RCCB On		I	02					41 2
1037	1851	RC	Step Motor	Clutch RCCB Off		I	02					41 2
1038	1851	RC	Step Motor	Clutch RCCB On		I	02					41 2
1039	1851	RC	Step Motor	Drive RCCB Off		I	02					41 2
1040	1851	RC	Step Motor	Drive RCCB On		I	02					41 2
1041	1851	RC	Furn Extrme	Trvl Not Exceeded		I	02					41 2
1042	1851	RC	Furn Extrdm	Trvl Exceeded		I	02					41 2
1043	1851	RC	Furnace	Position Not Home		I	02					41 2
1044	1851	RC	Furnace	Position Home		I	02					41 2
1045	1851	RC	System Bus	Relay Off		I	02					41 2
1046	1851	RC	System Bus	Relay On		I	02					41 2
1047	1851	RC	PCS Utility	RCCB Off		I	02					41 2
1048	1851	RC	PCS Utility	RCCB On		I	02					41 2
1049	1851	RC	SEM Indexing	Jog CW Status		I	02					41 2
1050	1851	RC	SEM Indexing	Jog CCW Status		I	02					41 2
1051	1851	RC	Argon Fill	Valve RCCB Off		I	02					41 2
1052	1851	RC	Argon Fill	Valve RCCB On		I	02					41 2
1053	1851	RC	Argon Fill	Valve Closed		I	02					41 2
1054	1851	RC	Argon Fill	Valve Open		I	02					41 2
1055	1851	RC	IFEA ABS	Press 1 RCCB Off		I	02					41 2
1056	1851	RC	IFEA ABS	Press 1 RCCB On		I	02					41 2
1057	1851	RC	IFEA ABS	Press 2 RCCB Off		I	02					41 2
1058	1851	RC	IFEA ABS	Press 2 RCCB On		I	02					41 2
1						I	1					
0						3	4					
3						9	0					
6						3	5					
7						7	8					
						1	3					
						5	7					
						5	6					
						7	7					
						7	7					
						8	0					

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 32 of 38)

ENTIC N		INMIS	ICIU	DATA DESCRIPTION	MONIC	MONIC	MONIC
NO.	O	DESCRIPTION	ID	REQ A	REQ B	REQ C	REQ D
IR.	059	851 IRC Vacuum Vent VIV RCCB Off	I02	I	I	I	I
IR.	1060	851 IRC Vacuum Vent VIV RCCB On	I02	I	I	I	I
.	1061	851 IRC Vacuum Vent Valve Closed	I02	I	I	I	I
.	1062	851 IRC Vacuum Vent Valve Open	I02	I	I	I	I
.	1063	851 IRC Water Inlet Valve RCCB Off	I02	I	I	I	I
.	1064	851 IRC Water Inlet Valve RCCB On	I02	I	I	I	I
.	1065	851 IRC Water Inlet Valve Bypass	I02	I	I	I	I
.	1066	851 IRC Water Inlet Valve Normal	I02	I	I	I	I
.	1067	851 IRC Water Outlet VIV RCCB Off	I02	I	I	I	I
.	1068	851 IRC Water Outlet VIV RCCB On	I02	I	I	I	I
.	1069	851 IRC Water Outlet Valve Bypass	I02	I	I	I	I
.	1070	851 IRC Water Outlet Valve Normal	I02	I	I	I	I
.	1071	851 RC Ampoule 1 Failure 2 Status	I02	I	I	I	I
.	1072	851 RC Ampoule 1 Failure 1 Status	I02	I	I	I	I
.	1073	851 RC Ampoule 2 Failure 2 Status	I02	I	I	I	I
.	1074	851 RC Ampoule 2 Failure 1 Status	I02	I	I	I	I
.	1075	851 RC Ampoule 3 Failure 2 Status	I02	I	I	I	I
.	1076	851 RC Ampoule 3 Failure 1 Status	I02	I	I	I	I
.	1077	851 RC Ampoule 4 Failure 2 Status	I02	I	I	I	I
.	1078	851 RC Ampoule 4 Failure 1 Status	I02	I	I	I	I
.	1079	851 RC Ampoule 5 Failure 2 Status	I02	I	I	I	I
.	1080	851 RC Ampoule 5 Failure 1 Status	I02	I	I	I	I
.	1081	851 RC Ampoule 6 Failure 2 Status	I02	I	I	I	I
.	1082	851 RC Ampoule 6 Failure 1 Status	I02	I	I	I	I
.	1083	851 RC Cartridge 1 Failure 2 Status	I02	I	I	I	I
.	1084	851 RC Cartridge 1 Failure 1 Status	I02	I	I	I	I
.	1085	851 RC Cartridge 2 Failure 2 Status	I02	I	I	I	I
.	1086	851 RC Cartridge 2 Failure 1 Status	I02	I	I	I	I
.	1087	851 RC Cartridge 3 Failure 2 Status	I02	I	I	I	I
.	1088	851 RC Cartridge 3 Failure 1 Status	I02	I	I	I	I

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 33 of 38)

		CIU	MN	NMISIT	DATA DESCRIPTION	MONIC	
ENTIC	NI	M S	SO OS QY		REQ A		-----
NO.	OI	D A	G ./ G	P START	END DATA VALUE	--- L	CRC SID E T
IR .		I G	W F E	D T	---- T	E E .	DIO NO. X A
IR .		U E	D T	WD BT WD BT Y	V X C	T D	P B
.		L	S X	#	N C O	2 E	T L
.		K	Y D	P	T P F	1	D E
				E			
1089	1851	RC Cartridge	4	Failure	2 Status	102	1 41 2
1090	1851	RC Cartridge	4	Failure	1 Status	102	
1091	1851	RC Cartridge	5	Failure	2 Status	102	
1092	1851	RC Cartridge	5	Failure	1 Status	102	
1093	1851	RC Cartridge	6	Failure	2 Status	102	
1094	1851	RC Cartridge	6	Failure	1 Status	102	
1095	1851	RC Mech Pulsing	Mod	RCCB	On	102	
1096	1851	RC Mech Pulsing	Mod	RCCB	Off	102	
1097	1851	RC Peltier	Pulsing	Drv	RCCB Off	102	
1098	1851	RC Peltier	Pulsing	Drv	RCCB On	102	
1099	1851	RC Peltier	Conn Motor	RCCB	Off	102	
1100	1851	RC Peltier	Conn Motor	RCCB	On	102	
1101	1851	RC Peltier	Conn	Extended	-Not	102	
1102	1851	RC Peltier	Conn	Extended		102	
1103	1851	RC Peltier	Conn	Retracted	-Not	102	
1104	1851	RC Peltier	Conn	Retracted		102	
1105	1851	RC Cold Guard	Mod	RCCB	Off	102	
1106	1851	RC Cold Guard	Mod	RCCB	On	102	
1107	1851	RC Cold Main	Prim	Mod	RCCB Off	102	
1108	1851	RC Cold Main	Prim	Mod	RCCB On	102	
1109	1851	RC Cold Main	Red	Mod	RCCB Off	102	
1110	1851	RC Cold Main	Red	Mod	RCCB On	102	
1111	1851	RC Hot Boost	Mod	A	RCCB Off	102	
1112	1851	RC Hot Boost	Mod	A	RCCB On	102	
1113	1851	RC Hot Boost	Mod	B	RCCB Off	102	
1114	1851	RC Hot Boost	Mod	B	RCCB On	102	
1115	1851	RC Hot Guard	Module	RCCB	Off	102	
1116	1851	RC Hot Guard	Module	RCCB	On	102	
1117	1851	RC HotMain	Prim	Mod	A RCCB Off	102	
1118	1851	RC HotMain	Prim	Mod	A RCCB On	102	

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 34 of 38)

ENT	C	N	I	ICU	IMN	NMISITI	DATA DESCRIPTION	MONIC	/
NO.	O			IMIS	ISOOSIOY			REQA	-----
IR	.	DESCRIPTION		DIA	G.	/G	P START END DATA VALUE	CRC SID	E T
IR	.			IG	W	F E	- - T	D IO NO.	X A
IR	.			IUE	ID	I	WD BT WD BT Y	T D	P B
IR	.			LI	S	X	- - P	V X C	I L
IR	.			IKI	I	D	- - E	N C O	I T
IR	.			IKI	I	/	- - E	T P F	I D
1119	851	IRC	Hot	Main	Prim	Mod B	RCCB Off	02	1
1120	851	IRC	Hot	Main	Prim	Mod B	RCCB On	02	1
1121	851	IRC	Hot	Main	Red	Mod A	RCCB Off	02	1
1122	851	IRC	Hot	Main	Red	Mod A	RCCB On	02	1
1123	851	IRC	Hot	Main	Red	Mod B	RCCB Off	02	1
1124	851	IRC	Hot	Main	Red	Mod B	RCCB On	02	1
1125	851	IRC	PCS	Airflow	2	Status	02	1	1 1 2
1126	851	IRC	PCS	Airflow	1	Status	02	1	1 1 2
1127	851	IRC	SCS	Airflow	1	Status	02	1	1 1 2
1128	851	IRC	PDS	Airflow	1	Status	02	1	1 1 2
1129	851	IRC	IFE	A	Coolant	Flow #2	Status	02	1
1130	851	IRC	IFE	A	Coolant	Flow #1	Status	02	1
1131	851	IRC	TC	Group B	Calibration	Type S	02	1	1 1 2
1132	851	IRC	TC	Group B	Calibration	Type K	02	1	1 1 2
1133	851	IRC	Hot	Guard	Heater	Ctl Temp 2	02	1	1 1 2
1134	851	IRC	TC	Group B	Calibration	Type B	02	1	1 1 2
1135	851	IRC	Hot	Main	Red	Htr Ctl Temp 2	02	1	1 1 2
1136	851	IRC	Hot	Main	Prim	Htr Ctl Temp 2	02	1	1 1 2
1137	851	IRC	Cold	Main	Prim	Htr Ctl Temp 2	02	1	1 1 2
1138	851	IRC	Booster	Heater	Ctl Temp 2	02	1	1	1 1 2
1139	851	IRC	TC	Group A	Calibration	Type K	02	1	1 1 2
1140	851	IRC	Cold	Guard	Heater	Ctl Temp 2	02	1	1 1 2
1141	851	IRC	TC	Group A	Calibration	Type B	02	1	1 1 2
1142	851	IRC	TC	Group A	Calibration	Type S	02	1	1 1 2
1143	851	IRC	Hot	Main	Prim	Htr Ctl Temp 1	02	1	1 1 2
1144	851	IRC	Cold	Main	Red	Htr Ctl Temp 1	02	1	1 1 2
1145	851	IRC	TC	Group C	Calibration	Type K	02	1	1 1 2
1146	851	IRC	Hot	Main	Red	Htr Ctl Temp 1	02	1	1 1 2
1147	851	IRC	TC	Group C	Calibration	Type B	02	1	1 1 2
1148	851	IRC	TC	Group C	Calibration	Type S	02	1	1 1 2
1	1	1	1	1	1	1	1	1	1
0	0	0	3	4	4	4	5	5	6
3	6	7	9	0	3	5	7	5	6

TABLE 2-7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 33 of 38)

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 36 of 38)

ENTIC N	ICIU	MNIN	MNSITI	DATA DESCRIPTION	MONIC	/
NO. IO O	IMIS	SOOS	OY		REQ A	
R .	ID A	G . /G	P START	END (DATA VALUE)	-- L	CIRC SID (E. T)
R .	I G	I W	F E	-- T	E E	D IO NO.
R .	I U E	I D	I WDI BT WDIBT Y	I	X A	T D
.	I L I	I S	X	#	V X C	P B
.	I K I	I /	I D I	I	N C O	I L
.				I E I	T P F	D E
179 851 RC Sample 6 Temp 4			102			
180 851 RC Sample 5 Temp 4			02			
181 851 RC Sample 2 Temp 5			02			
182 851 RC Sample 1 Temp 5			02			
183 851 RC Sample 4 Temp 5			02			
184 851 RC Sample 3 Temp 5			02			
185 851 RC Sample 6 Temp 5			02			
186 851 RC Sample 5 Temp 5			02			
187 851 RC Sample 2 Temp 6			02			
188 851 RC Sample 1 Temp 6			02			
189 851 RC Sample 4 Temp 6			02			
190 851 RC Sample 3 Temp 6			02			
191 851 RC Sample 5 Temp 6			02			
192 851 RC Sample 6 Temp 6			02			
193 851 RC IFEA Water Inlet Temp			02			
194 851 RC IFEA Water Outlet Temp			02			
195 851 RC RFM Hot End Shell Temp			02			
196 851 RC RFM Cold End Shell Temp			02			
197 851 RC Hot Zone CJ Block Temp 1			02			
198 851 RC Hot Zone CJ Block Temp 2			02			
199 851 RC Cold Zone CJ Block Temp 2			02			
200 851 RC Cold Zone CJ Block Temp 1			02			
201 851 RC Sample 1 CJ Block Temp 1			02			
202 851 RC RFM Water Outlet Temp			02			
203 851 RC Sample 2 CJ Block Temp 1			02			
204 851 RC Sample 1 CJ Block Temp 2			02			
205 851 RC Sample 3 CJ Block Temp 1			02			
206 851 RC Sample 2 CJ Block Temp 2			02			
207 851 RC Sample 4 CJ Block Temp 1			02			
208 851 RC Sample 3 CJ Block Temp 2			102			
1 1			1			
0 0	3 4	4 4	4 4	5 5	5 5	1 1
3 6	9 0	3 5	7 8	1 3	5 7	6 6 6 7 7 7 8
7					5 6 7	1 2 5 8 0

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 3 of 38)

TABLE 2.7-2. SIGNAL INTERFACE DEFINITION EXPANSION (Sheet 38 of 38)

ENTIC N NO.	ENTIC O O	DESCRIPTION	CIU	INN NM SITI	DATA DESCRIPTION	MONIC	REQA
G.	I/G		IMIS	S0 0 0 0 Y	DATA VALUE	---	---
I	W	P START END	ID A	P	L	C R S D E T	C R S D E T
F	E	T	G	E	E	D IO NO. X A	D IO NO. X A
I	D	T	U E	W DBT WD BT Y	V X C	T D	P B
S	X	P	L	S X #	N C O	? E	I L
I	D	E	K	/ D	T P F	/	D E
1239	851	IRC Cold Main Red Heater Current		02			4 1 2
1240	851	IRC Cold Main Red Heater Voltage		02			4 1 2
1241	851	IRC Hot Boost Heater Current		02			4 1 2
1242	851	IRC Hot Boost Heater Voltage		02			4 1 2
1243	851	IRC Hot Guard Heater Current		02			4 1 2
1244	851	IRC Hot Guard Heater Voltage		02			4 1 2
1245	851	IRC Hot Main Primary Heater Cur		02			4 1 2
1246	851	IRC Hot Main Primary Heater Volt		02			4 1 2
1247	851	IRC Hot Main Red Heater Current		02			4 1 2
1248	851	IRC Hot Main Red Heater Voltage		02			4 1 2
1249	851	IRC Stepping Motor Phase A Cur		02			4 1 2
1250	851	IRC Stepping Motor Phase A Volt		02			4 1 2
1251	851	IRC Stepping Motor Phase B Cur		02			4 1 2
1252	851	IRC Stepping Motor Phase B Volt		02			4 1 2
1253	851	IRC Indexing CAM Rotary Position		02			4 1 2
1254	851	IRC Furnace Linear Position		02			4 1 2
1255	851	IRC IFEA Lower Humidity		02			4 1 2
1256	851	IRC Rapid Translation Motor RPM		02			4 1 2
1257	851	IRC IFEA Absolute Pressure 1		02			4 1 2
1258	851	IRC IFEA Upper Humidity		02			4 1 2
1259	851	IRC Experiment Main Bus Current		02			4 1 2
1260	851	IRC IFEA Absolute Pressure 2		02			4 1 2
1261	851	IRC SMS Board Velocity Reading		02			4 1 2
1262	851	IRC Experiment Main Bus Voltage		02			4 1 2
1263	851	Process Elapsed Time - Seconds		02			4 1 2
1264	851	Go/NoGo Error Override		02			4 1 2
1265	851	ICGF System State		02			4 1 2
1266	851	Auto Pressure Ctl		02			4 1 2
				1	1	1	1
				3 4	4 4 4	5 5 5	6 6 6
0	0 0			9 0	3 5 7 8	1 3 5 7	7 7 7 8
3	6 7					5 6 7	1 2 0

TABLE 2.7-3. EVENT/EXCEPTION MONITOR REQUIREMENTS

IE	NIC	NEMR	MONITOR VALUES	IM	MESSAGE	ERROR	MESSAGE	LOW	TIOC	///	///
IN	UIO	Q1XOA		S	G	LOWER	MSG.	MSG.	N	UO	---
IT	M R	I CNT		I	G	LIMIT/	(HIGH/SINGLE)	MSG.	E	T	---
IR	B R	I PIE	UPPER	I	C	EXPT'D		MSG.	R	E	A
Y	E	I TT	LIMIT	L	C	STATE		MSG.	I	T	B
R	I IO	I IO		S	I	I		MSG.	I	L	P
I	I OR	I OR		I	I	I		MSG.	I	D	E
I	I N	I N		I	I	I		MSG.	I	I	I
1207 106 001	-073	-128 1 HI	WATER TEMP	4 1 14					4 1	1300 1 0 CGF	4 1 4
1208 106 001	-077	-128 1 HI	HUMIDITY LWR	4 1 16					4 1	300 1 0 CGF	4 1 4
1209 106 001	-077	-128 1 HI	HUMIDITY UPR	4 1 18					4 1	300 1 0 CGF	4 1 4
1210 106 001	-004	-128 1 HI	ATMOS TEMP	4 1 1A					4 1	300 1 0 MAN	4 1 4
1211 106 001	-073	-128 1 HI	CLD END TEMP	4 1 1C					4 1	300 1 0 MAN	4 1 4
1212 106 001	-073	-128 1 HI	HOT END TEMP	4 1 1E					4 1	300 1 0 MAN	4 1 4
1215 106 001	-009	-073 1 HI	IFEA PRES 1	4 1 20	LO	FEA PRES	1	4 1	21 300 1 0 CGF	4 1 4	
1216 106 001	-009	-073 1 HI	IFEA PRES 2	4 1 22	LO	FEA PRES	2	4 1	23 300 1 0 CGF	4 1 4	
1219 106 001	+105	-128 1 HI	MAIN CURRENT	4 1 24					4 1	300 1 0 CGF	4 1 4
1220 106 001	+076	+018 1 HI	MAIN VOLTAGE	4 1 26	LO	MAIN VOLTAGE	4 1 27	300 1 0 CGF	4 1		
1223 106 001		1 1 LO	WATER FLOW	4 1 28					4 1	300 1 0 CGF	4 1 4
1224 106 001		1 1 LO	WATER FLOW	4 1 2A					4 1	300 1 0 CGF	4 1 4
1237 106 001		1 1 NO	AVIONICS AIR	4 1 2C					4 1	300 1 0 CGF	4 1 4
1238 106 001		1 1 NO	AVIONICS AIR	4 1 2E					4 1	300 1 0 CGF	4 1 4
1239 106 001		1 1 NO	AVIONICS AIR	4 1 30					4 1	300 1 0 CGF	4 1 4
1240 106 001		1 1 NO	AVIONICS AIR	4 1 32					4 1	300 1 0 CGF	4 1 4
1265 106 001		1 1 WTR	OUT BYPASS	4 1 34					4 1	300 1 0 MAN	4 1 4
1266 106 001		0 1 WTR	OUT BYPASS	4 1 36					4 1	300 1 0 MAN	4 1 4
1267 106 001		1 1 WTR	IN BYPASS	4 1 38					4 1	300 1 0 MAN	4 1 4
1268 106 001		0 1 WTR	IN BYPASS	4 1 3A					4 1	300 1 0 FTS	4 1 4
1287 106 001		1 1 EXTRM	TRL LIM	4 1 3C					4 1	300 1 0 FTS	4 1 4
1288 106 001		0 1 EXTRM	TRL LIM	4 1 3E					4 1	300 1 0 CGF	4 1 4
1319 106 001		0 1 EXP	BUS PWR OFF	4 1 40					4 1	300 1 0 CGF	4 1 4
1320 106 001		1 1 EXP	BUS PWR OFF	4 1 42					4 1	300 1 0 CGF	4 1 4

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 1 of 20)

IE	N	C	NCT	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS					
IN	U	O	OAY						
IT	M	R	LP						
IR	B	IE							
Y	E	R							
I	A	T							
I	A	A							
I	I	T							
I	I	0							
I	10	I							
I	IN	I							
1001	850	PCI	+0000000+001	+1000000+011					141 61
1002	850	PCI	+0000000+001	+1000000+011					141 61
1003	850	PCI	+0000000+001	+1000000+011					141 61
1004	850	PCI	+0000000+001	+1000000+011					141 61
1005	850	PCI	+0000000+001	+1000000+011					141 61
1138	850	PCI	+0000000+001	+1000000+011					141 61
1139	850	PCI	+0000000+001	+1000000+011					141 61
1140	850	PCI	+0000000+001	+1000000+011					141 61
1141	850	PCI	+0000000+001	+1000000+011					141 61
1142	850	PCI	+0000000+001	+1000000+011					141 61
1143	850	PCI	+0000000+001	+1000000+011					141 61
1144	850	PCI	+0000000+001	+1000000+011					141 61
1145	850	PCI	+0000000+001	+1000000+011					141 61
1146	850	PCI	+0000000+001	+1000000+011					141 61
1147	850	PCI	+0000000+001	+1000000+011					141 61
1148	850	PCI	+0000000+001	+1000000+011					141 61
1149	850	PCI	+0000000+001	+1000000+011					141 61
1150	850	PCI	+0000000+001	+1000000+011					141 61
1151	850	PCI	+0000000+001	+1000000+011					141 61
1152	850	PCI	+0000000+001	+1000000+011					141 61
1153	850	PCI	+0000000+001	+1000000+011					141 61
1154	850	PCI	+0000000+001	+1000000+011					141 61
1155	850	PCI	+0000000+001	+1000000+011					141 61
1156	850	PCI	+0000000+001	+1000000+011					141 61
1157	850	PCI	+0000000+001	+1000000+011					141 61
1158	850	PCI	+0000000+001	+1000000+011					141 61
1159	850	PCI	+0000000+001	+1000000+011					141 61
1160	850	PCI	+0000000+001	+1000000+011					141 61
1161	850	PCI	+0000000+001	+1000000+011					141 61
1162	850	PCI	+0000000+001	+1000000+011					141 61
1163	850	PCI	+0000000+001	+1000000+011					141 61

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 2 of 20)

IE	NIC	NICT	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS					
IN	UO	OAY	A0	A1	A2	A3	A4	A5
IT	MIR	IIP	164 850 IPC +00000000+00 +10000000+01					
IR	B R	IIE	165 850 IPC +00000000+00 +10000000+01					
Y	E	B	166 850 IPC +00000000+00 +10000000+01					
R	R	A	167 850 IPC +00000000+00 +10000000+01					
T	A	IT	168 850 IPC +00000000+00 +10000000+01					
I	I	1	169 850 IPC +00000000+00 +10000000+01					
O	O	0	170 850 IPC +00000000+00 +10000000+01					
N	N	1	171 850 IPC +00000000+00 +10000000+01					
			172 850 IPC +00000000+00 +10000000+01					
			173 850 IPC +00000000+00 +10000000+01					
			174 850 IPC +00000000+00 +10000000+01					
			175 850 IPC +00000000+00 +10000000+01					
			176 850 IPC +00000000+00 +10000000+01					
			177 850 IPC +00000000+00 +10000000+01					
			178 850 IPC +00000000+00 +10000000+01					
			179 850 IPC +00000000+00 +10000000+01					
			180 850 IPC +00000000+00 +10000000+01					
			181 850 IPC +00000000+00 +10000000+01					
			182 850 IPC +00000000+00 +10000000+01					
			183 850 IPC +00000000+00 +10000000+01					
			184 850 IPC +00000000+00 +10000000+01					
			185 850 IPC +00000000+00 +10000000+01					
			187 850 IPC +00000000+00 +10000000+01					
			188 850 IPC +00000000+00 +10000000+01					
			189 850 IPC +00000000+00 +10000000+01					
			190 850 IPC +00000000+00 +10000000+01					
			191 850 IPC +00000000+00 +10000000+01					
			192 850 IPC +00000000+00 +10000000+01					
			193 850 PC +00000000+00 +10000000+01					
			194 850 PC +00000000+00 +10000000+01					
			195 850 PC +00000000+00 +10000000+01					

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 3 of 20)

IE NIC NICTI		CALIBRATION COEFFICIENTS/LINEAR SEGMENTS																																																											
IN VIO OIAYI	IT MIR ILP	X A	P B	L	I	B	D	A5	A4	A3	A2	A1	A0	R	I	Y E	IR	IT	I	II	IO	IN																																							
1196.850	1PC1+00000000+001+50000000-011	1197.850	1PC1+00000000+001+50000000-011	1198.850	1PC1+00000000+001+50000000-011	1199.850	1PC1+00000000+001+50000000-011	1200.850	1PC1+00000000+001+50000000-011	1201.850	1PC1+00000000+001+50000000-011	1202.850	1PC1+00000000+001+50000000-011	1203.850	1PC1+00000000+001+50000000-011	1204.850	1PC1+00000000+001+50000000-011	1205.850	1PC1+00000000+001+50000000-011	1206.850	1PC1+00000000+001+50000000-011	1207.850	1PC1+00000000+001+50000000-011	1208.850	1PC1+00000000+001+50000000-011	1209.850	1PC1+00000000+001+50000000-011	1210.850	1PC1+00000000+001+50000000-011	1211.850	1PC1+00000000+001+50000000-011	1212.850	1PC1+00000000+001+36630000-011	1213.850	1PC1+00000000+001+9768000-021	1214.850	1PC1+00000000+001+2442000-011	1215.850	1PC1+00000000+001+2442000-011	1216.850	1PC1+00000000+001+7326000-021	1217.850	1PC1+00000000+001+7326000-021	1218.850	1PC1-2419000+031+2325500+011+9104500-031+2442500-061	1219.850	1PC1-2419000+031+2325500+011+9104500-031+2442500-061	1220.850	1PC1-2414600+031+2297900+001+1211300-041-4356500-091	1221.850	1PC1-2414600+031+2297900+001+1211300-041-4356500-091	1222.850	1PC1-2414600+031+2297900+001+1211300-041-4356500-091	1223.850	1PC1-2414600+031+2297900+001+1211300-041-4356500-091	1224.850	1PC1-2414600+031+2297900+001+1211300-041-4356500-091	1225.850	1PC1+1493200+021+1381000+031-8505200+01+9220100+001+5766400-011+1394700-021	1226.850	1PC1+1493200+021+1381000+031-8505200+01+9220100+001+5766400-011+1394700-021

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 4 of 20)

IE	NIC	NCTI	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS					
IN	UO	OAY	A0	A1	A2	A3	A4	A5
227 850 IPC +1493200+02 +1381000+03 -8505200+01 +9220100+00 +9220100+00 -5706400-01 +1394700-02	41 6							
228 850 IPC +1493200+02 +1381000+03 -8505200+01 +9220100+00 +9220100+00 -5706400-01 +1394700-02	41 6							
229 850 IPC +1493200+02 +1381000+03 -8505200+01 +9220100+00 +9220100+00 -5706400-01 +1394700-02	41 6							
230 850 IPC +1493200+02 +1381000+03 -8505200+01 +9220100+00 +9220100+00 -5706400-01 +1394700-02	41 6							
231 850 IPC +1493200+02 +1381000+03 -8505200+01 +9220100+00 +9220100+00 -5706400-01 +1394700-02	41 6							
232 850 IPC +1493200+02 +1381000+03 -8505200+01 +9220100+00 +9220100+00 -5706400-01 +1394700-02	41 6							
233 850 IPC +1493200+02 +1381000+03 -8505200+01 +9220100+00 +9220100+00 -5706400-01 +1394700-02	41 6							
234 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
235 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
236 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
237 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
238 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
239 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
240 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
241 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
242 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
243 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
244 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
245 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
246 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
247 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
248 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
249 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
250 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
251 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
252 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
253 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
254 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
255 850 IPC -1089200+02 +2705600+02 -1504300+00 +1159800-02 +4582500-04 -5337600-06	41 6							
256 850 IPC +1493200+02 +1381000+03 -8505200+01 +9220100+00 -5706400-01 +1394700-02	41 6							
257 850 IPC +1493200+02 +1381000+03 -8505200+01 +9220100+00 -5706400-01 +1394700-02	41 6							
1	1	1	1	1	1	1	1	1
0	0	0	1	2	4	5	6	7
3	5	7	8	9	0	1	2	3
								9 0

TABLE 2.7.4. POIC DISPLAY REQUIREMENTS (Sheet 5 of 20)

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 6 of 20)

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 7 of 20)

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 8 of 20)

TABLE 2.7.4. POIC DISPLAY REQUIREMENTS (Sheet 9 of 20)

IE	NIC	NICT	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS					
IN	UIO	OIAY	IT	MIR	ILP	IE		
R	BIR	-	R	R	-	E		
I	Y	B	I	R	-	I		
I	R	-	I	A	-	I		
I	T	-	I	A0	-	A1		
I	I	-	I	-	-	-		
I	O	-	I	-	-	-		
I	IN	-	I	-	-	-		
1391	850	PCI +00000000+0 0 +10000000+0 1						141 6
1392	850	PCI +00000000+0 0 +10000000+0 1						141 6
1393	850	PCI +00000000+0 0 +10000000+0 1						141 6
1394	850	PCI +00000000+0 0 +10000000+0 1						141 6
1395	850	PCI +00000000+0 0 +10000000+0 1						141 6
1396	850	PCI +00000000+0 0 +10000000+0 1						141 6
1397	850	PCI +00000000+0 0 +10000000+0 1						141 6
1398	850	PCI +00000000+0 0 +10000000+0 1						141 6
1399	850	PCI +00000000+0 0 +10000000+0 1						141 6
1400	850	PCI +00000000+0 0 +10000000+0 1						141 6
1401	850	PCI +00000000+0 0 +10000000+0 1						141 6
1402	850	PCI +00000000+0 0 +10000000+0 1						141 6
1403	850	PCI +00000000+0 0 +10000000+0 1						141 6
1404	850	PCI +00000000+0 0 +10000000+0 1						141 6
1405	850	PCI +00000000+0 0 +10000000+0 1						141 6
1406	850	PCI +00000000+0 0 +10000000+0 1						141 6
1407	850	PCI +00000000+0 0 +10000000+0 1						141 6
1408	850	PCI +00000000+0 0 +10000000+0 1						141 6
1409	850	PCI +00000000+0 0 +10000000+0 1						141 6
1410	850	PCI +00000000+0 0 +10000000+0 1						141 6
1411	850	PCI +00000000+0 0 +10000000+0 1						141 6
1412	850	PCI +00000000+0 0 +10000000+0 1						141 6
1413	850	PCI +00000000+0 0 +10000000+0 1						141 6
1414	850	PCI +00000000+0 0 +10000000+0 1						141 6
1415	850	PCI +00000000+0 0 +10000000+0 1						141 6
1416	850	PCI +00000000+0 0 +10000000+0 1						141 6
1417	850	PCI +00000000+0 0 +10000000+0 1						141 6
1418	850	PCI +00000000+0 0 +10000000+0 1						141 6
1419	850	PCI +00000000+0 0 +10000000+0 1						141 6
1420	850	PCI +00000000+0 0 +10000000+0 1						141 6
1421	850	PCI +00000000+0 0 +10000000+0 1						141 6
1422	850	PCI +00000000+0 0 +10000000+0 1						141 6
1423	850	PCI +00000000+0 0 +10000000+0 1						141 6

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 10 of 20)

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 11 of 20)

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 12 of 20)

IE	N1C	N1CT	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS			
(N1U)(O1AY)	(L1P)	(I1E)	A0	A1	A2	A3
I016 851 PC +00000001+00 +1000000+01						
017 851 PC +0000000+00 +1000000+01						
I018 851 PC +00000000+00 +1000000+01						
019 851 PC +00000000+00 +1000000+01						
I020 851 PC +00000000+00 +1000000+01						
021 851 PC +00000000+00 +1000000+01						
I022 851 PC +0000000+00 +1000000+01						
023 851 PC +0000000+00 +1000000+01						
I024 851 PC +0000000+00 +1000000+01						
025 851 PC +0000000+00 +1000000+01						
I026 851 PC +0000000+00 +1000000+01						
027 851 PC +0000000+00 +1000000+01						
I028 851 PC +0000000+00 +1000000+01						
029 851 PC +0000000+00 +1000000+01						
I030 851 PC +0000000+00 +1000000+01						
031 851 PC +0000000+00 +1000000+01						
I032 851 PC +0000000+00 +1000000+01						
033 851 PC +0000000+00 +1000000+01						
I034 851 PC +0000000+00 +1000000+01						
035 851 PC +0000000+00 +1000000+01						
I036 851 PC +0000000+00 +1000000+01						
037 851 PC +0000000+00 +1000000+01						
I038 851 PC +0000000+00 +1000000+01						
039 851 PC +0000000+00 +1000000+01						
I040 851 PC +0000000+00 +1000000+01						
041 851 PC +0000000+00 +1000000+01						
I042 851 PC +0000000+00 +1000000+01						
043 851 PC +0000000+00 +1000000+01						
I044 851 PC +0000000+00 +1000000+01						
045 851 PC +0000000+00 +1000000+01						
I046 851 PC +0000000+00 +1000000+01						
1 1 1	1	1	1	1	1	1
0 0 0	1	2	4	5	6	7
3 5 7	8	9	0	1	2	3
						9 0

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 13 of 20)

IE	NIC	NICT	CALIBRATION COEFFICIENTS/LINEAR SEGMENTS					
IN	U10	O1AY	A0	A1	A2	A3	A4	A5
IT	MIR	LP1						
IR	B1R	IE1						
IY	E1	B1						
IR	R1	R1						
IA		IA1						
IT		IT1						
IO		IO1						
IN		IN1						
IE47	851	IPC1+00000000+001+10000000+01						
IE48	851	IPC1+00000000+001+10000000+01						
IE49	851	IPC1+00000000+001+10000000+01						
IE50	851	IPC1+00000000+001+10000000+01						
IE51	851	IPC1+00000000+001+10000000+01						
IE52	851	IPC1+00000000+001+10000000+01						
IE53	851	IPC1+00000000+001+10000000+01						
IE54	851	IPC1+00000000+001+10000000+01						
IE55	851	IPC1+00000000+001+10000000+01						
IE56	851	IPC1+00000000+001+10000000+01						
IE57	851	IPC1+00000000+001+10000000+01						
IE58	851	IPC1+00000000+001+10000000+01						
IE59	851	IPC1+00000000+001+10000000+01						
IE60	851	IPC1+00000000+001+10000000+01						
IE61	851	IPC1+00000000+001+10000000+01						
IE62	851	IPC1+00000000+001+10000000+01						
IE63	851	IPC1+00000000+001+10000000+01						
IE64	851	IPC1+00000000+001+10000000+01						
IE65	851	IPC1+00000000+001+10000000+01						
IE66	851	IPC1+00000000+001+10000000+01						
IE67	851	IPC1+00000000+001+10000000+01						
IE68	851	IPC1+00000000+001+10000000+01						
IE69	851	IPC1+00000000+001+10000000+01						
IE70	851	IPC1+00000000+001+10000000+01						
IE71	851	IPC1+00000000+001+10000000+01						
IE72	851	IPC1+00000000+001+10000000+01						
IE73	851	IPC1+00000000+001+10000000+01						
IE74	851	IPC1+00000000+001+10000000+01						
IE75	851	IPC1+00000000+001+10000000+01						
IE76	851	IPC1+00000000+001+10000000+01						
IE77	851	IPC1+00000000+001+10000000+01						

TABLE 2.7.4. POIC DISPLAY REQUIREMENTS (Sheet 14 of 20)

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 15 of 20)

CALIBRATION COEFFICIENTS/LINEAR SEGMENTS																														
IE	NIC	NICT	1	2	3	4	5	6	7																					
I	N	U	O	A	I																									
T	M	R	L	P																										
R	B	R	I	E																										
Y	E	B																												
R	I																													
A	T																													
T	A																													
I	T																													
O	I																													
IN	I																													
A0	A1	A2	A3	A4	A5																									
109 851 PC1+0000000+001+1000000+01	110 851 PC1+0000000+001+1000000+01	111 851 PC1+0000000+001+1000000+01	112 851 PC1+0000000+001+1000000+01	113 851 PC1+0000000+001+1000000+01	114 851 PC1+0000000+001+1000000+01	115 851 PC1+0000000+001+1000000+01	116 851 PC1+0000000+001+1000000+01	117 851 PC1+0000000+001+1000000+01	118 851 PC1+0000000+001+1000000+01	119 851 PC1+0000000+001+1000000+01	120 851 PC1+0000000+001+1000000+01	121 851 PC1+0000000+001+1000000+01	122 851 PC1+0000000+001+1000000+01	123 851 PC1+0000000+001+1000000+01	124 851 PC1+0000000+001+1000000+01	125 851 PC1+0000000+001+1000000+01	126 851 PC1+0000000+001+1000000+01	127 851 PC1+0000000+001+1000000+01	128 851 PC1+0000000+001+1000000+01	129 851 PC1+0000000+001+1000000+01	130 851 PC1+0000000+001+1000000+01	131 851 PC1+0000000+001+1000000+01	132 851 PC1+0000000+001+1000000+01	133 851 PC1+0000000+001+1000000+01	134 851 PC1+0000000+001+1000000+01	135 851 PC1+0000000+001+1000000+01	136 851 PC1+0000000+001+1000000+01	137 851 PC1+0000000+001+1000000+01	138 851 PC1+0000000+001+1000000+01	139 851 PC1+0000000+001+1000000+01

TABLE 2.7.4. POIC DISPLAY REQUIREMENTS (Sheet 16 of 20)

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 17 of 20)

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 18 of 20)

CALIBRATION COEFFICIENTS/LINEAR SEGMENTS									
E	NIC	NCT	I	O	Y	A	P	B	C
N	U	O	I	A					
M	R	L	P						
R	B	R	E						
I	Y	E	B						
R	I	R							
A	T	A	A0	A1	A2	A3	A4	A5	
I	I	I							
O	O	I							
N	N	N							
1	2	2	2	2	2	2	2	2	2
2	0	2	0	2	0	2	0	2	0
3	0	3	0	3	0	3	0	3	0
4	1	4	1	4	1	4	1	4	1
5	1	5	1	5	1	5	1	5	1
6	0	6	0	6	0	6	0	6	0
7	0	7	0	7	0	7	0	7	0
8	1	8	1	8	1	8	1	8	1
9	1	9	1	9	1	9	1	9	1
10	1	10	1	10	1	10	1	10	1
11	1	11	1	11	1	11	1	11	1
12	1	12	1	12	1	12	1	12	1
13	1	13	1	13	1	13	1	13	1
14	1	14	1	14	1	14	1	14	1
15	1	15	1	15	1	15	1	15	1
16	1	16	1	16	1	16	1	16	1
17	1	17	1	17	1	17	1	17	1
18	1	18	1	18	1	18	1	18	1
19	1	19	1	19	1	19	1	19	1
20	1	20	1	20	1	20	1	20	1
21	1	21	1	21	1	21	1	21	1
22	1	22	1	22	1	22	1	22	1
23	1	23	1	23	1	23	1	23	1
24	1	24	1	24	1	24	1	24	1
25	1	25	1	25	1	25	1	25	1
26	1	26	1	26	1	26	1	26	1
27	1	27	1	27	1	27	1	27	1
28	1	28	1	28	1	28	1	28	1
29	1	29	1	29	1	29	1	29	1
30	1	30	1	30	1	30	1	30	1
31	1	31	1	31	1	31	1	31	1
32	1	32	1	32	1	32	1	32	1

TABLE 2.7-4. POIC DISPLAY REQUIREMENTS (Sheet 19 of 20)

TABLE 2.7.4. POIC DISPLAY REQUIREMENTS (Sheet 20 of 20)

LINEAR COEFFICIENTS/LINEAR SEGMENTS	
NIC	NCT
IN UO	OAY
IT MIR	LPJ
IR BIR	IEI
YEI	IB
RI	R
I	A
T	A0
I	A1
O	A2
N	A3
	A4
	A5
1265.851	1PC1+0000000+001+1000000+011
1	1
1	1
0	1
0	2
3	4
5	5
7	6
8	7
9:	8

TABLE 2.7-5. POI LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 1 of 14)

TABLE 2.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 2 of 14)

IC NI	WARNING VALUES IE NIO OIMT IN UIR IN UIR IT MR	(YELLOW LINE) IOY INP	Critical Values (RED LINE)	EXCEPTION MONITOR MESSAGE	IDI STATE CODE
1029 850					11111
1030 850					IDI STATE CODE11111
1031 850					
1032 850					
1033 850					
1034 850					
1035 850					
1036 850					
1037 850					
1038 850					
1039 850					
1040 850					
1041 850					
1042 850					
1043 850					
1044 850					
1045 850					
1046 850	EM			1 NO AVIONICS AIR - POS #1	
1047 850	EM			1 NO AVIONICS AIR - PCS #1	
1048 850					
1049 850					
1050 850					
1051 850					
1052 850	EM			1 LO IFEA WATER FLOW #1	
1053 850	EM			1 NO AVIONICS AIR - SCS #1	
1054 850					
1055 850					
1056 850					
1057 850					
1058 850					
1059 850					
1060 850					
1061 850					
1	1	1	1	1	1
0 0	1	2	2	6	1
3 5	2	0	8	6	2
					9
					3

TABLE 2.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 3 of 14)

IC N	WARNING VALUES (YELLOW LINE)	CRITICAL VALUES (RED LINE)	DI STATE CODE
I E NIO O(MT)			1//1//1
I N U(R O(Y)			--1-
I T M(R	I N P		-E T
I R B	I I E	UPPER	I X A
I Y E	I T	LOWER	I P B
I R	I O	LIMIT	I I L
I R	I R	LIMIT	I D E
1062 850			
1063 850			ON OFF 41 7
1064 850			OFF ON 41 7
1065 850			OFF OFF 41 7
1066 850			ON ON 41 7
1067 850			OFF ON 41 7
1068 850			ON OFF 41 7
1069 850			OFF OFF 41 7
1070 850			ON OFF 41 7
1071 850			OFF ON 41 7
1072 850			ON OFF 41 7
1073 850			OFF ON 41 7
1074 850			ON OFF 41 7
1075 850			OFF ON 41 7
1076 850			ON OFF 41 7
1077 850			OFF ON 41 7
1078 850			YES NO 41 7
1079 850			NO YES 41 7
1080 850			YES NO 41 7
1081 850			NO YES 41 7
1082 850			YES NO 41 7
1083 850			NO YES 41 7
1084 850			ICLS OPEN 41 7
1085 850			OPEN CLS 41 7
1086 850			ON OFF 41 7
1087 850			OFF ON 41 7
1088 850			ON OFF 41 7
1089 850			OFF ON 41 7
1090 850			ON OFF 41 7
1091 850			OFF ON 41 7
1092 850			ON OFF 41 7
1093 850			OFF ON 41 7
1094 850			ON OFF 41 7
1	1	1	1 1 1 1
0	0	1	2 2 3 3
3	5	2	0 8 6 8
			6 6 7 7
			2 9 1 3

POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 4 of 14)

TABLE 2.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 5 of 14)

IC N	WARNING VALUES IE NIO OIMT (YELLOW LINE)	Critical Values (RED LINE)	DI STATE CODE
N VIR	IOY		1///1
IT MIR	INP		1E IT
IR B	IE	UPPER LIMIT	1E IA
YE	IT	LOWER LIMIT	IP IB
R	O	LIMIT	1I IL
	R	EXPECTED STATE	ID IE
1128 850			141171
1129 850			141171
1130 850			141171
1131 850			141171
1132 850			141171
1133 850			141171
1134 850			141171
1135 850			141171
1136 850			141171
1137 850			141171
1186 850			141171
1200 850 EM			141171
1212 850 LS	3740	3740	141171
1213 850 LS	3358	2396	141171
1214 850 LS	410	819	141171
1215 850 LS	410	819	141171
1216 850 LS	1911	887	141171
1217 850 LS	1911	887	141171
1218 850 LS	1954	2035	141171
1219 850 LS	1954	2035	141171
1220 850 LS	504	585	141171
1221 850 LS	827	907	141171
1222 850 LS	827	907	141171
1223 850 LS	827	907	141171
1224 850 LS	827	907	141171
1261 850 LS	2007	2007	141171
1262 850 LS	2163	2163	141171
1263 850 LS	2007	2007	141171
1264 850 LS	2163	2163	141171
1266 850 LS	827	1067	141171
1268 850 LS	3003	3003	141171
1269 850 LS	1536	1536	141171
1270 850 LS	3003	3003	141171
1	1	1	1
0 0	1	2	3 3
3 5	2	0	6 8
6	2	9	1 3

TABLE 2.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 6 of 14)

	IC N	WARNING VALUES (YELLOW LINE)	Critical Values (RED LINE)		DI STATE CODE	
	IE NIO OMT	OY			0 =	1 =
	IN UIR	OY			E T	X A
IT M	NP				P BI	I L
IR B	IE	UPPER	LOWER	LOWER	I D EI	
YE	IT	LIMIT	LIMIT	LIMIT / EXPECTED		
RI	O			STATE		
	IR					
127118501LS	1536		1536	HI COLD PRIM HTR VOLTAGE		
127218501LS	3003		3003	HI COLD RED HTR CURRENT		
127318501LS	1536		1536	HI COLD RED HTR VOLTAGE		
127418501LS	3003		3003	HI BOOST HTR CURRENT		
127518501LS	3072		3072	HI BOOST HTR VOLTAGE		
127618501LS	3003		3003	HI HOT GUARD HTR CURRENT		
127718501LS	1536		1536	HI HOT GUARD HTR VOLTAGE		
127818501LS	3003		3003	HI HOT PRIM HTR CURRENT		
127918501LS	3072		3072	HI HOT PRIM HTR VOLTAGE		
128018501LS	3003		3003	HI HOT RED HTR CURRENT		
128118501LS	3072		3072	HI HOT RED HTR VOLTAGE		
128218501LS	827		907	HI CJ TEMP - COLD ZONE #1		
128318501LS	827		907	HI CJ TEMP - COLD ZONE #2		
128418501LS	827		907	HI CJ TEMP - HOT ZONE #1		
128518501LS	827		907	HI CJ TEMP - HOT ZONE #2		
128618501LS	827		907	HI CJ TEMP - SAMPLE 1 SENSOR 1		
128718501LS	827		907	HI CJ TEMP - SAMPLE 1 SENSOR 2		
128818501LS	827		907	HI CJ TEMP - SAMPLE 2 SENSOR 1		
128918501LS	827		907	HI CJ TEMP - SAMPLE 2 SENSOR 2		
129018501LS	827		907	HI CJ TEMP - SAMPLE 3 SENSOR 1		
129118501LS	827		907	HI CJ TEMP - SAMPLE 3 SENSOR 2		
129218501LS	827		907	HI CJ TEMP - SAMPLE 4 SENSOR 1		
129318501LS	827		907	HI CJ TEMP - SAMPLE 4 SENSOR 2		
129418501LS	827		907	HI CJ TEMP - SAMPLE 5 SENSOR 1		
129518501LS	827		907	HI CJ TEMP - SAMPLE 5 SENSOR 2		
129618501LS	827		907	HI CJ TEMP - SAMPLE 6 SENSOR 1		
129718501LS	827		907	HI CJ TEMP - SAMPLE 6 SENSOR 2		
131318501LS	987		1227	HI ALIGN ARM TEMP		
131418501LS	827		907	HI SEM TRACK TEMP		
146518501					NO	YES
146618501					NO	YES
146718501					NO	YES
146818501					NO	YES
	1	1	1	1	1	1
	0	0	2	2	6	6
	3	5	2	8	2	9
						8
						3

TABLE 2.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 7 of 14)

IC	N	WARNING VALUES (YELLOW LINE)	Critical Values (RED LINE)	EXCEPTION MONITOR MESSAGE	DI STATE CODE
I	E NIO QINT	OY			11111
I	N U R	OY			11111
I	T M R	INP			11111
I	R B	IE	UPPER	LOWER	IE IT
I	Y E	T	LIMIT	LIMIT	IX IA
I	R	O			IP IB
I	R	R			IL IL
					ID IE
1469	850				NO • YES 14117
1489	850				OK IFAIL 14117
1490	850				OK IFAIL 14117
1491	850				OK IFAIL 14117
1492	850				OK IFAIL 14117
1493	850				OK IFAIL 14117
1494	850				OK IFAIL 14117
1495	850				OK IFAIL 14117
1496	850				OK IFAIL 14117
1497	850				OK IFAIL 14117
1498	850				OK IFAIL 14117
1499	850				OK IFAIL 14117
1500	850				OK IFAIL 14117
1501	850				OK IFAIL 14117
1502	850				OK IFAIL 14117
1503	850				OK IFAIL 14117
1504	850				OK IFAIL 14117
1505	850				OK IFAIL 14117
1506	850				OK IFAIL 14117
1507	850				OK IFAIL 14117
1508	850				OK IFAIL 14117
1509	850				OK IFAIL 14117
1510	850				OK IFAIL 14117
1511	850				OK IFAIL 14117
1512	850				OK IFAIL 14117
1513	850				OK IFAIL 14117
1514	850				OK IFAIL 14117
1515	850				OK IFAIL 14117
1516	850				OK IFAIL 14117
1517	850				OK IFAIL 14117
1518	850				OK IFAIL 14117
1519	850				OK IFAIL 14117
1520	850				OK IFAIL 14117
		1	1	1	1 1 1
		0	0	1	6 6 6
		3	5	2	7 7 7
					8 8 8
					9 1 3

TABLE 2.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 8 of 14)

IC	NI	WARNING VALUES		CRITICAL VALUES		EXCEPTION MONITOR MESSAGE	STATE CODE
		(E NIO OINT)	(YELLOW LINE)	(IN UIR)	(RED LINE)		
IN	OUT	LOW	HIGH	LOW	HIGH	LIMIT/LIMIT	STATE
I521	I850						
I522	I850						
I523	I850						
I524	I850						
I525	I850						
I526	I850						
I527	I850						
I528	I850						
I529	I850						
I530	I850						
I531	I850						
I532	I850						
I533	I850						
I534	I850						
I535	I850						
I536	I850						
I537	I850						
I538	I850						
I539	I850						
I540	I850						
I541	I850						
I542	I850						
I543	I850						
I544	I850						
I545	I850						
I546	I850						
I547	I850						
I548	I850						
I549	I850						
I550	I850						
I551	I850						
I552	I850						
I553	I850						

TABLE 2.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 9 of 14)

IC_N	WARNING VALUES (YELLOW LINE)	CRITICAL VALUES (RED LINE)	EXCEPTION MONITOR MESSAGE	DI STATE CODE
IE_NIO_OIMT IN_UIR_IYI				I E T
IT_MIR_NP IR_BI_IIE	UPPER LIMIT	LOWER LIMIT	UPPER LIMIT / EXPECTED STATE	I P B I L D E I
Y_E_I R_I I_R	LIMIT	LIMIT		
1554 850				OK FAIL 41 7
1555 850				OK FAIL 41 7
1556 850				OK FAIL 41 7
1557 850				OK FAIL 41 7
1558 850				OK FAIL 41 7
1559 850				OK FAIL 41 7
1560 850				OK FAIL 41 7
1561 850				OK FAIL 41 7
1562 850				OK FAIL 41 7
1563 850				OK FAIL 41 7
1564 850				OK FAIL 41 7
1565 850				OK FAIL 41 7
1566 850				OK FAIL 41 7
1567 850				OK FAIL 41 7
1568 850				OK FAIL 41 7
1569 850				OK FAIL 41 7
1570 850				OK FAIL 41 7
1571 850				OK FAIL 41 7
1572 850				OK FAIL 41 7
1573 850				OK FAIL 41 7
1574 850				OK FAIL 41 7
1575 850				OK FAIL 41 7
1576 850				OK FAIL 41 7
1577 850				OK FAIL 41 7
1578 850				OK FAIL 41 7
1579 850				OK FAIL 41 7
1580 850				OK FAIL 41 7
1581 850				OK FAIL 41 7
1582 850				OK FAIL 41 7
1583 850				OK FAIL 41 7
1584 850				OK FAIL 41 7
1585 850				OK FAIL 41 7
1586 850				OK FAIL 41 7
				1 1 1 1 1
0 0	1	2	2	6 6 7 7 8 8
3 5	2	0	8 6 8	2 9 1 3

TABLE 2.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 10 of 14)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	2																		

TABLE 2.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 11 of 14)

TABLE 2.7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 12 of 14)

TABLE 2-7-5. POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 13 of 14)

		CRITICAL VALUES		EXCEPTION MONITOR MESSAGE		STATE CODE	
		(RED LINE)		(YELLOW LINE)			
		IC	NI	IE	NIO	OIMT	IT
IN	UR	IOY					
IT	M	R	NP	IE	UPPER	LOWER	LOWER
TR	B	I		T	LIMIT	LIMIT	LIMIT /
YE	E	I		T	LIMIT	LIMIT	EXPECTED
RI	O	I					STATE
RI	R	I					
1686	1850	1	1	1	1	1	1
1687	1850	1	1	1	1	1	1
1688	1850	1	1	1	1	1	1
1689	1850	1	1	1	1	1	1
1690	1850	1	1	1	1	1	1
1691	1850	1	1	1	1	1	1
1692	1850	1	1	1	1	1	1
1693	1850	1	1	1	1	1	1
1694	1850	1	1	1	1	1	1
1695	1850	1	1	1	1	1	1
1696	1850	1	1	1	1	1	1
1697	1850	1	1	1	1	1	1
1698	1850	1	1	1	1	1	1
1699	1850	1	1	1	1	1	1
1700	1850	1	1	1	1	1	1
1701	1850	1	1	1	1	1	1
1702	1850	1	1	1	1	1	1
1703	1850	1	1	1	1	1	1
1704	1850	1	1	1	1	1	1
1705	1850	1	1	1	1	1	1
1706	1850	1	1	1	1	1	1
1707	1850	1	1	1	1	1	1
1708	1850	1	1	1	1	1	1
1709	1850	1	1	1	1	1	1
1710	1850	1	1	1	1	1	1
1711	1850	1	1	1	1	1	1
1712	1850	1	1	1	1	1	1
1713	1850	1	1	1	1	1	1
1714	1850	1	1	1	1	1	1
1715	1850	1	1	1	1	1	1
1716	1850	1	1	1	1	1	1
1717	1850	1	1	1	1	1	1
1718	1850	1	1	1	1	1	1

POIC LIMIT SENSING/EXCEPTION MONITOR REQUIREMENTS (Sheet 14 of 14)



2.8. FLIGHT SOFTWARE REQUIREMENTS

This section of the Experiment/Facility Requirements Document (E/FRD) defines the Space Station Furnace Facility (SSFF) Data Management System (DMS) software functions required to support the Furnace Module-1. Furnace Module-1 will require the SSFF Furnace Control Unit (FCU) and Furnace Actuator Unit (FAU) software to provide networking, data processing, storage and data acquisition and control for Furnace Module-1. The following subsections define the required resources and data handling requirements of Furnace Module-1.

2.8.1 COMMAND SUPPORT

The SSFF software will support the issuance of commands by the Furnace Module-1 application software or commands issued by Tier 1 or the SSFF Core Control Unit (CCU).

2.8.2 DATA ACQUISITION

The SSFF software will support the acquisition of the Furnace Module-1 data defined in Section 2.7 of this E/FRD.

2.8.3 DATA PROCESSING

The SSFF software shall support limited processing of Furnace Module-1 data defined in Section 2.7 of this E/FRD.

2.8.4 DATA ROUTING/FORMATTING

The SSFF software shall support formatting and routing of Furnace Module-1 data, defined in Section 2.7 of this E/FRD, to the SSFF CCU.

2.8.5 DOWNLOADING APPLICATION SOFTWARE AND DATA

The SSFF software shall support downloading of Furnace Module-1 application software and data.

2.8.6 DOWNLOADING ANCILLARY DATA

The SSFF software shall support the retrieval and downloading of ancillary data to the Furnace Module-1 application software.

2.8.7 FDIR SUPPORT

The SSFF software shall provide fault detection, isolation, and recovery (FDIR) support for Furnace Module-1.

2.8.8 OPERATING SYSTEM SERVICES

The SSFF software shall provide operating system services for the Furnace Module-1 application software.

2.8.9 HEALTH AND STATUS DATA

The SSFF shall acquire health and status data from the Furnace Module-1 application software for SSFF storage or transfer to the SSF.

2.9. PHYSICAL INTEGRATION

This section describes the Furnace Module-1 integration/deintegration requirements and flow. Figure 2.9-1 illustrates the Furnace Module-1 physical integration activity flow from the beginning of prelaunch site activities, through deintegration after return from space.

Table 2.9-1 provides the integration facility requirements for each stage of integration. Table 2.9-2 describes the requirements and activities at each step of the integration process.




FIGURE 2.9-1. PHYSICAL INTEGRATION FLOW

TABLE 2.9-1. FURNACE MODULE-1 GROUND PROCESSING REQUIREMENTS
(Sheet 1 of 2)

- Experiment/Facility Preintegration
- Experiment/Facility Preparation
- Postmission Requirements

Description of Planned Activities:

Functional tests, sample loading, and closeout will be performed after the EAC is mounted on the rotation fixture.

Total Floor Space Required Including Space for GSE: 2000 ft²

Ceiling Height Required: 10 ft

Overhead Crane Required: ✓ Yes No Hook Height 8 ft

Facility Power Required:

<u>✓</u>	120 V, 1 F, 60 Hz
<u>✓</u>	208 V, 3 F, 60 Hz
<u>✓</u>	Other 220 V, Single Phase, 60 Hz

Other Facility Support: Gases

<u>✓</u>	GN ₂	Liquids <u>Water</u>
<u>✓</u>	GHe	<u> </u>
<u>Argon</u>	Other	<u> </u>

Environment: ✓ Standard Other

Hazardous Operations: Yes ✓ No

Total Anticipated Use Time: 21 Days

Other Facility Support Description:

Mass spectrometer leak test

TABLE 2.9-1. FURNACE MODULE-1 GROUND PROCESSING REQUIREMENTS
(Sheet 2 of 2)

- Experiment/Facility Preintegration
- Experiment/Facility Preparation
- Postmission Requirements

Description of Planned Activities:

Functional tests, sample loading, and closeout will be performed after the EAC is mounted on the rotation fixture.

Total Floor Space Required Including Space for GSE: 2000 ft²

Ceiling Height Required: 10 ft

Overhead Crane Required: ✓ Yes No Hook Height 8 ft

Facility Power Required ✓ 120 V, 1 F, 60 Hz
 208 V, 3 F, 60 Hz
 Other 220 V, Single Phase, 60 Hz

Other Facility Support: Gases GN₂ Liquids Water
 GHe
 Other

Environment ✓ Standard Other

Hazardous Operations: Yes ✓ No

Total Anticipated Use Time: 3 Days

Other Facility Support Description:

Mass spectrometer leak test

TABLE 2.9-2. FURNACE MODULE-1 INTEGRATION REQUIREMENTS

Description of Special Alignment, Calibration, Servicing, or Performance Verification and Estimated Time to Perform:


TBD

Identification of Any Constraints on Experiment/Facility Operations During Tests:

TBD

Description of Time-Critical Operations and Time Constraints:

TBD



2.10. OPERATIONS SUPPORT

Table 2.10-1 describes the physical and operational support required at the Ground Science Operations Control Center, during flight of the Space Station Furnace Facility (SSFF). Specifically, this facility has been designated as the Payload Operations and Integration Center (POIC) by the Space Station Freedom (SSF) Program.

TABLE 2.10-1. FURNACE MODULE-1 MISSION OPERATIONS SUPPORT

COMMUNICATIONS REQUIREMENTS:**Downlink Data**

Three terminals

Uplink Commands/data

Three terminals

Voice Communications

Access for three

Video

Real-time and recorded

SUPPORT EQUIPMENT:**Description****Dimensions****Power Requirements****Data Interface****REMOTE SITE INTERFACE****Location**

Off-line room for three scientists with access to monitor voice, video, and data.

Describe Interfaces

2.11. TRAINING OBJECTIVES

Presently, the training objectives are TO BE SUPPLIED. The following is a detailed generic explanation of the Integrated Requirements on Payloads (IROP) requirements.

Training required for a successful mission begins with the Principal Investigator (PI)/Payload Element Developer (PED) team identifying the training objectives for each task of the experiment. This section shall identify and describe training objectives, trainees, and instructors necessary for experiment operation. This section shall also identify the hardware and software trainers required to support flight-like training.

There are three categories of personnel who will require training to support the mission. Training objectives will be required for each category. These categories are:

- Crew
- POIC cadre
- PI/PED team

Table 2.11-1 identifies the major training objectives, the trainees, and the organizations responsible for developing and conducting required mission payload training. The Furnace Module-1 PED may develop and conduct the training or identify training to be provided by the Core facility PED and/or POIC training function.

The PI/PED team and the Payload Increment Manager (PIM) shall jointly define the training objectives for training at NASA facilities and for integrated training with other mission experiments.

The PIM shall define the increment-independent training objectives for the POIC cadre and will define the increment-independent training objectives for the crew and PI/PED team for training conducted at Marshall Space Flight Center (MSFC).

The PI/PED and PIM shall provide information detailing training objectives for each operational task. The requirements for a trainer and its fidelity shall also be specified. MSFC POIC will develop increment training requirements based on inputs from each payload flown on a specific increment.

2.11.1 PI/PED-DEFINED TRAINING

The Furnace Module-1 (FM-1) PI/PED shall define the training objectives necessary for the crew to understand the required science to operate the furnace module to obtain science data. The FM-1 PI/PED shall also define training objectives required for the POIC cadre and the PIM support of experiment operations. The FM-1 PI/PED will specify the training equipment such as flight-like hardware or trainers required to support the training objectives. Table 2.11-2 will identify the equipment to be supplied by the PI/PED and the equipment requested to be furnished by the SSFP.

TABLE 2.11-1. TRAINING PARTICIPATION

Training Objectives	Trainee	Instructor
<u>PI/PED defined</u>		
Science Background/ Experiment Objectives	Crew Cadre	SSFF PI/PED
FM-1 Systems Familiarization	Crew Cadre	FM-1 PED
FM-1 Operations	Crew Cadre	FM-1 PED
<u>PIM and PI/PED Jointly Defined</u>		
Experiment Proficiency Training	Crew Cadre*	PI/PED, PTC
Integrated Training	Crew Cadre*	PI/PED, PTC
Simulations	Crew Cadre	PI/PED, PTC
<u>PIM Defined</u>		
Increment Independent	Crew Cadre	POIC
POIC Facility Training	Cadre	PI/PED, POIC

* Limited cadre participation

TABLE 2.11-2. FURNACE MODULE-1 TRAINING OBJECTIVES

NO.	DESCRIPTION	TRAINEE	LEVEL	RESPONSIBILITY	SIMULATOR REQUIRED			COMMENTS
					YES/ NO	H/W FIDELITY	S/W Y/N	
1.0	SCIENCE BACKGROUND	Crew, cadre	c/a	FM-1 PVPED	NO			
1.1	FM-1 Science Basis and Significance	Crew, cadre	c/a	FM-1 PVPED	NO			Classroom Instruction
1.2	FM-1 Science Objectives	Crew, cadre	c/a	FM-1 PVPED	NO			
1.3	FM-1 Science Theory	Crew, cadre	c/a	FM-1 PVPED	NO			
1.4	FM-1 Experiment Operations Philosophy	Crew, cadre	c/a	FM-1 PVPED	NO			
2.0	FM-1 SYSTEMS FAMILIARIZATION							
2.1	Hardware	Crew, cadre	b/a	FM-1 PVPED	YES	a	YES	FM-1 PVPED
2.1.1	Rack location							
2.1.2	Instrument Components							
2.1.3	Stowage locations							
2.1.4	FM-1 Command & Display							
2.1.5	DMS Interfaces							
2.2	Software	Crew, cadre	b/a	FM-1 PVPED	YES	a	YES	FM-1 PVPED
2.2.1	DMS							
2.2.2	Displays							
2.2.3	Command Capabilities							
2.2.4	Keyboard/MPAC/uplink Timeline requirements							
2.3	Data Collection	Crew, cadre	b/a	FM-1 PVPED	YES	a	YES	FM-1 PVPED
2.3.1	Onboard							
2.3.2	Downlink							

The PI/PED shall supply objectives for training in the following areas. Other areas may also be included.

- Science Background and Experiment Objectives - Basis and significance of experiment, relationship to precursor experiments, specific objectives of experiment.
- Experiment Systems Familiarization (hardware and software) - Hardware and software elements [both on-orbit and ground support equipment (GSE)] that constitute the experiment system.
- Experiment Operations (nominal, malfunction, in-flight maintenance) - Hands-on training using breadboards, simulators, or flight hardware/software.

The knowledge and skill level for each operational task shall be identified. Tables 2.11-3 and 2.11-4 provide a means of coding the level of proficiency to which the student should be trained in order to accomplish the task. The information will also be used in developing course materials and training equipment.

2.11.2 PIM AND PI/PED JOINTLY DEFINED TRAINING

The PIM and the PI/PED team will jointly define the following training objectives:

- Experiment Proficiency Training - Repetitive exercise of specific experiment operations to develop and maintain operational skills at a flight readiness level.
- Integrated Training - Repetitive exercise of selected portions of the integrated timeline conducted within a simulated mission operations environment and with onboard crew operations as its focus.
- Simulations - Exercise of major portions of the integrated timeline conducted at the highest level of fidelity. Includes all payload elements and may include element of the SSF operations. Exercise crew, POIC cadre, PI/PED team, and SSF operations teams in nominal and contingency operations with emphasis on developing specific skills, strategies, and interactions.

Table 2.11-2 shall be completed using inputs provided by the PIM and PI/PED team. This information is normally obtained from the Increment Training Assessment Team (TAT). The TAT is composed of representatives from POIC, PIM, and PI/PED team who gather, review, and assess mission training needs. The TAT reviews mission documentation and obtains experiment operations and interface requirements for the PIs and from design reviews. It reviews available training equipment and assess the need for development of trainers by the PI/PED team or NASA to accomplish training objectives.

Experiment/PTC/POIC operational training interface needs such as data flow, power and thermal requirements, trainer control and display, and experiment GSE shall be identified in this paragraph.

TABLE 2.11-3. KNOWLEDGE LEVELS

CODE	TRAINEE WILL BE ABLE TO:
a	Recall nomenclature, simple facts, or simple procedures involved in the task or operation.
b	Determine step-by-step procedures for sets of tasks or operations or for accomplishing important decisions.
c	Explain why and when each task or operation must be done.
d	Predict, identify, and solve problems related to the task or operation.

TABLE 2.11-4. SKILL PROFICIENCY LEVELS

CODE	TRAINEE WILL BE ABLE TO:
1	Accomplish most task activities only by being told or shown how.
2	Accomplish most of the behaviors in task or activity, but not necessarily to desired levels of speed or accuracy.
3	Accomplish behaviors in a task or activity at minimum acceptable levels of speed or accuracy.
4	Accomplish all behaviors in an activity at highest levels of speed or accuracy and be able to tell or show others how to do the activities.

Note: This is not a design requirement, but an instrument to document training objectives that present an early need for training equipment and interfaces with the training facility.

2.11.3 PIM-DEFINED TRAINING

The PIM will define the following training objectives:

- Increment-Independent Training - Includes training on SSF and payload support systems and subsystems that remain relatively constant from increment to increment. Examples are Data Management System (DMS), SSF overview, SSF Caution and Warning System, etc.
- POIC Facility Training - Classroom and hands-on opportunities for training on specific POIC facilities such as Operations Management Information System (OMIS), communications protocols, and generic POIC procedures.

2.11.3.1 Increment-Independent Training - Crew

The increment-independent training for the crew on SSF systems and procedures shall be defined by Johnson Space Center (JSC) in JSC training documents and shall be provided at JSC/Kennedy Space Center (KSC).

Increment-independent training for the crew to support payload operations shall be defined by the PIM and provided at Marshall Space Flight Center (MSFC).

The training objectives, trainee responsibility, and any required training equipment shall be listed in Table 2.11-2.

2.11.3.2 Increment-Independent Training - PI/PED Team

The increment-independent training required for the PI/PED team to support the increment at MSFC is defined in this E/FRD. Trainee responsibility and required training equipment shall be listed in Table 2.11-2.

2.11.3.3 Increment-Independent Training - POIC Cadre

The increment-independent training required for the POIC cadre to support the increment is defined in the MSFC Increment-Independent Training Plan.

2.11.4 TRAINING SIMULATION

Experiment trainers will be developed by the PI/PED based upon analysis of training objectives, available training tools, existing trainers, and availability of training opportunities on flight hardware.

The FM-1 PI/PED shall participate in trainer development by identifying training needs in this document. The PI/PED shall provide detailed data inputs to the TAT and Payload Training

Requirement Document (PTRD) and shall participate in Payload Trainer design acceptance reviews.

Training objectives that require a trainer to accomplish the training task shall be listed in this paragraph outlining the overall desired capabilities.


Examples:

Joystick Operation - Capable of interaction with control panel and trainer software.

Scene Generation - Capable of tracking any predefined target.

2.11.5 TRAINING PARTICIPATION

The PI/PED shall participate as instructor or trainee in formal training programs as outlined in Tables 2.11-1, 2.11-2, 2.11-3 and 2.11-4. Schedules and detailed objectives will be developed and maintained in the User Payload Training Plan (UPTP).



2.12. ENVIRONMENTAL CONTAMINATION DATA REQUIREMENTS

Tables 2.12-1, 2.12-2, and 2.12-3 define the environmental contamination requirements for Furnace Module-1.

TABLE 2.12-1. FLIGHT . IRONMENTAL LIMITS

SENSITIVITY LIMIT		EXPERIMENT GENERATED			
OPERATING		NONOPERATING		NONOPERATING	
MIN	MAX	MIN	MAX	MIN	MAX
N/A	N/A	N/A	N/A	0	0
N/A	N/A	N/A	N/A	0	0
N/A	N/A	N/A	N/A	-	-
CONTAMINATION MODULE ITEMS					
A. PARTICULATE SIZE (μm), number/ m^3					
B. TRACE GASES (type & ppm)					
PRESSURE (N/m^2)					

TABLE 2.12-2. EXTERNAL CONTAMINATION SOURCES

Does experiment/facility release (vent, purge) any material overboard on orbit?

Yes ✓ No _____

PARAMETER	DESCRIPTION
FOs of Occurrence	ALL
Frequency	TBD
Duration	TBD
Composition	Argon, Nitrogen, Air
Phase State (solid, liquid, or gas)	Gas
Quantity or Rate of Release	7 to 37 lbm*

* Maximum, assumes active pressure control for four samples and one manual sample exchange.

TABLE 2.12-3. ON-ORBIT EXTERNAL CONTAMINATION CONTROL SENSITIVITY

To understand and satisfy the on-orbit external contamination limits required by this experiment, please answer the following questions:

1. Is the equipment subject to corona? Yes No
2. Are the experiment data affected by deposition of contaminants on sensitive surfaces? Yes No
 - If yes, then answer the following:
 - Is the concern for deposition from particles, film/molecular, or both?
 - What is the FOV for receiving deposition from return flux?
 - What is the surface temperature of the sensitive element?
 - What are the limits of deposition in terms of experiment effects (e.g., 10% degradation at 1400 Å)?
 - List the FOs where deposition is a concern.
 - Is a controllable cover provided for non-data-collecting periods?
3. Is the experiment affected by induced contamination, such as water, CO₂, etc., in the FOV of the sensor? Yes No
 - If yes, then answer the following:
 - Is the concern for particles, molecular, or both?
 - Briefly explain the allowable effects on the experiment; qualify the limits if possible (e.g., 10% modification of ambient environment composition; or 10% degradation of 1400 Å waveband; or allowable molecules/cm² column density).
 - List the FOs where induced contamination is a concern.